




1974 / 75 / 76 / 77



ski-doo[®]

TECHNICAL DATA MANUAL





I N D E X

DESCRIPTION	PAGE	DESCRIPTION	PAGE
MODEL IDENTIFICATION	1 - 2	TRACK TENSION SPECIFICATIONS	207 to 208
ENGINE TOLERANCES MEASUREMENTS	3 to 7	TRACK SPECIFICATIONS	209 to 211
LIST OF ENGINE SECTIONS	8	DRIVE BELT NUMBER	212
247, 302 ENGINE TYPE	9 to 20	DRIVE PULLEY SPECIFICATIONS	213 to 216
248, 294 ENGINE TYPE	21 to 28	DRIVE PULLEY WEAR PADS	217
248 ENGINE TYPE (FROM 1975)	29 to 40	DRIVE PULLEY SPRING TENSION	218
245 ENGINE TYPE (UP TO SERIAL NO 2762 210).	41 to 54	PULLEY ALIGNMENT SPECIFICATIONS	219 to 220
245, 345 ENGINE TYPE (FROM 1976)	55 to 66	SPROCKET AND CHAIN SPECIFICATIONS	221 to 224
305, 338, 343, 401 ENGINE TYPE	67 to 74	STEERING SYSTEM	225 to 226
305, 343 ENGINE TYPE (FROM 1976)	75 to 88	SKI SYSTEM	227 to 228
346, 396, 436 ENGINE TYPE	89 to 92	ENGINE TECHNICAL DATA	229 to 232
346, 436 ENGINE TYPE (FROM 1977)	93 to 100	IGNITION TIMING SPECIFICATIONS	233 to 236
434 440 ENGINE TYPE	101 to 108	CARBURETOR SPECIFICATIONS	237 to 242
440 ENGINE TYPE (FROM 1976)	109 to 120	SPARK PLUG CHART	243 to 244
640 ENGINE TYPE	121 to 128	COIL RESISTANCE CHART	245 to 246
640 ENGINE TYPE (FROM 1976)	129 to 140		
IGNITION TIMING (TWO CYLINDER ENGINE).	141 to 144		
IGNITION TIMING (ONE BYLINDER ENGINE).	145 to 146		
IGNITION TIMING (C.D. IGNITION).	147 to 148		
ELECTRICAL CHARTS.	149 to 186		
BOMBARDIER IGNITION TESTER	187 to 196		
TOOLS	197 to 206		



SKI-DOO 1977	MODEL
Elan 250 M	3017
Elan 250 T	3018
Elan (Europe) 250 M	3019
Elan (Europe) 250 T	3020
Elan Stretch (Europe) 250 M	3021
Elan Stretch 250 M	3022
Olympique 300 M	3131
Olympique 300 T	3132
Olympique 340	3133
Olympique 340 E	3134
Olympique (Europe) 340	3137
Olympique 440	3138
Everest 440	3434
Everest 440 E	3435
Everest 340	3442
Everest 340 E	3443
Everest 444 L/C	3444
Everest (Europe) 340	3445
Everest (Europe) 440	3446
T'NT FA 340	3439
T'NT FA 440	3440
RV 340	3441
T'NT FC 440	3447
Cross Country 340 LC	3559
Blizzard 440 LC	3560
Blizzard X 254	3560-01
Blizzard X 354	3560-02
Blizzard X 454	3560-03
Alpine 640 ER	3313
Alpine (Europe) 640 ER	3314
Alpine (White) 640 ER	3315

SKI-DOO 1976	MODEL
Elan 250	3013
Elan 250 T	3014
Elan 250 M	3015
Elan Europe 250 M	3016
Olympique 300	3122
Olympique 300 T	3123
Olympique 300 T E	3124
Olympique 340	3125
Olympique 340 E	3126
Olympique 440	3127
Olympique Europe 300	3128
Olympique Europe 300 T	3129
Olympique Europe 340	3130
T'NT FC 340	3428
T'NT FC 340 E	3429
Everest 440	3430
Everest 440 E	3431
Everest LC	3436
RV 250	3432
RV 340	3433
Alpine 640 ER	3311
Alpine Europe 640 ER	3312

<u>SKI-DOO 1975</u>	<u>MODEL</u>	<u>SKI-DOO 1974</u>	<u>MODEL</u>
Elan 250	3010	Elan 250	3005
Elan 250 T	3011	Elan 250 E	3006
Elan 300	3012	Elan 250 T	3007
		Elan 250 Deluxe	3008
Olympique 300	3112	Elan 294 SS	3009
Olympique 300E	3113		
Olympique 340	3119	Olympique 300	4101
Olympique 340E	3120	Olympique 340	3107-09
		Olympique 340 S	3117
TNT F.C. 340	3418	Olympique 340 E	3108
TNT F.C. 340E	3419	Olympique 340 ES	3118
TNT F.C. 440	3420	Olympique 400	3104-10
TNT F.C. 440E	3421	Olympique 400 S	3114
		Olympique 400 E	3105
Everest 440	3422	Olympique 400 ES	3115
Everest 440E	3423	Olympique 440	3106
		Olympique 440 S	3116
TNT F.A. 340	3426		
TNT F.A. 440	3427	TNT 295	3409
		TNT 340	3404
Alpine 640 ER		TNT 340 E	3405
(1st run)	3307	TNT 440	3406
Alpine 640 ER		TNT 440 E	3407
(2nd run)	3308	TNT 440 Everest	3408
Alpine 640 ER			
(3rd run)	3309	TNT F.A. 340	3414
Alpine 640 ER		TNT F.A. 400	3415
(4th run)	3310	TNT F.A. 440	3416
Stock Racer 245	3554	Nordic 640 ER	3205
		Alpine 440 ER	3304
		Alpine 640 ER	3305
		Elite 440 ER	3701


ENGINE TOLERANCES MEASUREMENT

CYLINDER TAPER

Maximum: 0.08 mm (.003")

Compare cylinder diameter 16 mm (5/8") from top of cylinder with down to just below the intake port.


On rotary valve engines, measure just below auxiliary transfer port, facing exhaust port. If the difference exceeds 0.08 mm (.003") the cylinder should be rebored and honed or should be replaced.



CYLINDER OUT OF ROUND

Maximum: 0.05 mm (.002")


Measuring 16 mm (5/8") from top of cylinder with a cylinder gauge, check if the cylinder out of round is more than 0.05 mm (.002"). If larger, cylinder should be rebored and honed or should be replaced.



SECTION 04 SUB-SECTION 01 (ENGINE TOLERANCES MEASUREMENT)

Accurate measurement


To determine piston to wall clearance, the piston should be measured 8 mm (5/16") above its bottom edge and the cylinder should be measured 16 mm (5/8") below its top edge.



The difference between these two measurements should be within specified tolerance.

Quick measurement

Place cylinder upside down on a work-bench and press a feeler gauge against the cylinder wall (intake side) while trying to insert the piston without any ring in its usual position.




The thickest possible to use feeler gauge will determine the piston to wall clearance.

RING END GAP

Position ring half way between transfer ports and intake port. On rotary valve engines, position ring just below transfer ports.

NOTE: In order to correctly position the ring in the cylinder, use piston as a pusher.


Using a feeler gauge, check ring end gap. If gap exceeds specified tolerance the ring should be replaced.



PISTON RING/GROOVE CLEARANCE

Maximum: 0.20 mm (.008")


Using a feeler gauge check clearance between rectangular ring and groove. If clearance exceeds 0.20 mm (.008"), replace piston.



CRANKSHAFT DEFLECTION

Maximum: 0.06 mm (.0024")

With the crankshaft positioned between a center lathe, install a dial indicator as close as possible to crankshaft blade then measure deflection on each side. If deflection exceeds 0.06 mm (.0024") the crankshaft should be repaired by a specialized shop or it should be replaced.




CONNECTING ROD ALIGNMENT

Check if connecting rod is bent as follows:

- Once engine crankcase is assembled with the piston mounted on connecting rod without its piston rings, position cylinder on piston.

NOTE: The cylinder/crankcase gasket must not be installed.

- Rotate crankshaft slowly and at the same time observe piston movement within the cylinder. If piston bear against one side (PTO or mag. side), the connecting rod is bent.





- To correct, position needle bearing and gudgeon pin on connecting rod then pry connecting rod as illustrated.

CONNECTING ROD BIG END AXIAL PLAY

Maximum: 0.5 mm (.020")

Using a feeler gauge measure distance between connecting rod and thrust washer. If axial play exceeds 0.5 mm (.020"), the crankshaft should be replaced.



SECTION 04

SUB-SECTION 01 (ENGINE TOLERANCES/ MEASUREMENT)

CRANKSHAFT END-PLAY


Maximum: 0.10 mm (.004")

○ NOTE: Crankshaft end-play is adjusted only when crankshaft and/or crankcase is replaced.



One cylinder engine (247)

Maximum crankshaft end-play should be 0.10 mm (.004"). To determine necessary correction:

a) Measure crankcase. To do this first measure each half from mating surface to bottom of bearing seat. Add measurements of both halves then add 0.15 mm (.006") for gasket displacement. Equals **A**.



b) Measure thickness of each ball bearing. Measure distance between crankshaft blades. Add measurements. Total equals **B**.




c) Subtract measurement **B** from measurement **A** minus tolerance of 0.10 mm (.004") maximum. Total balance is distance to be shimmed. Shim(s) must be located between magneto side bearing and crankshaft blade.

Crankshaft end-play (0.1 mm (.004") maximum) is adjusted with a shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shims, proceed as follows:


Remove magneto side bearing(s) and existing shim(s). Slide the appropriate bearing simulator and retaining washers onto the crankshaft.

Position crankshaft assembly into crankcase lower half, making sure that retaining washers are correctly seated into the grooves.

Gently tap crankshaft mag. side blade until P.T.O. side bearing bears against retaining washer.



Any free-play between the bearing simulator and magneto side retaining washer, minus 0.1 mm (.004") maximum end-play is the distance to be covered by shims. Shims are available in variable thickness according to engine type.



LIST OF ENGINE SECTIONS

247, 302

248, 294

248 (FROM 1975)

245 (UP TO SERIAL NO. 2 762 210)

245, 345 (FROM 1976)

305, 338, 343 401

305, 343 (FROM 1976)

346, 396, 436

346, 436 (FROM 1977)

434, 440

440 (FROM 1976)

640


640 (FROM 1976)

247, 302 ENGINE TYPE

247 MUFFLER & SUPPORT



SECTION 04
SUB-SECTION 01 (ONE CYLINDER ENGINE)



MUFFLER & SUPPORT

247 TYPE

REMOVAL FROM VEHICLE

Remove or disconnect the following then lift engine from vehicle.

- Pulley guard.
- Drive belt.
- Muffler.
- Choke knob.
- Decompressor (if applicable).
- Throttle cable.
- Fuel lines.
- Electrical connector.

CAUTION: On electric start model, disconnect negative cable (ground) from battery post before disconnecting other wires.

- Separate steering column support at upper column.
- Engine mount nuts.

DISASSEMBLY & ASSEMBLY

- ⓐ Torque to 3.2 kg-m (23 ft-lbs).
- ⓑ Torque to 3.6 kg-m (26 ft-lbs).
- ⓒ Torque to 2.2 kg-m (16 ft-lbs).

INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the following.

- Check ignition timing prior to installation in vehicle.
- Check tightness of engine mount nuts, and drive pulley bolt.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

302 TYPE

REMOVAL FROM VEHICLE

Remove or disconnect the following then lift engine from vehicle.

- Pulley guard.
- Drive belt.
- Air silencer box.
- Throttle cable.
- Fuel lines.
- Muffler.
- Electrical connector.
- Engine mount nuts.

DISASSEMBLY & ASSEMBLY

- ⓐ Torque to 3.6 kg-m (26 ft-lbs).
- ⓒ Torque to 2.2 kg-m (16 ft-lbs).


INSTALLATION

To install engine on vehicle, inverse removal procedure. However, pay attention to the following.

- Check ignition timing prior to installation in vehicle.
- Check tightness of engine mount nuts, and drive pulley bolt.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

SECTION 04
SUB-SECTION 01 (ONE CYLINDER ENGINE)

BOTTOM END



- 1. Crankcase half (P.T.O. side)
- 2. Crankcase half (Mag side)
- 3. Crankshaft
- 4. Polyamid ring
- 5. Bearing
- 6. Shim
- 7. Dowel tube
- 8. Wires grommet
- 9. Stud
- 10. Gasket
- 11. Oil seal
- 12. Bolt or nut
- 13. Lockwasher
- 14. Stud (cylinder)
- 15. Washer (head)
- 16. Nut (head)
- 17. Distance sleeve
- 18. Stud
- 19. Lockwasher
- 20. Nut

- 21. Labyrinth ring (fan)
- 22. Screw
- 23. Shim
- 24. Spring
- 25. Breaker point cam
- 26. Nut
- 27. Loctite Lock'n Seal (no 242)
- 28. Needle bearing
- 29. Woodruff key

BOTTOM END

CLEANING

Discard all oil seals and gaskets.

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY


General

Refer to Technical Data Section for component fitted tolerance and wear limit. If necessary, refer to Drive Pulley Section to remove drive pulley.



①② When disassembling / assembling crankcase halves, do not use heat the crankcase. If heat is necessary, temperature must not exceed 55° C (130° F).

③④ Crankshaft end-play should be between 0.10-0.40 mm (.004-.016"). To determine necessary correction:

a) Measure crankcase. To do this first measure each half from mating surface to bottom of bearing seat. Add measurements of both halves then add 0.15 mm (.006") for gasket displacement. **Equals A.**



b) Measure thickness of each ball bearing. Measure distance between crankshaft blades. Add measurements. **Total equals B.**




c) Subtract measurement B from measurement A minus tolerance of 0.10-0.40 mm (.004-.016"). Total balance is distance to be shimmed. Shim(s) must be located between magneto side bearing and crankshaft blade.

○ **NOTE:** Crankshaft end-play is adjusted only when crankshaft and / or crankcase is replaced.

⑤ Do not remove unless necessary.


To remove, heat slightly with a butane torch then pry out using a screwdriver.

To install, apply oil on outside diameter then use a suitable pusher.




SECTION 04
SUB-SECTION 01 (ONE CYLINDER ENGINE)

⑤ To remove bearing from crankshaft use a protective cap and special puller as illustrated. (See Tool Section).




○ **NOTE:** Prior to magneto side bearing installation, install required shim(s) (crankshaft end play) on crankshaft extension. At assembly, place bearings into an oil container and heat the oil to 100° C (210° F) for 5 to 10 min. This will expand the bearings and permit them to slide easily on the shaft.

⑩ To remove or install new seal into crankcase use an appropriate oil seal pusher as illustrated. (See Tool Section).



Also, prior to crankcase adjoining, install a protector sleeve on each crankshaft extension to prevent oil seal damage (See Tool Section). Apply a light coat of lithium grease on seal lip. Seal outer surface should be flush with crankcase.


⑫ At assembly, torque to 2.2 kg-m (16 ft-lbs) following illustrated sequence.



⑬ Torque to 3.6 kg-m (26 ft-lbs).


⑭ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support. (See Tool Section).

At assembly apply Loctite Lock'n Seal 242 on threads then torque retaining nut to 7.5 kg-m (54 ft-lbs).



⑮ Clean thoroughly then apply Loctite Lock'n Seal no. 242 or equivalent.

TOP END



- 1. Ring
- 2. Piston
- 3. Gudgeon pin
- 4. Circlip
- 5. Cylinder
- 6. Cylinder head
- 7. Gasket (head / cylinder)
- 8. Gasket (cylinder / crankcase)
- 9. Stud
- 10. Gasket
- 11. Isolating flange
- 12. Locking tab
- 13. Nut
- 14. Exhaust gasket
- 15. Locking tab (Olympique)
- 16. Nut
- 17. Muffer
- 18. Flat washer
- 19. Nut (head)

247
ONLY

- 20. Locking sleeve
- 21. Decompressor
- 22. Cable
- 23. Switch housing
- 24. Cap nut
- 25. Knob
- 26. Spring plate
- 27. Spring plate reinforcement
- 28. Spring lock
- 29. Lockwasher
- 30. Screw

SECTION 04
SUB-SECTION 01 (ONE CYLINDER ENGINE)

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

NOTE: The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY & ASSEMBLY


NOTE: Refer to Technical Data for component fitted tolerance and wear limit.

Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.


CAUTION: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the piston over the connecting rod with the letters "AUS" (over an arrow on the piston dome) facing in direction of the exhaust port.

EXHAUST




NOTE: Once the circlips are installed turn each circlip so the circlip break is not directly on piston notch. Remove any burrs on piston caused through circlip installation with very fine emery cloth.



Position cylinder head on cylinder with fins in line with crankshaft center line. Cross torque retaining nut to 1.9-2.2 kg-m (14-16 ft-lbs.)

Tab washer should be replaced if bent more than three (3) times. If in doubt, replace.

At assembly, torque to 2.2 kg-m (16 ft-lbs.).



MAGNETO

CLEANING

Clean all metal components in a non-ferrous metal cleaner.


CAUTION: Clean armature using only a clean cloth.

DISASSEMBLY & ASSEMBLY

⑪ At assembly, apply a small amount of grease into spring seating.

⑫ With magneto retaining nut removed and hold on support in place, install special puller onto hub.

Tighten puller nut at same time, tap on nut head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242, position magneto on crankshaft with the keyway and the cam notch position as illustrated.

Apply Loctite Lock'n Seal 242 on threads of retaining nut then torque to 7.5 kg·m (54 ft·lbs).



⑬ Apply Loctite Lock'n Seal 242 on threads.

⑭ To replace a capacitor, it is first necessary to disconnect the two (2) black leads using a soldering iron. The capacitor can then be driven out of the armature plate using a suitable drift. To reinstall, inverse procedure.

⑮ ⑯ ⑰ Whenever a coil is replaced, the air gap (distance between magnet and coil end) must be adjusted.

To check air gap, insert a feeler gauge of 0.25-0.38 mm (.010"-.015") between magnet and coil ends. If necessary to adjust, slacken retaining screws and relocate coil.




⑱ When replacing breaker point set, apply a light coat of grease on lubricating wick.

⑲ Do not remove pivot pin unless replacement is needed, if removed reinstall with Loctite Lock'n Seal on threads.

Old type breaker point set can be replaced by new type if pivot pin is removed. When installing new breaker point type it is advisable to fill the pivot pin cavity of the armature plate with Loctite 277 (thick red solution).

COOLING SYSTEM



MANUAL START ENGINE

ELECTRIC START ENGINE

1. Fan cowl ass'y
2. Fan cowl stud (4)
3. Spring bracket
4. Labyrinth ring (manual start only)
5. Screw (4)
6. Screw
7. Ground cable
8. Cable clamp
9. Flat head screw
10. Spring washer

11. Nut
12. Air deflector
13. Fan cowl cover
14. Fan cowl
15. Lock washer
16. Cylindrical head screw (2)
17. Dowel screw (2)
18. Allen screw (4)
19. Cylindrical head screw (long)
20. Starter stud

21. Lock washer (4)
22. Magneto ring
23. Fan ass'y
24. Starter ring gear
25. Lock washer (8)
26. Hex. cap screw (8)
27. Stud
28. Lock washer (4)
29. Nut (4)
30. Spring retainer

COOLING SYSTEM

CLEANING

Clean all metal components in a non-ferrous metal cleaner.

▼ **CAUTION:** Clean armature using only a clean cloth.


DISASSEMBLY & ASSEMBLY

④ At assembly, position labyrinth ring with bevelled side on top.

⑬ ⑭ ⑮ ⑯ To remove fan cowl ass'y and / or magneto from electric start engine, it is first necessary to separate fan cowl cover from fan cowl.

To remove magneto ring / fan ass'y from engine, lock crankshaft in position with special hold-on support. Remove magneto retaining nut, then install special puller onto hub (See Tool Section).

Tighten puller nut and at same time, tap on nut head with a hammer to release magneto from its taper. At assembly, torque retaining nut to 7.5 kg-m (54 ft-lbs.)




⑤ ⑬ ⑭ ⑮ At assembly, apply Loctite "Lock'n Seal 242" on screws threads.

○ **NOTE:** It should be noted that to correctly remove a Loctite locked screw, it is first necessary to tap on head of screw to break Loctite bond. This will eliminate the possibility of screw breakage.

248, 294 ENGINE TYPE

BOTTOM END




SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)


BOTTOM END

- | | | |
|---------------------------------------|-----------------------------------|-------------------------------|
| 1. Crankshaft | 15. Magneto retaining nut | 29. Lock washer (2) |
| 2. "O" ring (4 or 6) | 16. Labyrinth sealing ring | 30. Nut (2) |
| 3. Woodruff key | 17. Crankcase lower half | 31. Spacer (4, if applicable) |
| 4. Needle bearing | 18. Dowel pin | 32. Stud (4) |
| 5. Ball bearing (2 or 3) | 19. Crankcase upper half | 33. Lock washer (4) |
| 6. Retaining disc | 20. Cylinder stud | 34. Nut (4) |
| 7. Distance sleeve (16 mm - .232") | 21. Crankcase stud (294 only) (2) | 35. Capacitor (2) |
| 8. Distance sleeve (12 mm - .0472") | 22. Crankcase stud (8) | 36. Screw (2) |
| 9. Oil seal (P.T.O.) | 23. Crankcase stud (2) | 37. Nut (2) |
| 10. Distance sleeve (17.7 mm - .697") | 24. Clamp | 38. Ignition coil |
| 11. Distance sleeve (9.7 mm - .382") | 25. Cap | 39. Lock washer (6) |
| 12. Shim(s) | 26. Spring washer (8 or 10) | 40. Screw (6) |
| 13. Oil seal (Mag) | 27. Lock washer (8 or 10) | 41. Ignition box cover |
| 14. Lock washer | 28. Nut (8 or 10) | 42. Screw |

TOP END




MAGNETO



- | | | | | |
|--------------------|----------------------|-----------------------------|-----------------------|--------------------|
| 1. Nut (3) | 6. Magneto ring | 11. Spacer | 15. Pivot pin | 20. Washer |
| 2. Lock washer (3) | 7. Screw (3) | 12. Ignition generator coil | 16. Breaker point set | 21. Screw |
| 3. Starting pulley | 8. Screw (4) | 13. Armature plate | 17. Bolt | 22. Washer |
| 4. Stud (3) | 9. Spring washer (4) | 14. Lighting coil | 18. Lock washer | 23. Retaining clip |
| 5. Magneto housing | 10. Brake light coil | | 19. Nut | |

COOLING SYSTEM



- | | | | | |
|-------------------------|-------------------------|------------------------|---------------------|----------------------------|
| 1. Cylinder cowl | 7. Lock washer | 13. Ball bearing | 19. Lock washer | 25. Stud |
| 2. Allen screw | 8. Cowl retainer washer | 14. Shim (1 mm/.040") | 20. Fan nut | 26. Nut |
| 3. Elastic stop nut (3) | 9. Spring washer | 15. Locking ring | 21. Fan housing | 27. Junction block bracket |
| 4. Stud (2) | 10. Allen screw | 16. Shim (as required) | 22. Lock washer (4) | 28. Fan belt |
| 5. Washer (2) | 11. Fan shaft | 17. Pulley half | 23. Screw | 29. Fan cover |
| 6. Bolt | 12. Woodruff key | 18. Fan | 24. Screw (2) | |

SECTION 04 SUB-SECTION 02 (TWO CYLINDER ENGINE)

REMOVAL

Remove or disconnect the following, then lift engine from vehicle.

Front-mounted engine

- Drive belt
- Muffler
- Rewind starter
- Air silencer
- Choke cable
- Throttle cable
- Fuel lines at carburetor

Note: Secure fuel lines to steering support so that the opened ends are higher than the fuel tank.

- Electrical connector
- Engine mount nuts

Center mounted engine

- Drive belt
- Muffler
- Choke knob
- Throttle cable
- Fuel lines
- Electrical connectors
- Steering column support at upper column
- Engine mount nuts


DISASSEMBLY & ASSEMBLY

If necessary, remove drive pulley as described in drive pulley section.

Note: Refer to Technical Data Section for component fitted tolerance and wear limit.

Bottom end

③ To remove bearing from crankshaft use a protective cap and special puller as illustrated. (See Tool Section).



Note: Prior to magneto side bearing installation, determine crankshaft end-play and install required shim (s) on crankshaft extension.

At assembly, place bearings into an oil container and heat the oil to 200° F. for 5 to 10 min. This will expand the bearings and permit them to slide easily on the shaft. Install bearings with groove outward.


④ Crankshaft end-play is adjusted with a shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim, proceed as follows.

Remove magneto side bearing and existing shim(s). Slide the appropriate crankshaft ring and retaining disc onto the crankshaft. (See Tool Section).

Position crankshaft assembly into crankcase lower half, making sure that retaining discs are correctly seated into the grooves.


Gently tap crankshaft until P.T.O. side bearing bears against retaining disc.

Any free-play between the crankshaft ring and magneto side retaining disc, minus recommended end-play, is the distance to be covered by shim(s). Shims are available in thickness of 0.1 mm/.004", 0.2 mm/.008", 0.3 mm/.012", 0.5 mm/.020", 1 mm/.039".



Note: Crankshaft end-play is adjusted only when crankshaft and/or crankcase is replaced.

⑤ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).




SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

At assembly torque retaining nut to 42-50 ft-lb.

⑫ To increase sealing between left and right crankcase halves, on engine equipped with an external labyrinth seal, a steel ring is available, (part no. 414-2072).


Prior to installation, the steel ring must be stretched open. To do this, slide the ring onto the neck of a soft drink bottle (2 1/2" outside diameter).

Install steel ring on crankshaft labyrinth as illustrated.



⑬ ⑭ ⑮ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves.

Prior to joining of crankcase halves, apply a light coat of "Loctite" crankcase sealant to mating surfaces of bottom half. Position spring washers, lock washers and nuts on crankcase studs then torque nuts to 14-16 ft-lb following illustrated sequence.



Note: Torque the two smaller nuts on magneto side to 9 ft-lb.

⑯ At assembly torque crankcase/support nut to 23-29 ft-lb.

Top end

⑰ ⑱ ⑲ Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to re-

move circlip from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

Caution: When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters "AUS", over an arrow on the piston dome, facing in direction of the exhaust port.



Note: Once circlips are installed, turn each circlip so that the circlip break is not directly on piston notch. Remove any burrs on piston caused through circlip installation with very fine emery cloth.



⑳ ㉑ To insure correct cylinder alignment, install and secure intake and exhaust manifolds on cylinder prior to cylinder head tightening. Cross torque cylinder head nuts to 14-16 ft-lb.


Note: Torque each head individually.

㉒ At assembly, torque to 14-16 ft-lb.

Magneto

㉓ At assembly torque to 9 ft-lb.

㉔ ㉕ ㉖ With magneto retaining nut removed and hold-on



SECTION 04 SUB-SECTION 02 (TWO CYLINDER ENGINE)

support in place, install special puller onto hub. Tighten puller bolt and at same time, tap bolt head using a hammer to release magneto from its taper. (See Tool Section)

Note: Do not separate magneto housing from magneto ring unless necessary. At assembly, apply Loctite "Lock'n Seal" on magneto housing hub where magneto ring center bore sits.

⑩ ⑫ ⑭ When a coil is replaced, the air gap between magnet and armature must be adjusted.

To check air gap insert a feeler of correct thickness (.025 mm/.010"-.039 mm/.015") between magnet and each armature end.



If necessary to adjust, slacken retaining screw and relocate coil.

⑮ Do not remove pivot pin unless replacement is needed. At assembly, apply Loctite "Lock'n Seal" on threads.

⑯ When replacing breaker point set, apply a light coat of grease on pivot pin and rubbing block. Recheck engine timing.


Cooling system

⑩ ⑲ ⑳ ㉑ At assembly, apply Loctite "Lock'n Seal" on threads to prevent loosening through vibration.

Note: To correctly remove a "Loctite" locked screw, it is necessary to slightly tap on head of screwdriver to break bond.

⑬ ⑭ ⑮ To remove or install bearing, heat bearing housing to 140°-160° F.

⑯ ⑰ ⑱ ㉒ ㉓ To remove or install fan retaining nut, lock fan in position with fan holder wrench. (See Tool Section).



At assembly, torque retaining nut to 42-50 ft-lb. Make sure that belt is not squeezed between pulley halves.


Correct fan belt free-play is 1/4". To adjust, add or remove shim(s) between inner and outer pulley halves. Excess shim(s) must be positioned between outer pulley half and fan.

Fan belt alignment

For reliable fan belt operation, the two fan belt pulleys must lie within .020" of either side of the pulley center line.

Prior to checking alignment, check fan belt free-play.

Position and secure aligning tool (See Tool Section) on magneto housing as illustrated.



Turn knurled knob to center bent feeler rod between pulley halves. Insert a .040" feeler gauge between tool arm and knurled knobs. If gauge fits between both sides of the arms, the setting lies within tolerance.

If clearance is smaller than .040" on one side, shim(s) must be added or removed between bearing and inner pulley half to bring both gaps within tolerance of .060" \pm .020".

Excess shim(s) should be stored between outer pulley half and fan.

CLEANING

Discard all oil seals, gaskets and "O" rings.

Clean all metal components in a non-ferrous metal cleaner.

Caution: Clean armature with a clean cloth only.

Scrape carbon formation from cylinder exhaust ports, cylinder heads and piston domes.

Note: The letter "AUS" over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, and/or a piece of broken ring.

Remove old sealant from mating surfaces of crankcase with a scraper blade.

Caution: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


INSTALLATION

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Torque engine mount nuts to 18-23 ft-lb.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.
- Check ignition timing.

248 ENGINE TYPE (FROM 1975)

ENGINE SUPPORT & MUFFLER



- | | | |
|----------------------------|----------------------|-------------------|
| 1. Carriage bolt | 13. Screw | 25. Clip |
| 2. Threaded spacer bushing | 14. Exhaust manifold | 26. Washer |
| 3. Rubber insulator | 15. Aluminum ring | 27. Screw |
| 4. Engine support | 16. Muffler | 28. Plug |
| 5. Washer | 17. Spring | 29. Rubber washer |
| 6. Nut | 18. Bolt | 30. Washer |
| 7. Bolt | 19. Cup | 31. Screw |
| 8. Engine bracket | 20. Bushing | 32. Stud |
| 9. Nut | 21. Spring | 33. Lockwasher |
| 10. Air duct | 22. Cup | 34. Nut |
| 11. Rubber spacer | 23. Nut | 35. Lockwasher |
| 12. Washer | 24. Exhaust grommet | 36. Screw |

ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Remove or disconnect the following, then lift engine from vehicle.

- Pulley guard
- Drive belt
- Muffler
- Choke knob
- Throttle cable
- Fuel lines
- Electrical connectors
- Steering column support at upper column
- Engine mount nuts

DISASSEMBLY & ASSEMBLY


- ① Torque to 3.2 kg-m (23 ft-lbs).
- ② Torque to 3.6 kg-m (26 ft-lbs)
- ③ Torque to 2.2 kg-m (16 ft-lbs)

INSTALLATION

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Torque engine mount nuts to 2.7 kg-m (20 ft-lbs).
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

BOTTOM END



- 1. Crankshaft
- 2. Shim
- 3. Crankcase lower half
- 4. Crankcase upper half
- 5. Bearing
- 6. Retaining washer
- 7. Oil seal
- 8. "O" ring
- 9. Distance ring 6 mm

- 10. Distance ring 9.7 mm
- 11. Needle cage bearing
- 12. Lockwasher
- 13. Magneto ring nut
- 14. Loctite 242
- 15. Woodruff key
- 16. Stud (cylinder)
- 17. Crankcase sealant
- 18. Ignition coil cover

- 19. Screw
- 20. Spring washer
- 21. Lockwasher
- 22. Bolt or stud with nut
- 23. Bolt or stud with nut
- 24. Bolt or stud with nut
- 25. Stud
- 26. Nut

BOTTOM END

CLEANING

Discard all oil seals gaskets and "O" rings. Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY

General

Refer to Technical Data Section for component fitted tolerance and wear limit. If necessary, refer to Drive Pulley Section to remove drive pulley.

①② Crankshaft end-play is adjusted with a shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim, proceed as follows.


NOTE: Crankshaft end-play is adjusted only when crankshaft and / or crankcase is replaced.

Remove magneto side bearing and existing shim(s). Slide the appropriate bearing simulator and retaining washer onto the crankshaft. (See Tools Section).

Position crankshaft assembly into crankcase lower half, making sure that retaining washers are correctly seated into the grooves.

Gently tap crankshaft until P.T.O. side bearing bears against retaining washer.

Any free-play between the bearing simulator and magneto side retaining washer, minus recommended end-play, is the distance to be covered by shim(s). Shims are available in thickness of 0.1 mm (.004"), 0.2 mm (.008"), 0.3 mm (.012"), 0.5 mm (.020"), 1 mm (.039").




③④⑦ Crankcase halves are factory matched and therefore, are not interchangeable or available single halves.

Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant (See Tool Section) as per instruction printed on container.


Position the crankcase halves together and tighten nuts (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque nuts (or bolts) to 2.2 kg-m (15 ft-lbs) following illustrated sequence.



NOTE: Torque the two smaller nuts on magneto side (no. 11 and 12) to 1.2 kg-m (9 ft-lbs).

⑤ To remove bearing from crankshaft use a protective cap and special puller as illustrated. (See Tool Section).




NOTE: Prior to magneto side bearing installation, determine crankshaft end-play and install required shim(s) on crankshaft extension.

At assembly, place bearings into an oil container and heat the oil to 100° C (210° F) for 5 to 10 min. This will expand the bearings and permit them to slide easily on the shaft. Install bearings with groove outward.

⑦ At assembly apply a light coat of lithium grease on seal lips then position oil seal with outer surface flush with crankcase.

⑬ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).




At assembly torque retaining nut to 6.4 kg-m (46 ft-lbs).

⑳ Torque to 2.2 kg-m (16 ft-lbs).

㉑ Torque to 1.2 kg-m (9 ft-lbs).

㉒ Torque to 3.6 kg-m (26 ft-lbs).

TOP END



- 1. Gasket (cylinder/crankcase)
- 2. Cylinder (P.T.O.)
- 3. Cylinder (MAG)
- 4. Cylinder head gasket
- 5. Cylinder head (PTO)
- 6. Cylinder head (MAG)
- 7. Flat washer
- 8. Nut (head)
- 9. Support sleeve
- 10. Distance nut
- 11. Distance nut

- 12. Stud
- 13. Gasket
- 14. Isolating flange
- 15. Rubber ring
- 16. Intake manifold
- 17. Lockwasher
- 18. Nut
- 19. Stud
- 20. Gasket
- 21. Locking tab
- 22. Nut

- 23. Exhaust gasket
- 24. Exhaust manifold
- 25. Lockwasher
- 26. Allen cap screw
- 27. Sealing ring
- 28. Clip
- 29. "L" ring
- 30. Rectangular ring
- 31. Piston
- 32. Gudgeon pin
- 33. Circlip

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

○ **NOTE:** The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.


Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY & ASSEMBLY

○ **NOTE:** Refer to Technical Data for components fitted tolerance and wear limit.

⑤ ⑥ To insure correct cylinder alignment, install and secure intake and exhaust manifolds on cylinder prior to cylinder head tightening. Cross torque cylinder head nuts to 2.1 kg-m (15 ft-lbs).

⑧ ⑩ ⑪ Torque nuts and distance nuts to 2.1 kg-m (15 ft-lbs). Correct position for distance nuts is as following illustration.




⑫ ⑬ ⑭ Torque to 2.1 kg-m (15 ft-lbs).

⑮ ⑯ ⑰ Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlip from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

▼ **CAUTION:** When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters "AUS" (over an arrow on the piston dome) facing in direction of the exhaust part.




○ **NOTE:** Once circlips are installed, turn each circlip so that the circlip break is not directly on piston notch. Remove any burrs on piston caused through circlip installation with very fine emery cloth.



SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

MAGNETO



- | | | |
|--------------------------|-----------------------------|-----------------------|
| 1. Nut | 13. Flat washer | 25. Lubricating wick |
| 2. Lockwasher | 14. Wires grommet | 26. Breaker point set |
| 3. Starting pulley | 15. Coil | 27. Pivot pin |
| 4. Lockwasher | 16. Screw | 28. Breaker point |
| 5. Nut | 17. Nut | 29. Spark plug |
| 6. Stud | 18. Condenser with clamp | 30. Protector |
| 7. Magneto housing | 19. Lighting coil | 31. Protection cap |
| 8. Loctite 242 | 20. Distance sleeve | 32. Rubber ring |
| 9. Screw | 21. Lockwasher | 33. H.T. Cable |
| 10. Magneto ring | 22. Screw | 34. Protection cap |
| 11. Armature plate ass'y | 23. Female connector | 35. Brake light coil |
| 12. Allen capscrew | 24. Ignition generator coil | |

MAGNETO


CLEANING

Clean all metal components in a non-ferrous metal cleaner.


CAUTION: Clean armature ass'y using only a clean cloth.

DISASSEMBLY & ASSEMBLY

- ① Torque to 6.4 kg-m (46 ft-lbs).
- ② Torque to 1.2 kg-m (9 ft-lbs)
- ③ ④ ⑤ ⑥ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).



With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller bolt and at same time, tap bolt head using a hammer to release magneto from its taper. (See Tool Section).



- **NOTE:** Do not separate magneto housing from magneto ring unless necessary. At assembly, apply Loctite "Lock'n Seal" on magneto housing hub (where magneto ring center bore sits) and on retaining screws.

Prior to magneto installation, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242.

Install magneto retaining nut with lockwasher then torque to 6.4 kg-m (46 ft-lbs).

⑦ ⑧ ⑨ Whenever a coil is replaced, the air gap (distance between magnet and coil end) must be adjusted.




Checking the air gap

To check air gap, insert a feeler gauge of 0.25-0.39 mm (.010-.015") between magnet and coil ends. If necessary to adjust, slacken retaining screws and relocate coil.

⑩ Do not remove pivot pin unless replacement is needed. At assembly, apply Loctite "Lock'n Seal" on threads.

⑪ ⑫ When replacing breaker point set, apply a light coat of grease on pivot pin and lubricating wick.

COOLING SYSTEM



- 1. Cylinder cowl (intake)
- 2. Cylinder cowl (exhaust)
- 3. Screw
- 4. Nut
- 5. Spring washer
- 6. Screw
- 7. Screw
- 8. Loctite no. 242
- 9. Fan housing
- 10. Circlip

- 11. Shim
- 12. Bearing
- 13. Fan shaft
- 14. Woodruff key
- 15. Shim
- 16. Pulley half
- 17. Shim
- 18. Belt
- 19. Fan
- 20. Locking washer

- 21. Nut
- 22. Fan cover
- 23. Stud
- 24. Stud
- 25. Junction block bracket
- 26. Lockwasher
- 27. Nut
- 28. Lockwasher
- 29. Screw
- 30. Screw

COOLING SYSTEM

CLEANING

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY

③ ④ ⑦ ⑱ ⑳ ㉑ At assembly, apply Loctite Lock'n seal or equivalent on threads to prevent loosening through vibration.

○ **NOTE:** To correctly remove a "Loctite" locked screw, it is necessary to slightly tap on head of screwdriver to break bond.


㉒ To remove or install bearing, heat bearing housing to 65° C (150° F).

㉓ Fan belt pulleys alignment

For reliable fan belt operation, the two fan belt pulleys must lie within 0.5 mm (.020") of either side of the pulley center line.

Prior to checking alignment, check fan belt free-play.

Position and secure aligning tool (See Tool Section) on magneto housing as illustrated.



Turn knurled knob to center bent feeler rod between pulley halves. Insert a 1 mm (.040") feeler gauge between tool arm and knurled knobs. If gauge fits between both sides of the arms, the setting lies within tolerance.


If clearance is smaller than 1 mm (.040") on one side, shim(s) must be added or removed between bearing and inner pulley half to bring both gaps within tolerance of $1.5 \text{ mm} \pm 0.5$ (.060" \pm .020").

Excess shim(s) should be stored between outer pulley half and fan.

⑱ ㉒ Correct fan belt free-play is 6 mm (1/4"). To adjust, add or remove shim(s) (no. 17) between inner and outer pulley halves. Excess shim(s) must be positioned between outer pulley half and fan.


㉓ ㉔ ㉕ Newer pulley half does not have a shoulder on its inner face so it is installed with a 6 mm (0.236") spacer.

Pulley half



There are two types of fan interchangeable. The first type utilizes two pulley halves and the second type utilizes one pulley half (the second half being part of the fan itself).

To remove or install fan retaining nut, lock fan in position with fan holder wrench. (See Tool Section).




At assembly, torque retaining nut to 6.4 kg-m (46 ft-lbs). Make sure that belt is not squeezed between pulley halves.

245 ENGINE TYPE

BOTTOM END

1. Crankshaft
2. Woodruff key
3. Sper (1 mm / .040")
4. Ball bearing
5. "O" ring
6. Retaining disc
7. Oil seal
8. Lockwasher
9. Magneto retaining nut
10. Shim (as required)
11. Needle bearing
12. Lower crankcase half
13. Upper crankcase half






14. Crankcase stud (8) (57 mm)
15. Crankcase stud (2) (37 mm)
16. Dowel pin
17. Sealing ring
18. Oil inlet nipple
19. Cap
20. Spring clip
21. Valve cover stud (18 mm)
22. Valve cover stud (25 mm)
23. Crankcase support stud (4)
24. Flat washer (10)
25. Lock washer (14)
26. Nut (18)
27. Lock washer (4)
28. Nut (4)
29. Drain screw
30. Cylinder stud (8)
31. Vent elbow
32. Rubber cap

33. Rubber grommet
34. Junction block bracket
35. Lock washer
36. Screw
37. Rotary valve cover
38. Plain washer
39. "O" ring

*Applies to engine up to serial no 2,762,210

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)





MAGNETO

- | | |
|-------------------------|------------------------------|
| 1. Nut (3) | 9. Allen screw (4) |
| 2. Lockwasher (3) | 10. Coil retaining screw (4) |
| 3. Starting pulley | 11. Lockwasher (6) |
| 4. Starting pulley stud | 12. Washer (2) |
| 5. Nut (4) | 13. Allen screw (2) |
| 6. Washer (4) | 14. Armature plate ass'y |
| 7. Magneto housing | 15. Lighting coil |
| 8. Magneto ring | 16. Capacitor charging coil |

REMOVAL

Disconnect or remove the following from vehicle, if applicable:


- Drive belt
- Air silencer
- Unscrew slide chamber cover from carburetors then withdraw throttle slide ass'y from carburetor.
- Rotary valve mechanism vent tube
- Fuel lines, primer lines and impulse line
- Electrical wires
- Muffler
- Rewind starter
- Engine mount nuts and front air deflector
- Drive pulley (as described in Drive Pulley Section).

DISASSEMBLY & ASSEMBLY

NOTE: Refer to Technical Data Section for component fitted tolerance and wear limit.

Bottom End

To remove bearing from crankshaft, use a protective cap and special puller as illustrated.




Prior to installation, place bearings into an oil container and heat the oil to 93° C (200° F) for 5 to 10 min. This will expand bearing and ease installation.

Install bearings with groove outward.

To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated. (See Tool Section).

At assembly, torque magneto retaining nut to 8.0-8.6 kg-m (58-62 ft-lbs).



SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

⑩ Whenever the crankshaft and / or the crankcase is replaced, the crankshaft end-play must be adjusted. To adjust proceed as follows:


Remove magneto side bearing and existing shims. Re-install magneto side bearing without the shims making sure bearing sits flush against crankshaft shoulder.

Position crankshaft ass'y into lower crankcase half. Make sure that retaining discs are correctly seated into their grooves.

Gently tap crankshaft counterweight unto P.T.O. side bearing bears against retaining disc.

Any free-play between the magneto side bearing and retaining disc minus recommended end-play is the distance to be covered by shim(s).


Shims are available in thickness of 0.15 mm (.006"), 0.2 mm (.008"), 0.3 mm (.012") and 1.0 mm (.039").



⑫ ⑬ ⑭ Prior to joining of crankcase halves prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant as per instructions printed on containers.

Position spring washers, lock washers and nuts on crankcase studs then torque nuts to 1.9-2.2 kg-m (14-16 ft-lbs) following illustrated sequence.

○ **NOTE:** There is no spring washer on the last two (2) magneto side studs.



⑮ At assembly, torque to 1.9-2.2 kg-m (14-16 ft-lbs).

⑯ At assembly, torque to 4.0-4.8 kg-m (29-35 ft-lbs).

⑰ Apply Loctite Lock'n Seal on the threads of the two (2) studs, screwed into the crankcase, above the intake ports.

Top End

① ② ③ Place a clean cloth over crankcase to prevent circlips from falling into crankcase then use a pointed tool to remove circlips from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

CAUTION: When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters AUS, over an arrow on the piston dome, facing direction of the exhaust port.



Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.



⑩ ⑪ ⑫ At assembly, torque to 2.2-2.5 kg-m (16-18 ft-lbs) following illustrated sequence.




○ **NOTE:** To prevent leakage, install exhaust manifold prior to cylinder head tightening.

⑩ At assembly, torque to 1.9-2.2 kg-m (14-16 ft-lbs).

Rotary Valve Mechanism


③ ⑦ At assembly, apply Loctite crankcase sealant on rotary valve gear and bearing mating surfaces.



④ To correctly install the rotary valve disc proceed as follows:

- Bring magneto side piston to Top Dead center using a Top Dead Center gauge (See Tools Section).
- Position the rotary valve disc on gear so that both edges fall within range of 6 mm (1/4") on either side of timing marks.


○ **NOTE:** The rotary valve disc is asymmetrical. Therefore, at assembly try positioning each side of disc on gear to determine best installation position.




⑤ to ⑮ To remove rotary valve shaft assembly from crankcase a special puller is needed. (See Tools Section).

REVISION 1

Place special puller over shaft bore and screw puller bolt into rotary valve shaft. While holding puller bolt, turn puller nut clockwise until shaft comes out.



⑮ At assembly, position square edge of locking ring against shaft shoulder as illustrated.




⑮ At assembly, apply a light coat of Loctite crankcase sealant on end cap sealing surface.

Magneto

① At assembly, torque to 1.9 - 2.2 Kg-m (14-16 ft-lbs).

② At assembly, torque to 1.3 kg-m (9 ft-lbs).

⑦ With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper. (See Special Tool).



SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)


④ At assembly, apply Loctite Lock'n Seal on screw threads.

⑤⑥ Whenever a coil is replaced, the air gap (distance between magnet and armature end) must be adjusted. To check air gap, insert a feeler gauge of correct thickness (0.31 mm / .012" - 0.45 mm / .018") between magnet and armature ends.

To adjust, slacken retaining screw and relocate armature.



⑦ To facilitate timing procedure, perform primary adjustment by matching crankcase and armature plate marks.



CLEANING

Discard all oil seals, gaskets and "O" rings. Clean all metal components in a non-ferrous metal cleaner.

▼ **CAUTION:** Clean armature using only a clean cloth.

Scrape off carbon formation from cylinder exhaust ports, cylinder heads and piston domes.

○ **NOTE:** The letter "AUS" over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

Remove old sealant from crankcase mating surfaces.

▼ **CAUTION:** Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

INSTALLATION




To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.


245° 345 ENGINE TYPE

1. Crankshaft
2. Woodruff key
3. Distance sleeve
4. Ball bearing
5. "O" ring
6. Spacer, 1 mm (.039")
7. Oil seal
8. Spacer, 2 mm (.078")
9. Magneto retaining nut
10. Shim, 0.50 mm (.020")
11. Needle bearing
12. Lower crankcase half
13. Upper crankcase half
14. Crankcase stud (8) (57 mm)
15. Crankcase stud (4) (37 mm)
16. Plain washer
17. Lock washer
18. Oil inlet nipple
19. Allen screw (4)



BOTTOM END




20. Rubber cap
21. Rubber grommet
22. Valve cover stud (18 mm)
23. Crankcase support stud (4)
24. Flat washer (10)
25. Lock washer (14)
26. Nut (18)
27. Lock washer (4)
28. Nut (4)
29. Cylinder stud (8)
30. Vent elbow
31. Screw
32. Lock washer
33. Junction block bracket
34. "O" ring
35. Rotary valve cover



* From engine serial no 2,762,211





REMOVAL

Disconnect or remove the following from vehicle:

- Pulley guard and drive belt
- Air silencer
- Throttle cable and housing at handlebar
- Fuel lines, primer lines and impulse line
- Electrical wires
- Muffler
- Rewind starter

Disconnect oil line from bottom of oil reservoir then drain oil from reservoir and crankcase. Disconnect upper oil line from vent elbow.

Remove engine mount nuts then lift engine from vehicle.


- **NOTE:** If necessary, remove drive pulley as detailed in Drive Pulley Section.

DISASSEMBLY & ASSEMBLY

- **NOTE:** Refer to Technical Data Section for component fitted tolerance and wear limit.

Bottom End

④ To remove magneto side bearing from crankshaft, use a protective cap and special puller as illustrated. (See Tools Section).




To remove PTO side bearings from crankshaft proceed as follows:

- Install a 1/2" - 20 X 1" bolt into crankshaft to protect shaft end and threads.
- Install puller on outer bearing as illustrated above then remove bearing from crankshaft.

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

- A puller plate (from puller no 420 977 415) and two (2) longer bolts (part no 222 085 525) are needed to remove the inner bearing. Install puller plate as a spacer between puller ring halves and puller, as illustrated. (See Tools Section).




Prior to installation, place bearings into an oil container and heat the oil to 93° C (200° F) for 5 to 10 min. This will expand bearing and ease installation.


Install all bearings with groove outward.

- ⓐ At assembly apply a light coat of lithium grease on all surfaces.

CAUTION: To insure adequate oil supply to the outer PTO bearing it is imperative that the oil seal outer surface be flush with crankcase as illustrated.




- ⓑ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated. (See Tool Section). At assembly, torque magneto retaining nut to 8.0 - 8.6 kg-m (58 to 62 ft-lbs).



- ⓓ Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant as per instructions printed on container.

Position spring washers, lock washers, nuts or Allen screws on crankcase. Torque nuts to 1.9-2.2 kg-m (14-16 ft-lbs), and Allen screws to 0.8-1.1 kg-m (6-8 ft-lbs) following illustrated sequence.

NOTE: There is no spring washer installed on the last two (2) magneto side studs.



⑭ Apply Loctite Lock'n Seal on threads prior to assembly.

⑮ At assembly, torque to 1.9-2.2 kg-m (14-16 ft-lbs).

⑯ At assembly, torque to 4.0-4.8 kg-m (29-35 ft-lbs).

⑰ Apply Loctite Lock'n Seal on the threads of the two studs, screwed into the crankcase, above the intake ports.


Top End

①②③ Place a clean cloth over crankcase to prevent circlips from falling into crankcase then use a pointed tool to remove circlips from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

CAUTION: When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters AUS, over an arrow on the piston dome, facing direction of the exhaust port.



Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.



⑩⑪⑫⑬ At assembly, torque to 1.5-1.8 kg-m (11-13 ft-lbs) following illustrated sequence.




SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

- **NOTE:** To prevent leakage, install exhaust manifold prior to cylinder head tightening.
- ⑭ At assembly, torque to 1.9-2.2 kg-m (14-16 ft-lbs).

Rotary Valve Mechanism


- ⑬ At assembly, apply crankcase sealant on rotary valve gear and bearing mating surfaces.




- ⑮ To correctly install the rotary valve disc proceed as follows:

- Bring magneto side piston to T.D.C. using a Top Dead Center Gauge (See Tools Section).
- Position the rotary valve disc on gear so that both edges fall within range of 6 mm (1/4") on either side of timing marks.


- **NOTE:** The rotary valve disc is asymmetrical. Therefore, at assembly try positioning each side of disc on gear to determine best installation position.



- ⑯ to ⑰ To remove rotary valve shaft assembly from crankcase a special puller is needed. (See Tools Section). First remove locking ring then position special puller over shaft bore and screw puller bolt into rotary valve shaft. While holding puller bolt, turn puller nut clockwise until shaft comes out.




- ⑱ At assembly, position square edge of locking ring against shaft shoulder as illustrated.



- ⑲ At assembly, apply a light coat of Loctite crankcase sealant on end cap sealing surface.


Magneto

- ① At assembly torque to 1.9-2.2 kg-m (14-16 ft-lbs).
- ② At assembly torque to 1.3 kg-m (9 ft-lbs).
- ③ With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper. (See Special Tools).



⑬ At assembly, apply Loctite Lock'n Seal on screw threads.

⑭ To facilitate timing procedure, perform primary adjustment by matching crankcase and armature plate marks.




⑮ ⑯ ⑰ Whenever a coil is replaced, the air gap (distance between magnet and armature end) must be adjusted.

To check air gap, insert a feeler gauge of correct thickness (0.31 mm / .012" - 0.45 mm / .018") between magnet and armature ends. To adjust, slacken retaining screws and relocate armature.



⑱ ⑲ Use a cable connector and rubber sleeve as illustrated, whenever a coil or cable is replaced.

1. Strip 5 mm of insulation from each end



2. Solder wires into connector with resin core type solder.



3. Slide rubber sleeve over connector then heat with a match to shrink sleeve.

CLEANING

Discard all oil seals, gaskets and "O" rings. Clean all metal components in a non-ferrous metal cleaner.

▼ **CAUTION:** Clean armature using only a clean cloth.

Scrape off carbon formation from cylinder exhaust ports, cylinder heads and piston domes.

○ **NOTE:** The letter "AUS" over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

▼ **CAUTION:** Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


INSTALLATION

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

245, 345 ENGINE TYPE (FROM 1976)

ENGINE SUPPORT & MUFFLER (1976)




- 1. Carriage bolt
- 2. Washer
- 3. Cup washer
- 4. Spacer bushing
- 5. Rubber damper
- 6. Engine support
- 7. Nut
- 8. Spacer bushing
- 9. Washer
- 10. Nut

- 11. Exhaust gasket
- 12. Exhaust manifold
- 13. Lockwasher
- 14. Nut
- 15. Rubber shear mount
- 16. Washer
- 17. Nut
- 18. Washer
- 19. Aluminum ring

- 20. Muffler
- 21. Spring
- 22. Exhaust grommet
- 23. Loctite 242
- 24. Stud
- 25. Bolt
- 26. High tension cable clip
- 27. Clip nut
- 28. Noise damper

ENGINE SUPPORT & MUFFLER (1977)



- 1. Carriage bolt
- 2. Washer
- 3. Cup washer
- 4. Spacer bushing
- 5. Rubber damper
- 6. Engine support
- 7. Nut
- 8. Spacer bushing
- 9. Washer
- 10. Nut
- 11. Exhaust gasket
- 12. Exhaust socket
- 13. Lockwasher

- 14. Bolt
- 15. Tuned pipe (P.T.O.)
- 16. Tuned pipe (mag.)
- 17. Spring
- 18. Support
- 19. Rubber shear mount
- 20. Washer
- 21. Washer
- 22. Nut
- 23. Loctite 242
- 24. Stud
- 25. Coupler
- 26. Tail pipe

- 27. Spring
- 28. Swirl chamber
- 29. Support
- 30. Spring
- 31. Bolt
- 32. Washer
- 33. Nut
- 34. Exhaust grommet
- 35. Bolt
- 36. High tension cable clip
- 37. Clip nut
- 38. Spring
- 39. Noise damper

ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Disconnect or remove the following from vehicle:

- Pulley guard and drive belt.
- Air silencer.
- Throttle cable and housing at handlebar.
- Fuel lines, primer lines and impulse line.
- Electrical wires.
- Muffler.
- Rewind starter.

Disconnect oil line from bottom of oil reservoir then drain oil from reservoir and crankcase. Disconnect upper oil line from vent elbow.

Remove engine mount nuts then lift engine from vehicle.

DISASSEMBLY & ASSEMBLY

- Ⓢ Torque to 3.6 kg-m (26 ft-lbs).
- Ⓣ Torque to 2.1 kg-m (15 ft-lbs).
- Ⓓ At assembly on crankcase apply Loctite Lock'n Seal 242 on threads.



INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

BOTTOM END

1. Crankshaft
2. Woodruff key
3. Loctite 242
4. Needle cage bearing
5. "Sealing ring"
6. Distance ring 1 mm
7. Shim 0.5 mm
8. Bearing
9. Oil seal
10. Distance sleeve 9.7 mm
12. Distance ring 2 mm
13. Oil hose connector
14. Magneto ring nut
15. Crankcase upper half
16. Crankcase lower half
17. Crankcase sealant



18. Stud (support)
19. Lockwasher
20. Nut
21. Spring washer
22. Lockwasher
23. Bolt or stud with nut
24. Allen cap screw
25. Washer
26. Cylinder stud
27. Vent elbow
28. Plug
29. Circlip
30. End cap
31. Junction block bracket
32. Screw
33. Wire grommet

BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.


Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY

⑧ To remove magneto side bearing from crankshaft, use a protective cap and special puller as illustrated. (See Tools Section).




Prior to installation, place bearings into an oil container and heat the oil to 100° C (210° F) for 10 min. This will expand bearing and ease installation.

Install bearings with groove outward.

⑨ At assembly apply a light coat of lithium grease on seal lips. To insure adequate oil supply to the bearings it is imperative that the oil seals outer surface be flush with crankcase.

⑩ Apply Loctite Lock'n Seal 242 on threads prior to assembly.

⑪ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated. (See Tool Section).



⑮ ⑯ ⑰ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves.



Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant (See Tool Section) as per instructions printed on container.

CAUTION: Before joining of crankcase halves be sure that crankshaft rotary valve gear is well engage with rotary valve shaft gear.

Position the crankcase halves together and tighten nut (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque nuts (or bolts) to 2.2 kg-m (16 ft-lbs) and Allen cap screws to 1 kg-m (7 ft-lbs) following illustrated sequence.

○ **NOTE:** There is no spring washer installed on the last two (2) magneto side studs (or bolts).



⑱ At assembly on crankcase, apply Loctite Lock'n Seal 242 on threads.

⑲ Torque to 3.6 kg-m (26 ft-lbs).

⑳ Torque to 2.2 kg-m (16 ft-lbs).


㉑ Torque to 1 kg-m (7 ft-lbs).

㉒ Apply Loctite Lock'n Seal on the threads of the two studs, screwed into the crankcase, above the intake ports.

㉓ At assembly, apply a light coat of crankcase sealant on end cap sealing surface.

㉔ Apply Loctite Lock'n Seal 242 on threads.

ROTARY VALVE MECHANISM



1. Bolt (or nut with stud)
2. Lockwasher
3. Rotary valve cover
4. "O" ring
5. Allen cap screw
6. Washer
7. Rotary valve gear
8. Rotary valve disc
9. Locking ring
10. Oil seal
11. Bearing
12. Woodruff key

13. Rotary valve shaft
14. Distance sleeve
15. "O" ring
16. Pinion
17. Spring sleeve
18. Spring
19. Shim 1 mm
20. Locking ring
21. Bearing
22. Locking ring
23. End cap

24. Oil tank cap
25. Gasket
26. Clamp
27. Oil tank
28. Support
29. Bolt
30. Nut
31. Grommet
32. Male connector
33. Clamp (hose)
34. Oil line

ROTARY VALVE MECHANISM

CLEANING


Discard all oil seals and "O" rings.

Remove crankcase sealant traces on rotary valve gear, adjacent bearing and on end cap sealing surface.

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY


⑦ ⑪ At assembly, apply crankcase sealant on rotary valve gear and bearing mating surfaces.




⑧ To correctly install the rotary valve disc proceed as follows:

- Turning crankshaft counter-clockwise, (drive pulley side) bring magneto side piston to Top Dead Center using a T.D.C. gauge.
- Position the rotary valve disc on gear to have edges as close as possible to the marks.


○ **NOTE:** The rotary valve disc is asymmetrical, therefore, at assembly try positioning each side of disc on gear to determine best installation position.



⑨ to ⑳ To remove rotary valve shaft assembly from crankcase a special puller is needed. (See Tools Section). First remove locking ring then position special puller over shaft bore and screw puller bolt into rotary valve shaft. While holding puller bolt, turn puller nut clockwise until shaft comes out.




㉑ At assembly, position square edge of locking ring against shaft shoulder as illustrated.



㉒ At assembly, apply a light coat of Loctite crankcase sealant on end cap sealing surface.

TOP END



- 1. Piston
- 2. Gudgeon pin
- 3. Circlip
- 4. Ring
- 5. Gasket (cylinder / crankcase)
- 6. Cylinder
- 7. Gasket (Cylinder head)
- 8. Cylinder head
- 9. Expansion sleeve

- 10. Nut (1977)
- 11. Nut (1976)
- 12. Washer
- 13. Exhaust gasket
- 14. Lockwasher
- 15. Nut
- 16. Cap screw
- 17. Exhaust socket
- 18. Exhaust manifold

TOP END

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

NOTE: The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY & ASSEMBLY


NOTE: Refer to Technical Data Section for component fitted tolerance and wear limit.

①②③ Place a clean cloth over crankcase to prevent circlips from falling into crankcase then use a pointed tool to remove circlips from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

CAUTION: When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters AUS (over an arrow on the piston dome) facing direction of the exhaust port.




Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.




NOTE: To prevent leakage, install exhaust manifold prior to cylinder head tightening.

④⑤⑥ Torque cylinder head nuts to 1.6 kg-m (12 ft-lbs) following illustrated sequence.



⑦⑧ Torque to 2.2 kg-m (16 ft-lbs).

MAGNETO



1. Armature plate
2. Magneto ring
3. Electronic box
4. Junction block
5. Screw
6. Lockwasher
7. Nut
8. Magneto housing
9. Starting pulley
10. Lockwasher
11. Screw (or nut with stud)
12. Wire grommet
13. Magneto nut
14. Protection cap
15. Loctite Lock'n Seal 242

16. H.T. wire
17. Spark plug protector
18. Spark plug
19. Flat washer
20. Lockwasher
21. Screw
22. Lighting coil 110 W
23. Screw
24. Charging coil
25. Lighting coil 30W
26. Lockwasher
27. Screw
28. Wire function terminal
29. Protection hose

MAGNETO


CLEANING

Clean all metal components in a non-ferrous metal cleaner.

▼ **CAUTION:** Clean armature and magneto using only a clean cloth.


DISASSEMBLY & ASSEMBLY

① To facilitate timing procedure, perform primary adjustment by matching crankcase and armature plate marks.




② ③ Apply Loctite Lock'n Seal 242 on threads then torque to 1.2 kg-m (9 ft-lbs).

④ ⑤ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated (See Tool Section).



With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



Prior to assembly, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242 on taper.

Install magneto retaining nut (with Loctite Lock'n Seal 242 on threads) and torque to 7.5 kg-m (54 ft-lbs).

⑥ Torque to 2.2 kg-m (16 ft-lbs).



⑦ ⑧ ⑨ Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.

To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012"-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and relocate coil.




Use a cable connector and rubber sleeve as illustrated, whenever a coil or cable is replaced.

1. Strip 5 mm of insulation from each end




2. Solder wires into connector with resin core type solder.



3. Slide rubber sleeve over connector then heat with a match to shrink sleeve.

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)


305, 338, 343, 401 ENGINE TYPE



BOTTOM END

- | | | | |
|-----------------------|---------------------------|--------------------------|--------------------------------|
| 1. Crankshaft | 10. Washer | 19. Upper crankcase half | 28. Cylinder head stud (8) |
| 2. "O" ring (3) | 11. Spring | 20. Crankcase stud (7) | 29. Crankcase/support stud (4) |
| 3. Woodruff Key | 12. Breaker point cam | 21. Crankcase stud | 30. Lock washer (4) |
| 4. Needle bearing | 13. Tab washer | 22. Crankcase stud (2) | 31. Nut (4) |
| 5. Ball bearing | 14. Magneto retaining nut | 23. Dowel pin | 32. Dowel tube |
| 6. "O" ring | 15. Distance sleeve | 24. Stud (4) | 33. Crankcase/starter stud |
| 7. Retaining disc | 16. Starter gear | 25. Lock washer (4) | 34. Nut (2) |
| 8. Oil seal | 17. Washer (3 mm/0.118") | 26. Nut (17) | 35. Starter bracket |
| 9. Shim (as required) | 18. Lower crankcase half | 27. Lock washer (13) | 36. Washer (2) |


SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)



TOP END


- | | | |
|---------------------------------|--|---------------------------------------|
| 1. Piston (P.T.O. side) | 12. Cylinder head (Mag. side) | 23. Intake manifold gasket (Mag side) |
| 2. Piston (Mag. side) | 13. Plain washer (7) | 24. Intake manifold |
| 3. Gudgeon pin | 14. Nut (10) | 25. Ring gasket |
| 4. Circlip | 15. Distance nut (long) | 26. Intake cover |
| 5. Rectangular ring | 16. Distance nut (short) | 27. Carburetor stud |
| 6. "L" or rectangular ring | 17. Support sleeve | 28. Plain washer |
| 7. Crankcase/cylinder gasket | 18. Exhaust socket (P.T.O. side-short) | 29. Lock washer |
| 8. Cylinder (P.T.O. side) | 19. Exhaust socket (Mag. side-long) | 30. Flange gasket |
| 9. Cylinder (Mag. side) | 20. Aluminium ring | 31. Isolating flange |
| 10. Cylinder head gasket | 21. Intake manifold stud | 32. Tab washer |
| 11. Cylinder head (P.T.O. side) | 22. Intake manifold gasket (P.T.O. side) | 33. Exhaust manifold |

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)



MAGNETO

- | | | | | |
|----------------------|------------------------------|---------------------------------|---------------------------------------|--------------------|
| 1. Nut (3) | 8. Bearing screw | 15. Ignition generator coil | 20. Breaker point (unit construction) | 26. Lock washer |
| 2. Lock washer (3) | 9. Magneto ring | 16. Capacitor (2) | 21. Pivot pin | 27. Plain washer |
| 3. Fan belt pulley | 10. Lock washer (4) | 17. Armature plate | 22. Bolt | 28. Washer |
| 4. Stud (3) | 11. Allen screw (4) | 18. Lighting coil (75W or 100W) | 23. Lock washer | 29. Retaining clip |
| 5. Magneto housing | 12. Lock washer (4) | 19. Breaker point set | 24. Nut | 30. Washer (2) |
| 6. Spring | 13. Coil retaining screw (4) | | 25. Screw | 31. Lock washer |
| 7. Centrifugal lever | 14. Brake light coil (23W) | | | 32. Allen screw |



COOLING SYSTEM

- | |
|----------------------------|
| 1. Rear cylinder cowl |
| 2. Front cylinder cowl |
| 3. Allen screw (2) |
| 4. Nut (2) |
| 5. Bolt |
| 6. Lock washer |
| 7. Cowl cover |
| 8. Fan |
| 9. Woodruff key |
| 10. Ball bearing |
| 11. Spacer (2) |
| 12. Locking ring |
| 13. Fan housing |
| 14. Screw |
| 15. Lock washer |
| 16. Junction block bracket |
| 17. Spring washer (4) |
| 18. Flat head screw (3) |
| 19. Screw |
| 20. Shim (5) |
| 21. Pulley half |
| 22. Lock washer |
| 23. Nut |
| 24. Fan belt |
| 25. Fan cover |
| 26. Spacer |

SECTION 04 SUB-SECTION 02 (TWO CYLINDER ENGINE)

REMOVAL

Remove or disconnect the following then lift engine out of vehicle.

Front-mounted engine

- Drive belt
- Muffler
- Rewind starter
- Air silencer
- Choke cable
- Throttle cable
- Fuel lines at carburetor

Note: Secure fuel line to steering support so that the opened ends are higher than the fuel tank.

- Electrical connector

Caution: On electric start model, disconnect negative cable (ground) from battery post before disconnecting other wires.

- Engine mount nuts.

Center mounted engine

- Drive belt
- Muffler
- Choke knob
- Throttle cable
- Fuel lines
- Electrical connector

Caution: On electric start model, disconnect negative cable (ground) from battery post before disconnecting other wires.

- Separate steering column support at upper column
- Engine mount nuts.

DISASSEMBLY & ASSEMBLY

If necessary, remove drive pulley as described in drive pulley section.

Note: Refer to Technical Data Section for component fitted tolerance and wear limit.

Bottom End

② The center "O" ring/ball bearing combination may vary depending on production date of engine.

For correct assembly, refer to the following chart for identification.

Ball bearing Groove Depth	"O" Ring		
	Thickness	Outside Diameter	Part Number
.059" to .063"	.078"	2 5/16"	420 830 350
.047" to .051"	.070"	2 1/8"	420 830 355

⑤ To remove bearing from crankshaft, use a protective cap and special puller, as illustrated. (See Tool Section).

Prior to installation, place bearings into an oil container and heat the oil to 200 ° F, for 5 to 10 min. This will expand

bearing and ease installation.

Install bearings with groove outward.


⑥ Crankshaft end-play is adjusted with shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim(s), proceed as follows.

Remove magneto side bearing and existing shim(s). Slide the appropriate crankshaft ring and the retaining disc on the crankshaft. (See Tool Section).

Position crankshaft assembly into crankcase lower half. Make sure that retaining washers are correctly seated in the grooves.


Gently tap crankshaft counterweight until P.T.O. side bearing bears against retaining disc.

Any free-play between the crankshaft ring and magneto side retaining disc minus recommended end-play is the distance to be covered by shim(s). Shims are available in thickness of 0.1 mm/.004", .02 mm/.008", 0.3 mm/.012", 0.5 mm/.020", 1 mm/.039".



Note: Crankshaft end-play requires adjustment only when crankshaft and/or crankcase is replaced.


⑭ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).



SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

At assembly torque retaining nut to 50-58 ft-lbs.


⑮ To remove starter gear from crankshaft it may be necessary to use a special puller as illustrated. (See Special Tool).



At assembly, apply a light coat of anti-seize compound on crankshaft extension nearest starter gear.

⑯ Prior to joining of crankcase halves, apply a light coat of "Loctite" crankcase sealant to the mating surfaces of the bottom half.

Position spring washers and nuts on crankcase studs then torque nuts to 14-16 ft-lbs., following illustrated sequence.



⑰ At assembly, torque to 14-16 ft-lbs.


⑱ At assembly, torque crankcase/support nut to 23-29 ft-lbs.

Top End


① ② ③ ④ Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.

Caution: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters "AUS", over an arrow on the piston dome, facing in direction of the exhaust port.



Also make sure that the piston window is aligned with the crankcase transfer passage when the gudgeon pin orifice is in-line with the connecting rod bore.




Note: Once the circlips are installed turn each circlip so the circlip is not directly on piston notch. Remove any burrs on piston caused through circlip installation with very fine emery cloth.




SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

- ⑧ ⑨ ⑩ ⑪ ⑫ When installing cylinder and or cylinder head, the cylinder aligning tool must be used to ensure sealing of intake manifold and cylinders. (See Tool Section). Install exhaust manifold on exhaust socket then install aligning bar and torque distance nut to 14-16 ft-lbs. Cross torque cylinder head nut to 14-16 ft-lbs. Remove aligning bar and exhaust manifold.
Note: Torque each cylinder head individually.
 ⑬ At assembly, torque to 14-16 ft-lbs.




Magneto


- ⑬ With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller nut and at same time, tap on nut head using a hammer to release magneto from its taper.



At assembly, position magneto on crankshaft with the keyway and the cam notch position as illustrated.



- ⑬ ⑭ ⑮ At assembly, apply a small amount of low temperature grease into spring seating.
 ⑯ At assembly, apply Loctite "Lock'n Seal" on retaining screw threads.
 ⑰ ⑱ Whenever a coil is replaced, the air gap (distance between magnet and armature end) must be adjusted. To check air gap, insert a feeler gauge of correct thickness (0.31 mm/.012"-0.45 mm/.018") between magnet and armature ends.
 If necessary to adjust, slacken retaining screw and relocate armature.



⑮ To replace a capacitor, it is first necessary to unsolder the two (2) black leads using a soldering iron. The capacitor can then be driven out of the armature plate using a suitable punch and hammer. To reinstall, inverse procedure.

⑯ ⑰ When replacing breaker point set, apply a light coat of grease on pivot pin and rubbing block.

Do not remove pivot pin unless replacement is needed. At assembly, apply Loctite "Lock'n Seal" on threads.

⑱ When replacing unit construction type breaker point, apply a small amount of grease on rubbing block.


Cooling System

③ ⑱ ⑲ At assembly, apply a light coat of Loctite "Lock'n Seal" on threads. It should be noted that to correctly remove a Loctite locked screw, it is first necessary to slightly tap on head of screw to break Loctite bond.

The screw can then be removed. This will eliminate the possibility of screw breakage.

⑳ It is first necessary to heat bearing housing to 140° -160° F. To remove or install bearing.

㉑ ㉒ ㉓ ㉔ Lock fan pulley with special holder wrench to remove or install pulley retaining nut. (See Tool Section).



Shim(s) located between pulley halves are used to adjust fan belt free-play. Correct free-play is 1/4". If necessary to adjust, install or remove shim(s) between pulley halves. Install excess shim(s) between outer pulley half and washer.

CLEANING

Discard all oil seals, gaskets and "O" rings.

Clean all metal components in a non-ferrous metal cleaner.

Caution: Clean armature using only a clean cloth.

Scrape off carbon formation from cylinder exhaust ports, cylinder exhaust ports, cylinder heads and piston domes.

Note: The letter "AUS" over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

Remove old sealant from mating surfaces with Bombardier "Sealant stripper".


Caution: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

INSTALLATION


To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing.
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

305, 343 ENGINE TYPES (FROM 1976)



ENGINE SUPPORT & MUFFLER (T'NT & EVEREST)



ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Remove or disconnect the following (if applicable) then lift engine out of vehicle.

- Pulley guard & drive belt
- Muffler & air duct
- Cab retaining cable
- Air intake silencer
- Fuel lines at carburetor, impulse line
- Throttle cable
- Electrical junction block.

▼ CAUTION: On electric start model, disconnect negative cable (ground) from battery before disconnecting other wires.

- Rewind starter
- Engine mount nuts

DISASSEMBLY & ASSEMBLY

⑩ At assembly on crankcase, apply Loctite Lock'n Seal 242 on threads.


⑪ Torque to 3.6 kg-m (26 ft-lbs).

INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

BOTTOM END



- 1. Crankshaft
- 2. Sealing ring
- 3. Distance ring 1 mm (1977)
- 4. Shim
- 5. Bearing (MAG)
- 6. "O" ring
- 7. Retainer washer
- 8. Oil seal (MAG)
- 9. Washer
- 10. Spring
- 11. Breaker point cam

- 12. Loctite Lock'n Seal 242
- 13. Magneto nut
- 14. Woodruff key
- 15. Distance ring 2 mm
- 16. Bearing (P.T.O.)
- 17. "O" ring
- 18. Distance ring 3 mm
- 19. Oil seal (P.T.O.)
- 20. Needle cage bearing
- 21. Crankcase upper half
- 22. Crankcase lower half

- 23. Crankcase sealant
- 24. Bolt or nut with stud
- 25. Lockwasher
- 26. Stud
- 27. Lockwasher
- 28. Nut
- 29. Stud
- 30. Washer
- 31. Nut
- 32. Loctite Lock'n Seal 242

BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.

Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY

General

Refer to Technical Data Section for component fitted tolerance and wear limit.

①④ Crankshaft end-play is adjusted with shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim(s), proceed as follows.


○ **NOTE:** Crankshaft end-play requires adjustment only when crankshaft and / or crankcase is replaced.

Remove magneto side bearings and existing shim(s). Slide the appropriate bearing simulator and the retaining washers on the crankshaft. (See Tool Section).


Position crankshaft assembly into crankcase lower half. Make sure that retaining washers are correctly seated in the grooves.

Gently tap crankshaft counterweight until P.T.O. side inner bearing bears against retaining washer.

Any free-play between the bearing simulator and magneto side retaining washer, minus recommended end-play, is the distance to be covered by shim(s). Shims are available in the thickness of 0.10 mm (.004"), 0.15 mm (.006"), 0.20 mm (.008") and 0.30 mm (.012").



⑤⑩ To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tool Section).




Prior to installation, place bearings into an oil container and heat the oil to 100° C (210° F) for 10 min. This will expand bearings and ease installation.

Install bearings with groove outward.

○ **NOTE:** Prior to magneto side bearing installation, determine crankshaft end-play and install required shim(s) on crankshaft extension.

⑥⑭ At assembly apply a light coat of lithium grease on seal lip. Seal outer surface should be flush with crankcase.

⑮ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).



At assembly apply Loctite Lock'n Seal 242 or equivalent on threads then torque to 8.3 kg-m (60 ft-lbs).

⑯ A 4 mm (0.160") distance ring is used on P.T.O. side with crankcase upper half having the oil passage between the two bearings. When the oil passage is between oil seal and outer bearing, a 3 mm (0.120") must be used.


SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

⑳ ㉓ ㉔ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves.

Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant (See Tool Section) as per instructions printed on container.

Position the crankcase halves together and tighten nuts (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque bolts or nuts to 2.1 kg-m (15 ft-lbs) following illustrated sequence.




㉕ Torque to 2.1 kg-m (15 ft-lbs).

㉖ At assembly on crankcase apply Loctite Lock'n Seal 242 on threads.

㉗ Torque to 3.6 kg-m (28 ft-lbs).

㉘ Torque to 2.1 kg-m (15 ft-lbs).



- 1. Gasket (cylinder / crankcase)
- 2. Cylinder (P.T.O.)
- 3. Cylinder (MAG)
- 4. Cylinder head gasket
- 5. Cylinder head (P.T.O.)
- 6. Cylinder head (MAG)
- 7. Flat washer
- 8. Support sleeve
- 9. Nut
- 10. Distance nut (short)
- 11. Distance nut (long)

- 12. Stud
- 13. Gasket (intake P.T.O.)
- 14. Gasket (intake MAG)
- 15. Intake manifold
- 16. Sealing ring
- 17. Intake cover
- 18. Intake cover (new type)
- 19. Flat washer
- 20. Lockwasher
- 21. Nut
- 22. Gasket

- 23. Isolating flange
- 24. Screw
- 25. Screw
- 26. Exhaust socket (P.T.O.)
- 27. Exhaust socket (MAG)
- 28. Sealing ring
- 29. Exhaust manifold
- 30. Piston
- 31. Gudgeon pin
- 32. Circlip
- 33. Ring

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

NOTE: The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.


Clean the piston mag grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY & ASSEMBLY

NOTE: Refer to technical data for component fitted tolerance and wear limit.


When installing cylinder and / or cylinder head, the cylinder aligning tool must be used to ensure sealing of intake manifold and cylinders. (See Tool Section).

With exhaust manifold and aligning tool installed, you can then cross torque cylinder head nuts to 2.1 kg-m (15 ft-lbs).



Position nuts and distance nuts as per illustration then cross torque to 2.1 kg-m (15 ft-lbs).

NOTE: Torque each cylinder head individually (exhaust manifold & aligning tool installed).




Apply Loctite Lock'n Seal 242 on threads then torque to 2.1 kg-m (15 ft-lbs).


Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.

CAUTION: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters "AUS" (over an arrow on the piston dome) facing in direction of the exhaust port.




Also make sure that the piston window is aligned with the crankcase transfer passage when the gudgeon pin orifice is in line with the connecting rod bore.



NOTE: Once the circlips are installed turn each circlip so it is not directly on piston notch. Remove any burrs on piston caused through circlip installation with very fine emery cloth.



MAGNETO



- 1. Magneto nut
- 2. Loctite Lock'n Seal 242
- 3. Screw
- 4. Lockwasher
- 5. Starting pulley
- 6. Magneto housing
- 7. Magneto ring
- 8. Screw
- 9. Lockwasher
- 10. Screw
- 11. Centrifugal lever

- 12. Spring
- 13. Armature plate
- 14. Screw
- 15. Lockwasher
- 16. Flat washer
- 17. Capacitor
- 18. Lighting coil
- 19. Ignition generator coil
- 20. Washer
- 21. Screw
- 22. Armature plate ass'y

- 23. Wire grommet
- 24. H. T. coil
- 25. Ground wire
- 26. Screw
- 27. Lockwasher
- 28. Protector
- 29. H. T. cable
- 30. Spark plug
- 31. Spark plug protector
- 32. Breaker point set
- 33. Lubricating wick

MAGNETO


CLEANING

Clean all metal components in a non-ferrous metal cleaner.

CAUTION: Clean armature ass'y and magneto using only a clean cloth.


DISASSEMBLY & ASSEMBLY

①④⑦ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See tool Section).




With magneto retaining nut removed and hold-on support in place, install special puller onto support.

Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242 or equivalent, position magneto on crankshaft with the keyway and the cam notch positioned as illustrated.



Install magneto retaining nut (with Loctite Lock'n Seal 242) on threads and torque to 8.3 kg-m (60 ft-lbs).

③ Torque to 2.2 kg-m (16 ft-lbs).

⑧ Apply Loctite Lock'n Seal 242 on threads.

⑫ At assembly apply a small amount of low temperature grease into spring seating.

⑰ To replace a capacitor, it is first necessary to unsolder the two (2) black leads using a soldering iron. The capacitor can then be driven out of the armature plate using a suitable drift. To reinstall, inverse procedure.

⑱ Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.

To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012"-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and re-locate coil.




⑳ Apply Loctite Lock'n Seal 242 on threads.




㉑ Do not remove pivot pin unless replacement is needed, if removed, reinstall with Loctite Lock'n Seal 242 on threads.

Old type breaker point set can be replaced by new type if pivot pin is removed. When installing new breaker point type it is advisable to fill the pivot pin cavity of the armature plate with Loctite 277 (thick red solution).

㉒ When replacing breaker point set, apply a light coat of grease on lubricating wick.



INTERNAL FAN TYPE



- 1. Fan housing
- 2. Circlip
- 3. Shim(s)
- 4. Bearing
- 5. Fan shaft
- 6. Woodruff key
- 7. Pulley half
- 8. Shim
- 9. Shim
- 10. Fan
- 11. Washer
- 12. Nut
- 13. Belt

- 14. Fan cowl (intake)
- 15. Fan cowl (exhaust)
- 16. Spring washer
- 17. Screw
- 18. Screw
- 19. Nut
- 20. Fan cover
- 21. Junction block bracket
- 22. Lockwasher
- 23. Screw
- 24. Screw
- 25. Lockwasher
- 26. Rubber washer

COOLING SYSTEM

CLEANING

Clean all components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY

- ④ Heat bearing housing to 70° C (160° F) prior to bearing removal or installation.
- ⑦ Newer pulley half does not have a shoulder on its inner face so it is installed with a 6 mm (0.230") spacer.

Pulley half




NEW TYPE

OLD TYPE

⑧ Shim(s) located between pulley halves are used to adjust fan belt free-play. Correct free-play is 6 mm (¼"). If necessary to adjust install or remove shim(s) between pulley halves. Install excess shim(s) between outer pulley half (or fan) and washer of retaining nut.

⑨ There are three types of fan, the first is an internal type, the second and third are external and interchangeable. The second type utilises two pulley halves and the third type utilises one pulley half (the second half being part of the fan itself).

⑩ Lock fan (or pulley half) with special holder wrench to remove or install pulley retaining nut. (See Tool Section).




At assembly torque to 6.4 kg-m (46 ft-lbs).

⑰ ⑱ ⑲ Apply Loctite Lock'n Seal 242 on threads.

○ NOTE: It should be noted that to correctly remove a Loctite locked screw, it is first necessary to tap on head of screw to break Loctite bond. This will eliminate the possibility of screw breakage.

⑳ Apply Loctite Lock'n Seal 242 on threads then torque to 1 kg-m (7 ft-lbs).


346, 396, 436 ENGINE TYPE



1. Crankshaft
2. "O" ring
3. Woodruff key
4. Needle bearing
5. Ball bearing
6. Lock washer
7. Magneto retaining ring nut
8. Oil seal
9. Shim (1 mm)
10. Stud (6)
11. Stud (8)
12. Dowel pin
13. Crankcase lower half
14. Stud (4)
15. Lock washer (4)
16. Nut (4), M-12
17. Spring washer (12)
18. Lock washer (14)
19. Nut (14)
20. Stud (8)
21. Rubber plug
22. Crankcase upper half

1. Piston
2. Gudgeon pin
3. Circlip
4. Piston ring
5. Cylinder/crankcase gasket
6. Cylinder (P.T.O. side)
7. Cylinder (Mag. side)
8. Cylinder head gasket
9. Cylinder head stud (4 or 8)
10. Cylinder head
11. Plain washer (12 or 16)
12. Cylinder head nut (12 or 16)
13. Exhaust manifold stud (4)
14. Exhaust manifold gasket
15. Lock washer (4)
16. Nut (8)
17. Exhaust manifold
18. Cross flange stud (4)
19. Cross flange gasket (2)
20. Cross flange (2)
21. Lock washer (4)
22. Nut (4)
23. Carburetor stud (4)
24. Flange gasket (4)
25. Isolating flange (2)
26. Lock tab (4)

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)



REMOVAL

Remove or disconnect the following, then lift engine out of vehicle.

- Drive belt
- Muffler
- Rewind starter
- Air silencer
- Choke cable
- Throttle cable
- Fuel lines at carburetor
- Engine mount nuts and washers

Note: Secure fuel line to steering support so that the open ends are located higher than the fuel tank.

DISASSEMBLY & ASSEMBLY

If necessary, removed drive pulley as described in drive pulley section.


Note: Refer to Technical Data section for component fitted tolerance and wear limit.

Bottom End

②⑤ The "O" ring/ball combination between early and later production engines vary. For correct assembly, refer to the following chart identification.

Ball bearing Groove Depth	"O" Ring	
	Outside Diameter	Part no.
.059" to .063"	2 5/16"	420 830 350
.047" to .051"	2 1/8"	420 830 355


⑤⑧ To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tool Section).



Prior to installation, place bearings into an oil container and heat the oil to 200° F. for 5 to 10 min. (This will expand bearings and ease installation).

Install magneto side bearing with groove outward. Install the P.T.O. side bearings with groove outward. Two (2) .040" shims should be located between each bearing.

⑦ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated. (See Tool Section).




SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

At assembly torque magneto retaining nut to 58-62 ft/lbs.

⑬⑰⑱⑲⑳ Prior to joining of crankcase halves, apply a light coat of "Loctite" crankcase sealant to the mating surfaces of the bottom half. Position spring washers, lock washers and nuts on crankcase studs then torque nut to 14-16 ft/lbs. following illustrated sequence.

Note: There is no spring washer on the last two (2) magneto side studs.



⑯ Torque crankcase/support nut to 30-35 ft/lbs.


Top End

①②③ Place a clean cloth over crankcase to prevent circlip from falling into crankcase then use a pointed tool to remove circlips from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

Caution: When tapping gudgeon pins in or out of pistons, hold firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters AUS, over an arrow on the piston dome, facing direction of the exhaust port.



Note: Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.



⑩⑪⑫⑰ Torque cylinder head nut to 14-16 ft/lbs. following illustrated sequence.



Note: To prevent possible distortion, install exhaust manifold prior to cylinder head tightening.

⑯⑳ At assembly torque to 14-16 ft/lbs.


Magneto

① At assembly torque to 14-16 ft/lbs.


② At assembly torque to 9 ft/lbs.

③ With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller nut and at same time, tap on nut head using a hammer to release magneto from its taper. (See Special Tool).

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)



⑪ At assembly, make sure the three (3) bottom wires are positioned as illustrated to prevent squeezing. (A dab of silicon seal or a few drops of candle wax will hold them in place).



CLEANING

Discard all oil seals, gaskets and "O" rings.

Clean all metal components using a non-ferrous metal cleaner.

Caution: Clean armature using only a clean cloth.

Scrape off any carbon formation from cylinder exhaust ports, cylinder heads and piston domes.

Note: The letter *AUS* over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or using a piece of broken ring.

Remove old sealant from mating surfaces of crankcase with a scraper blade.

Caution: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


INSTALLATION

To install engine on vehicle inverse removal procedure, however, special attention should be paid to the following:

- Torque engine mount nuts to 25 ft/lbs.
- After throttle cable installation, check maximum throttle opening adjustment.
- Check pulley alignment.
- Check ignition timing.

346, 436 ENGINE TYPE (FROM 1977)

ENGINE SUPPORT & MUFFLER



1. Rubber mount
2. Nut
3. Engine support
4. Flat washer
5. Reinforcement plate
6. Lockwasher
7. Nut
8. Exhaust
9. Exhaust manifold
10. Lockwasher
11. Bolt
12. Aluminum ring
13. Muffler
14. Spring
15. Rubber shear mount
16. Washer
17. Washer
18. Nut
19. Exhaust grommet
20. Stud

REMOVAL FROM VEHICLE

Remove or disconnect the following (if applicable) then lift engine out of vehicle.

- Pulley guard & drive belt.
- Muffler.
- Cab retaining cable.
- Air intake silencer.
- Fuel lines at carburetor, impulse line.
- Throttle cable.
- Electrical junction block.
- Rewind starter.
- Engine mount nuts.


DISASSEMBLY & ASSEMBLY

- ⑦ Torque to 4.4 kg-m (32 ft-lbs).
- ⑩ Torque to 2.1 kg-m (15 ft-lbs).
- ⑳ At assembly on crankcase, apply Loctite Lock'n Seal 242 or equivalent on threads.

INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing prior to installation in vehicle.
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.



BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.

Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY


①②③ Crankcase halves are factory matched and therefore, are not interchangeable as single halves.

Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant (See tool Section) as per instructions printed on container.

Position the crankcase halves together and tighten nuts (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Position spring washers, lock washers and nuts or bolts then torque to 2.1 kg-m (15 ft-lbs) following illustrated sequence.

○ **NOTE:** There is no spring washer on the last two (2) magneto side studs (no. 1344).



④ Torque to 2.1 kg-m (15 ft-lbs).

⑤ At assembly on crankcase apply Loctite Lock'n Seal 242 or equivalent on threads.


⑥ Torque to 4.4 kg-m (32 ft-lbs).

⑦ Apply Loctite Lock'n Seal 242 or equivalent on threads.

⑧ Apply Loctite Lock'n Seal on threads then torque to 8.3 kg-m (60 ft-lbs).

⑨ At assembly apply a light coat of lithium grease on seal lips then position oil seal with outer surface flush with crankcase.

⑩⑪⑫⑬ To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tool Section).




Prior to installation, place bearings into an oil container and heat the oil to 100° C (210° F) for 10 min. This will expand bearings and ease installation.

Before installation of bearing, slide the appropriate distance ring on crankshaft then install bearings with groove outward.

On P.T.O. side position two (2) 1 mm (.040") thick shims between the two bearings.

TOP END



- 1. Gasket (crankcase / cylinder)
- 2. Cylinder (P.T.O.)
- 3. Cylinder (mag.)
- 4. Cylinder head gasket
- 5. Stud
- 6. Cylinder head
- 7. Flat washer
- 8. Nut
- 9. Gasket (intake / cylinder)
- 10. Intake cover
- 11. Gasket
- 12. Intake manifold
- 13. Lockwasher
- 14. Screw

- 15. Ignition cable bracket
- 16. Lockwasher
- 17. Bolt
- 18. Bolt
- 19. Exhaust gasket
- 20. Exhaust manifold
- 21. Lockwasher
- 22. Screw
- 23. Muffler
- 24. Piston
- 25. Ring
- 26. Gudgeon pin
- 27. Circlip

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.


○ **NOTE:** The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY ; ASSEMBLY

○ **NOTE:** Refer to Technical Data for component fitted tolerance and wear limit.

⑩⑪ Torque to 2.1 kg-m (15 ft-lbs) following illustrated sequence for cylinder head nuts.



○ **NOTE:** To prevent leakage, install exhaust manifold prior to cylinder head tightening.

⑫ Torque to 1.4 kg-m (10 ft-lbs).

⑬ Torque to 2.1 kg-m (15 ft-lbs).


⑭ Torque to 0.5 kg-m (4 ft-lbs).

⑮⑯⑰ Place a clean cloth over crankcase to prevent circlips from falling into crankcase then use a pointed tool to remove circlips from piston.


Drive the gudgeon pins in or out using a suitable drive punch and hammer.

▼ **CAUTION:** When tapping gudgeon pin in or out of piston, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters AUS (over an arrow on the piston dome) facing direction of the exhaust port.



Once the circlips are installed, turn each circlip so that the circlip break is not directly in line with piston notch. Using very fine emery cloth, remove any burrs on piston caused through circlip installation.



MAGNETO



- 1. Armature ass'y
- 2. Armature plate
- 3. Magneto ring
- 4. Capacitor
- 5. Magneto retaining nut
- 6. Lockwasher
- 7. Screw
- 8. Magneto housing
- 9. Spring
- 10. Centrifugal weight
- 11. Screw
- 12. Starting pulley

- 13. Lockwasher
- 14. Screw
- 15. Wire grommet
- 16. Coils bracket
- 17. Lockwasher
- 18. Screw
- 19. Coil
- 20. Lockwasher
- 21. Screw
- 22. Protection cap
- 23. H.T. cable
- 24. Spark plug protector

- 25. Spark plug
- 26. Lighting coil
- 27. Ignition generator coil
- 28. Flat washer
- 29. Lockwasher
- 30. Screw
- 31. Breaker point set
- 32. Lubricating wick
- 33. Loctite Lock'n Seal 242
- 34. Screw
- 35. Vibration damper (436 only)
- 36. Vibration damper (436 only)

CLEANING

Clean all metal components in a non-ferrous metal cleaner.


CAUTION: Clean armature and magneto using only a clean cloth.

DISASSEMBLY & ASSEMBLY


⊕ To replace a capacitor, it is first necessary to unsolder the two (2) black leads. The capacitor can then be driven out of the armature plate using a suitable drift

and hammer. To reinstall, inverse procedure.


⊕ ⊕ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support, as illustrated. (See Tool Section).



With magneto retaining nut removed and hold-on support in place, install special puller onto hub. Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242 or equivalent, position magneto on crankshaft with the keyway and the cam notch positioned as illustrated.



Install magneto retaining nut (with Loctite Lock'n Seal 242 on threads) and torque to 8.3 kg-m (60 ft-lbs).

① Apply Loctite Lock'n Seal 242 or equivalent on threads.

③ ⑩ At assembly, apply a small amount of low temperature grease into spring seating.

⑩ ⑫ Apply Loctite Lock'n Seal 242 or equivalent on threads.


⑫ ⑫ Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.

To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012"-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and relocate coil.



⑫ When replacing breaker point set, apply a small amount of grease on lubricating wick.


⑫ ⑬ ⑭ Install vibration dampers as per illustration.



Apply Loctite Lock'n Seal 242 or equivalent on threads then torque to 2.1 kg-m (15 ft-lbs).

434, 440 ENGINE TYPE

Bottom End




- | | | | |
|---------------------|---------------------------|--------------------------|-----------------------------|
| 1. Crankshaft | 11. Distance sleeve | 21. Crankcase stud | 31. Engine bracket stud (4) |
| 2. "O" ring (5) | 12. Starter ring gear | 22. Crankcase stud | 32. Lock washer (4) |
| 3. Woodruff key | *13. Washer | 23. Crankcase stud | 33. Nut (4) |
| 4. Needle bearing | *14. Spring | 24. Dowel pin | 34. Sealing ring |
| 5. Ball bearing | *15. Breaker point cam | 25. Fan housing stud (4) | 35. Crankcase drain plug |
| 6. Retaining ring | 16. Tab washer | 26. Lock washer (4) | 36. Dowel tube |
| 7. Distance ring | 17. Magneto retaining nut | 27. Nut | 37. Starter stud (2) |
| 8. Spacer | 18. Lower crankcase half | 28. Lock washer | 38. Starter bracket |
| 9. Oil seal | 19. Upper crankcase half | 29. Cylinder stud (8) | 39. Washer (2) |
| 10. Distance sleeve | 20. Crankcase stud (6) | 30. Distance sleeve (4) | 40. Nut (2) |

*Not installed on engine equipped with a C.D. ignition system.

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

Top End



- 1. Piston (P.T.O. side)
- 2. Piston (Mag. Side)
- 3. Gudgeon pin
- 4. Circlip
- 5. Rectangular ring
- 6. "L"-Trapez or rectangular ring
- 7. Cylinder gasket
- 8. Cylinder (P.T.O. side)


- 9. Cylinder (Mag. side)
- 10. Cylinder head gasket
- 11. Cylinder head (P.T.O. side)
- 12. Cylinder head (Mag. side)
- 13. Flat washer (10)
- 14. Nut (14)
- 15. Distance nut
- 16. Exhaust socket (P.T.O. side-short)

- 17. Exhaust socket (Mag. side -long)
- 18. Asbestos string
- 19. Intake manifold stud
- 20. Intake manifold ring gasket
- 21. Intake manifold
- 22. Manifold cover ring gasket
- 23. Intake manifold cover
- 24. Carburetor stud


- 25. Flange gasket
- *26. Intake deflector
- 27. Isolating flange
- 28. Tab washer
- 29. Exhaust manifold stud (4)
- 30. Exhaust manifold gasket
- 31. Exhaust manifold
- 32. Lock washer

*Applicable on 440 type only.

Magneto




Breaker Point type Ignition



C.D. Ignition

- | | | | |
|----------------------|--|--|---------------------------------------|
| 1. Nut (3) | 11. Allen screw (4) | 20. Breaker point
(unit construction) | 29. Retaining clip |
| 2. Lock washer (3) | 12. Lock washer | 21. Pivot pin | 30. Washer (2) |
| 3. Fan belt pulley | 13. Coil retaining screw | 22. Bolt | 31. Lock washer |
| 4. Stud (3) | 14. Brake light coil (23W) | 23. Lock washer | 32. Allen screw |
| 5. Magneto housing | 15. Ignition generator coil | 24. Nut | 33. Additional lighting
coil (30W) |
| 6. Spring | 16. Capacitor (2) | 25. Screw | 34. Cable connector |
| 7. Centrifugal lever | 17. Armature plate | 26. Lock washer | 35. Insulating sleeve |
| 8. Bearing screw | 18. Lighting coil
(75W, 100W or 110W) | 27. Plain washer | 36. Armature plate
assy |
| 9. Magneto ring | 19. Breaker point set | 28. Washer | |
| 10. Lock washer (4) | | | |

Cooling System



- | | |
|--------------------------------------|-----------------------------------|
| 1. Cowl (Exhaust side) | 19. Cowl cover |
| 2. Cowl (Intake side) | 20. Fan |
| 3. Cowl (434 type only) | 21. Woodruff key |
| 4. Nut | 22. Ball bearing |
| 5. Lock washer | 23. Spacer |
| 6. Flat washer (3) | 24. Locking ring |
| 7. Cable clamp | 25. Shim (5) |
| 8. Spacer (2) | 26. Pulley half |
| 9. Flat washer (3) | 27. Lock washer |
| 10. Lock washer (2) | 28. Fan retaining nut |
| 11. Front cowl retaining bolt (2) | 29. Fan belt |
| 12. Rear cowl retaining bolt | 30. Protector retaining screw (3) |
| 13. Rear cowl retaining bolt (short) | 31. Fan protector |
| 14. Rear cowl retaining bolt (long) | 32. Screw |
| 15. Rubber washer | 33. Flat head screw |
| 16. Flat washer | 34. Fan housing |
| 17. Spring washer | 35. Junction block bracket |
| 18. Cover retaining screw | 36. Lock washer |
| | 37. Screw |

REMOVAL

Remove or disconnect the following (if applicable) then lift engine out of vehicle.

- Drive belt.
- Muffler.

Note: On rear-mounted engine vehicle, the muffler and associated components are accessible through an access panel located under the seat rest.

- Cab retaining cable.
- Air silencer.
- Choke cable or primer line at carburetor.
- Throttle cable.
- Fuel lines at carburetor.

Warning: Secure fuel lines so that the opened ends are higher than the fuel tank.

- Electrical connections.

Caution: On electric start model, disconnect negative cable (ground) from battery **before** disconnecting other wires.

- Engine mount nuts.

DISASSEMBLY & ASSEMBLY

General

Refer to Technical data Section for component fitted tolerance and wear limit. If necessary, refer to Drive Pulley Section for pulley removal.


Bottom End

② The outside diameter of the "O" rings installed on engine type 440, vary.

The two magneto side bearings and the center bearing are fitted with small "O" rings (2 1/8" O.D.) while the two labyrinth seals are fitted with large "O" rings (2 5/16" O.D.).

On 434 engine type, only large "O" rings (2 5/16" O.D.) are installed.


⑥ To remove bearing from crankshaft, use a protective cap and special puller, as illustrated. (See Tool Section).




Prior to installation, place bearings into an oil container and heat the oil to 200° F. for 5 to 10 min. This will expand bearing and ease installation. Install bearings with groove outward.

⑦ A distance ring replaces the crankshaft shoulder on type 440 engine, starting from vehicle serial no. 2,749,845.

⑫ To remove starter gear from crankshaft it may be necessary to use a special puller as illustrated (See Tool Section).



⑬⑰ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).




At assembly, torque retaining nut to 50-58 ft-lbs on 434 type, and to 58-63 ft-lbs on 440 type.

Note: The tab washer located between magneto and retaining nut on late production 440 engine type has been cancelled. Therefore, at assembly apply a light coat of Loctite "Lock'n Seal" on magneto retaining nut threads.

⑱ Prior to joining of crankcase halves, apply a light coat of "Loctite" crankcase sealant to the mating surfaces of the bottom half. Position spring washers and nuts on crankcase studs then torque nuts to 14-16 ft-lbs., following illustrated sequence.

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)



⑭ At assembly, torque to 14-16 ft-lbs.

⑮ At assembly, torque to 29-35 ft-lbs.

Top End


① ② ③ ④ Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.

Caution: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters "AUS", over an arrow on the piston dome, facing in direction of the exhaust port.



Also make sure that the piston window is aligned with the crankcase transfer passage when the gudgeon pin orifice is in-line with the connecting rod bore.



Note: Once the circlips are installed, turn each circlip so it is not directly on piston notch. Remove any burrs on piston caused through circlip installation using very fine emery cloth.




⑥ ⑨ ⑩ ⑪ ⑫ When installing cylinder and / or cylinder head, the cylinder aligning tool must be used to ensure sealing of intake manifold and cylinders. (See Tool Section).

Install exhaust manifold on cylinder then install aligning bar and torque distance nut to 14-16 ft-lbs.

Cross torque cylinder head nuts to 14-16 ft-lbs.

Note: Torque each head individually.



⑭ ⑮ At assembly, torque to 14-16 ft-lbs.

⑲ At assembly, position deflector with tap toward inside on magneto side.


⑳ Tab washer should be replaced if bent more than three (3) times. If in doubt, replace.

Magneto


① At assembly, torque to 14-16 ft-lbs.

③ With magneto retaining nut removed and hold-on support in place, install special puller onto support.

Tighten puller nut and at same time, tap on nut head using a hammer to release magneto from its taper.



At assembly, install magneto on crankshaft with the keyway, centrifugal lever and breaker point cam position as illustrated.



⑥ ⑦ ⑧ At assembly, apply a small amount of low temperature grease into spring seating.

⑪ At assembly, apply Loctite "Lock'n Seal" on retaining screw threads.

⑭ ⑮ ⑯ ⑰ Whenever a coil is replaced, the air gap (distance between magnet and armature end) must be adjusted.

To check air gap, insert a feeler gauge of correct thickness (0.31 mm / .012" 0.45 mm / .018") between magnet and armature ends. To adjust, slacken retaining screw and relocate armature.




⑱ To replace a capacitor, it is first necessary to unsolder the two (2) black leads using a soldering iron. The capacitor can then be driven out of the armature plate using a suitable drift. To reinstall, inverse procedure.

⑲ ⑳ When replacing breaker point set, apply a light coat of grease on pivot pin and rubbing block.

Do not remove pivot pin unless replacement is needed. At assembly, apply Loctite "Lock'n Seal" on threads.

㉑ When replacing unit construction type breaker point, apply a small amount of grease on rubbing block.

㉒ At assembly, align armature plate crankcase marks.




SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

Cooling System

② Heat bearing housing to 140° -160° F. prior to bearing removal or installation.

②②②② Lock fan pulley with special holder wrench or install pulley retaining nut. (See Tool Section).



Shim(s) located between pulley halves are used to adjust fan belt free-play. Correct free-play is $\frac{1}{4}$ ". If necessary to adjust install or remove shim(s) between pulley halves. Install excess shim(s) between outer pulley half and washer.

At assembly, torque fan shaft nut to 42-50 ft-lbs.

②②② At assembly, apply a light coat of Loctite "Lock'n Seal" on threads.

It should be noted that to correctly remove a Loctite locked screw, it is first necessary to tap on head of screw to break Loctite bond. This will eliminate the possibility of screw breakage.

CLEANING

Discard all oil seals, gaskets and "O" rings. Clean all metal components in a non-ferrous metal cleaner.

Caution: Clean armature using only a clean cloth. Scrape off carbon formation from cylinder exhaust ports, cylinder heads and piston domes.

Note: The letter "AUS" over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

Remove old sealant from mating surfaces with Bombardier "Sealant Stripper".

Caution: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


INSTALLATION

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing prior to installation in vehicle.
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

440 ENGINE TYPE (FROM 1976)

ENGINE SUPPORT & MUFFLER
(T'NT & EVEREST)




- 1. Rubber mount
- 2. Nut
- 3. Engine bracket
- 4. Washer
- 5. Reinforcement plate
- 6. Lockwasher
- 7. Nut
- 8. Exhaust manifold

- 9. Washer
- 10. Nut
- 11. Exhaust collar
- 12. Bolt
- 13. Nut
- 14. Spring
- 15. Asbestos tape
- 16. Aluminum ring

- 17. Nut
- 18. Washer
- 19. Muffler
- 20. Exhaust grommet
- 21. Washer
- 22. Rubber shear mount
- 23. Washer
- 24. Nut

ENGINE SUPPORT & MUFFLER
 (OLYMPIQUE 1977)



- | | |
|-------------------------------|----------------------|
| 1. Carriage bolt | 14. Exhaust manifold |
| 2. Flat washer | 15. Spring |
| 3. Spacer | 16. Sealing ring |
| 4. Vibration absorber (lower) | 17. Muffler |
| 5. Retainer | 18. Spring |
| 6. Lockwasher | 19. Washer |
| 7. Nut | 20. Spring |
| 8. Vibration absorber (upper) | 21. Muffler support |
| 9. Washer | 22. Bolt |
| 10. Nut | 23. Washer |
| 11. Nut | 24. Rubber spacer |
| 12. Engine bracket | 25. Stud |
| 13. Reinforcement plate | 26. Nut |

ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Remove or disconnect the following (if applicable) then lift engine out of vehicle.

- Pulley guard & drive belt.
- Muffler & air duct.
- Cab retaining cable.
- Air intake silencer.
- Fuel lines at carburetor, impulse line.
- Throttle cable.
- Electrical junction block.

▼ **CAUTION:** On electric start model, disconnect negative cable (ground) from battery before disconnecting other wires.

- Rewind starter.
- Engine mount nuts.

DISASSEMBLY & ASSEMBLY


- ⑦ Torque to 4.4 kg-m (32 ft-lbs).
- ⑩ Torque to 2.1 kg-m (15 ft-lbs).
- ⑳ At assembly on crankcase, apply Loctite Lock'n Seal 242 or equivalent on threads.

INSTALLATION ON VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing prior to installation in vehicle.
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

BOTTOM END



1. Crankshaft
2. "O" ring (sealing ring)
3. Shim
4. Bearing
5. "O" ring
6. Distance ring (4 mm)
7. Retaining washer
8. Oil seal
9. Washer
10. Cam spring
11. Breaker point cam
12. Loctite 242
13. Magneto ring nut
14. Woodruff key
15. Distance ring 1 mm
16. Distance sleeve

17. Upper crankcase half
18. Lower crankcase half
19. Crankcase sealant
20. Needle cage bearing
21. Drain plug
22. Sealing ring
23. Lockwasher
24. Bolt or stud with nut
25. Stud
26. Lockwasher
27. Nut
28. Stud (fan housing)
29. Washer (fan housing)
30. Nut (fan housing)
31. Stud (cylinder)

BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.

Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY

General

Refer to Technical Data Section for component fitted tolerance and wear limit.

①③ Crankshaft end-play is adjusted with shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim(s), proceed as follows.


○ **NOTE:** Crankshaft end-play requires adjustment only when crankshaft and / or crankcase is replaced.

Remove magneto side bearings and existing shim(s). Slide the appropriate bearing simulator and the retaining washers on the crankshaft. (See Tool Section).


Position crankshaft assembly into crankcase lower half. Make sure that retaining washers are correctly seated in the grooves.

Gently tap crankshaft counterweight until P.T.O. side inner bearing bears against retaining washer.

Any free-play between the bearing simulator and magneto side retaining washer, minus recommended end-play, is the distance to be covered by shim(s). Shims are available in the thickness of 0.15 mm (.006"), 0.20 mm (.008") and 0.30 mm (.012").



④ To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tool Section).




Prior to installation, place bearings into an oil container and heat the oil to 100° C (210° F) for 10 min. This will expand bearings and ease installation.

Install bearings with groove outward.

○ **NOTE:** Prior to magneto side bearing installation, determine crankshaft end-play and install required shim(s) on crankshaft extension.

⑤ At assembly apply a light coat of lithium grease on seal lip. Seal outer surface should be flush with crankcase.

⑥ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).



At assembly, apply Loctite Lock'n Seal 242 or equivalent on threads then torque to 8.3 kg-m (60 ft-lbs).


SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

⑰ ⑱ ⑲ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves.

Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant (See Tool Section) as per instructions printed on container.

Position the crankcase halves together and tighten nuts (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque bolts or nuts to 2.2 kg-m (16 ft-lbs) following illustrated sequence.




⑳ ㉑ Torque to 2.2 kg-m (16 ft-lbs).

㉒ At assembly on crankcase apply Loctite Lock'n Seal 242 or equivalent on threads.

㉓ Torque to 4.4 kg-m (32 ft-lbs).

TOP END



1. Gasket (cylinder / crankcase)
2. Cylinder (P. T. O.)
3. Cylinder (mag.)
4. Cylinder head gasket
5. Cylinder head (P. T. O.)
6. Cylinder head (Mag.)
7. Flat washer
8. Support sleeve
9. Nut
10. Distance nut
11. Distance nut
12. Stud
13. Gasket
14. Intake manifold
15. Gasket
16. Intake cover
17. Flat washer
18. H. T. cable bracket

19. Lockwasher
20. Nut
21. Gasket
22. Intake deflector
23. Isolating flange
24. Bolt
25. Stud or bolt
26. Exhaust gasket
27. Exhaust manifold
28. Lockwasher
29. Nut or bolt
30. Sealing ring
31. Muffler
32. Piston
33. Gudgeon pin
34. Circlip
35. Rectangular ring
36. "L" ring

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

NOTE: The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.


Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY & ASSEMBLY


NOTE: Refer to Technical Data for component fitted tolerance and wear limit.

When installing cylinder and/or cylinder head, the cylinder aligning tool must be used to ensure sealing of intake manifold and cylinders. (See Tool Section).

With exhaust manifold and aligning tool installed, you can then cross torque cylinder head nuts to 2.1 kg-m (15 ft-lbs).



Position nuts and distance nuts as per illustration then cross torque to 2.1 kg-m (15 ft-lbs).



NOTE: Torque each cylinder head individually.

At assembly, position deflector with tab toward inside on magneto side.

Torque to 2.1 kg-m (15 ft-lbs).

Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.


CAUTION: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters "AUS" (over an arrow on the piston dome) facing in direction of the exhaust port.

EXHAUST




Also make sure that the piston window is aligned with the crankcase transfer passage when the gudgeon pin orifice is in-line with the connecting rod bore.



NOTE: Once the circlips are installed, turn each circlip so it is not directly on piston notch. Remove any burrs on piston caused through circlip installation using very fine emery cloth.



MAGNETO



- | | | |
|-----------------------|--------------------|-----------------------------|
| 1. Armature ass'y | 13. Lockwasher | 25. Spark plug protector |
| 2. Armature plate | 14. Screw | 26. Spark plug |
| 3. Magneto ring | 15. Wire grommet | 27. Magneto ring nut |
| 4. Screw | 16. Coil bracket | 28. Loctite 242 |
| 5. Lockwasher | 17. Lockwasher | 29. Breaker point |
| 6. Lockwasher | 18. Screw | 30. Lubricating wick |
| 7. Screw | 19. Ignition coil | 31. Capacitor |
| 8. Magneto housing | 20. Lockwasher | 32. Lighting coil |
| 9. Spring | 21. Screw | 33. Ignition generator coil |
| 10. Centrifugal level | 22. Protection cap | 34. Screw |
| 11. Screw | 23. H.T. cable | 35. Flat washer |
| 12. Starting pulley | 24. Protection cap | |

MAGNETO

CLEANING


Clean all metal components in a non-ferrous metal cleaner.

CAUTION: Clean armature ass'y and magneto using only a clean cloth.

DISASSEMBLY & ASSEMBLY


① At assembly apply Loctite Lock'n Seal 242 on threads.

② To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).




With magneto retaining nut removed and hold on support in place, install special puller onto support.

Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242 or equivalent, position magneto on crankshaft with the keyway and the cam notch positioned as illustrated.



Install magneto retaining nut (with Loctite Lock'n Seal 242 on threads) and torque to 8.3 kg-m (60 ft-lbs).

③ At assembly apply a small amount of low temperature grease into spring seating.

④ Torque to 2.1 kg-m (15 ft-lbs).

⑤ ⑥ Apply Loctite Lock'n Seal 242 or equivalent on threads.

⑦ Apply Loctite Lock'n Seal 242 on threads then torque to 8.3 kg-m (60 ft-lbs).



⑧ Do not remove pivot pin unless replacement is needed, if removed, reinstall with Loctite Lock'n Seal 242 on threads.

Old type breaker point set can be replaced by new type if pivot pin is removed. When installing new breaker point type it is advisable to fill the pivot pin cavity of the armature plate with Loctite 277 (thick red solution).

⑨ When replacing breaker point set, apply a light coat of grease on lubricating wick.


⑩ To replace a capacitor, it is first necessary to unsolder the two (2) black leads using a soldering iron. The capacitor can then be driven out of the armature plate using a suitable drift. To reinstall, inverse procedure.

⑪ ⑫ Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.

To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012"-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and relocate coil.



COOLING SYSTEM



1. Fan housing
2. Circlip
3. Washer (2)
4. Bearing
5. Fan
6. Woodruff key
7. Shim (2)
8. Pulley halves
9. Shim
10. Lockwasher
11. Nut
12. Belt

13. Cable clamp
14. Washer
15. Spring washer
16. Screw M6 x 35
17. Screw M6 x 30
18. Screw M6 x 80
19. Fan cover
20. Screw
21. Fan cowl (exhaust)
22. Sealing strip
23. Distance sleeve
24. Washer

25. Screw M8 x 35
26. Screw M8x 28
27. Screw M8 x 20
28. Fan cowl cover
29. Spring washer
30. Washer
31. Fan cowl (intake) T'NT Everest
32. Fan cowl (intake) Olymp.
33. Electrical junction block bracket
34. Lockwasher
35. Screw

COOLING SYSTEM


CLEANING

Clean all components in a non ferrous metal cleaner.


DISASSEMBLY & ASSEMBLY

④ Heat bearing housing to 90° C (160° F) prior to bearing removal or installation.

⑤ Newer inner pulley half does not have a shoulder on its inner face so it is installed with a 6 mm (.236") spacer.




⑪ To remove or install pulley retaining nut lock fan pulley with special holder wrench (See Tools Section). At assembly torque nut to 6.4 kg-m (46 ft-lbs).




⑫ Shim(s) located between pulley halves are used to adjust fan belt free-play. Correct free-play is 6 mm (1/4"). If necessary to adjust install or remove shim(s) between pulley halves. Install excess shim(s) between outer pulley half and washer.

⑬ ⑭ ⑮ ⑯ Apply Loctite Lock'n Seal 242 on threads.

○ NOTE: It should be noted that to correctly remove a Loctite locked screw, it is first necessary to tap on head of screw to break Loctite bond. This will eliminate the possibility of screw breakage.



OLYMPIQUE




T'NT & EVEREST

640 ENGINE TYPE

BOTTOM END


1. Crankshaft
2. "O" ring
3. Woodruff key
4. Needle bearing
5. Ball bearing
6. Retaining disc
7. Oil seal
8. Shim (as required)
9. Washer
- *10. Spring
- *11. Breaker point cam
12. Lock washer
13. Magneto retaining nut
14. Distance sleeve
15. Starter gear
16. Oil drain screw
17. Sealing ring
18. Lower crankcase half
19. Upper crankcase half
20. Crankcase stud (9 short)
21. Crankcase stud (1 medium)
22. Crankcase stud (2 long)
23. Dowel pin
24. Fan housing stud (4)
25. Lock washer (4)
26. Nut (19)
27. Lock washer (15)
28. Cylinder head stud (8)
29. Crankcase / support stud (4)
30. Lock washer (4)
31. Nut (4)
32. Spacer tube
33. Dowel tube
34. Electric starter stud
35. Starter bracket
36. Nut (2)
37. Washer (2)



*Breaker point ignition only.

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)


TOP END



1. Piston (P.T.O. side)
2. Piston (Mag. side)
3. Gudgeon pin
4. Circlip
5. Rectangular ring
6. Crankcase / cylinder gasket
7. Cylinder (P.T.O. side)
8. Cylinder (Mag. side)
9. Cylinder head gasket
10. Cylinder head (P.T.O. side)
11. Cylinder head (Mag. side)
12. Washer (7)
13. Nut (15)
14. Support sleeve
15. Distance nut
16. Exhaust socket stud (4)

17. Exhaust socket gasket
18. Exhaust socket (P.T.O. side)
19. Exhaust socket (Mag. side)
20. Lock washer (6)
21. Sealing ring (2 or 4)
22. Intake manifold stud
23. Profile gasket (Mag. side)
24. Profile gasket (P.T.O. side)
25. Intake manifold
26. Profile gasket
27. Intake manifold cover
28. Ignition cable bracket
29. Carburetor stud
30. Flange gasket
31. Isolating flange
32. Tab washer


MAGNETO



- 1. Nut (3)
- 2. Lock washer (3)
- 3. Starting pulley
- 4. Starting pulley stud (3)
- 5. Magneto housing
- 6. Centrifugal lever spring
- 7. Centrifugal lever
- 8. Bearing screw
- 9. Magneto ring
- 10. Lock washer (4)
- 11. Allen screw (4)
- 12. Coil retaining screw (4)
- 13. Lock washer (4)
- 14. Lighting coil
- 15. Ignition generator coil
- 16. Capacitor charging coil

- 17. Capacitor (2)
- 18. Washer (2)
- 19. Lock washer (2)
- 20. Allen screw (2)
- 21. Armature plate
- 22. Breaker point set
- 23. Breaker point (unit construction)
- 24. Pivot pin
- 25. Bolt
- 26. Lock washer
- 27. Nut
- 28. Screw
- 29. Lock washer
- 30. Washer
- 31. Washer
- 32. Retaining clip

COOLING SYSTEM



- 1. Cylinder cowl (exhaust side)
- 2. Cylinder cowl (intake side)
- 3. Allen screw (2)
- 4. Lock nut (2)
- 5. Bolt
- 6. Lock washer
- 7. Cowl retainer washer
- 8. Spring holder
- 9. Bolt
- 10. Nut
- 11. Lock washer
- 12. Fan
- 13. Woodruff key
- 14. Ball bearing

- 15. Spacer (2)
- 16. Locking ring
- 17. Spring washer (4)
- 18. Flat headed screw (3)
- 19. Screw
- 20. Spacer
- 21. Pulley half
- 22. Lock washer
- 23. Nut
- 24. Fan belt
- 25. Fan housing
- 26. Cover retaining screw (3)
- 27. Fan cover
- 28. Shim (as required)

REMOVAL

Remove or disconnect the following (if applicable) then lift engine out of vehicle.

- Drive belt.
- Muffler.
- Air silencer tube.
- Choke cable at carburetor.
- Throttle cable at carburetor.
- Fuel lines at carburetor.

Note: Secure fuel lines so that the opened ends are higher than the fuel level in the tank.

- Disconnect negative cable (ground) from battery, then disconnect electrical connections leading from engine.
- Console.
- Engine mount nuts.

DISASSEMBLY & ASSEMBLY

General


Refer to Technical Data Section for component fitted tolerance and wear limit.

If necessary, refer to Drive Pulley Section for pulley removal.


Bottom End

② The "O" ring / ball bearing combination within the same engine may vary depending on production date of engine.

For correct assembly, refer to the following chart for identification.

Ball bearing groove width 	"O" RING	
	Outside diameter	Part number
.118" (3 mm)	2 3/4"	420 830 370
.078" (2 mm)	2 5/16"	420 830 350

③ To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tool Section).



Prior to installation, place bearings into an oil container and heat the oil to 200° F. for 5 to 10 min. This will expand bearings and ease installation.

Install bearings with groove outward.


④ Crankshaft end-play is adjusted with shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim(s), proceed as follows.

Remove magneto side bearing and existing shim(s). Slide the appropriate crankshaft ring and the retaining disc on the crankshaft. (See Tool Section).

Position crankshaft assembly into crankcase lower half. Make sure that retaining discs are correctly seated in the grooves.


Gently tap crankshaft counterweight until P.T.O. side bearing bears against retaining disc.

Any free-play between the crankshaft ring and magneto side retaining disc, minus recommended end-play, is the distance to be covered by shim(s). Shims are available in the thickness of 0.1 mm / .004", 0.2 mm / .008", 0.3 mm / .012", 0.5 mm / .020", 1 mm / .039".



Note: Crankshaft end-play requires adjustment only when crankshaft and / or crankcase is replaced.


⑤ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).



SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

At assembly, torque retaining nut to 58-63 ft-lbs.


⑮ To remove starter gear from crankshaft it may be necessary to use a special puller as illustrated. (See Special Tool).



At assembly, apply a light coat of anti-seize compound on crankshaft extension nearest starter gear.

⑩ Prior to joining of crankcase halves, apply a light coat of "Loctite" crankcase sealant to the mating surfaces of the bottom half.

Position spring washers and nuts on crankcase studs then torque nuts to 14-16 ft-lbs., following illustrated sequence.



⑫ At assembly, torque to 14-16 ft-lbs.


⑬ At assembly, torque to 29-35 ft-lbs.

Top End


① ② ③ ④ Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.

Caution: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.


At assembly, place the pistons over the connecting rods with the letters "AUS", over an arrow on the piston dome, facing in direction of the exhaust port.



Also make sure that the piston windows are aligned with the crankcase transfer passages when the gudgeon pin orifice is in-line with the connecting rod bore.



Note: Once the circlips are installed turn each circlip so the circlip break is not directly on piston notch. Remove any burrs from piston caused through circlip installation using very fine emery cloth.




⑦ ⑧ ⑨ ⑩ ⑪ When installing cylinder and / or cylinder head, the cylinder aligning tool must be used to ensure sealing of intake manifold and cylinders. (See Tool Section).

Install muffler on exhaust socket then install aligning bar.

Torque distance nut to 14-16 ft-lbs.

Cross torque cylinder head nut to 14-16 ft-lbs.

Note: Torque each cylinder head individually.




⑫ ⑬ At assembly, torque to 14-16 ft-lbs.


Magneto

⑭ With magneto retaining nut removed and hold-on support in place, install special puller onto hub.

Tighten puller nut and at same time, tap on nut head using a hammer to release magneto from its taper.



At assembly, on engine fitted with breaker points, position magneto on crankshaft with the keyway and the cam notch positioned as illustrated.



⑥ ⑦ ⑧ At assembly, apply a small amount of low temperature grease into spring seating.

⑩ At assembly, apply Loctite "Lock'n Seal" on retaining screw threads.

⑭ ⑮ ⑯ Whenever a coil is replaced, the air gap (distance between magnet and armature end) must be adjusted.

To check air gap, insert a feeler gauge of correct thickness (0.31 mm / .012" - 0.45 mm / .018") between magnet and armature ends. If necessary to adjust, slacken retaining screw and relocate armature.



SECTION 04 SUB-SECTION 02 (TWO CYLINDER ENGINE)

⑰ To replace a capacitor, it is first necessary to unsolder the two (2) black leads. The capacitor can then be driven out of the armature plate using a suitable drift and hammer. To reinstall, inverse procedure.

⑱ ⑲ When replacing breaker point set, apply a light coat of grease on pivot pin and rubbing block.

⑳ When replacing unit construction type breaker point, apply a small amount of grease on rubbing block.


Note: New unit construction type breaker point may be installed on older engine. To install, simply remove pivot pin, then insert new breaker point pin into threaded hole and secure. A special tool is available to remove old pivot pin. (See Tool Section).

Cooling System

⑭ It is first necessary to heat bearing housing to 140° - 160° F. to remove or install bearing.

⑩ ⑩ At assembly, apply a light coat of Loctite "Lock'n Seal" on threads. It should be noted that to correctly remove a Loctite locked screw, it is first necessary to slightly tap a head of screw to break Loctite bond. The screw can then be removed. This will eliminate the possibility of screw breakage.

⑳ ㉑ ㉒ ㉓ Lock fan pulley with special holder wrench to remove or install pulley retaining nut. (See Tool Section).



Shim(s) located between pulley halves are used to adjust fan belt free-play. Correct free-play is $\frac{1}{4}$ ". If necessary to adjust, install or remove shim(s) between pulley halves. Install excess shim(s) between outer pulley half and washer.

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.

Clean all metal components in a non-ferrous metal cleaner.

Caution: Clean armature using only a clean cloth.

Scrape off carbon formation from cylinder exhaust ports, cylinder heads and piston domes using a wooden spatula.

Note: The letter "AUS" over an arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

Remove old sealant from crankcase mating surfaces with Bombardier "Sealant stripper".

Caution: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.


INSTALLATION

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing prior to installation on vehicle.
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

640-ENGINE TYPE (FROM 1976)

ENGINE SUPPORT & MUFFLER



- 1. Carriage bolt
- 2. Threaded insulator
- 3. Rubber insulator
- 4. Engine support
- 5. Washer
- 6. Nut
- 7. Bolt
- 8. Spring leaf
- 9. Engine bracket
- 10. Washer
- 11. Washer
- 12. Nut
- 13. Air duct

- 14. Retainer ring
- 15. Screw
- 16. Nut
- 17. Aluminum ring
- 18. Exhaust manifold
- 19. Spring
- 20. Exhaust manifold elbow
- 21. Aluminum ring
- 22. Muffler
- 23. Spring
- 24. Muffler clamp
- 25. Screw
- 26. Cup

- 27. Bushing
- 28. Spring
- 29. Cup
- 30. Exhaust grommet
- 31. Rubber plug
- 32. Distance sleeve
- 33. Stud
- 34. Lockwasher
- 35. Nut
- 36. Loctite Lock'n Seal 242

ENGINE SUPPORT & MUFFLER

REMOVAL FROM VEHICLE

Remove or disconnect the following (if applicable) then lift engine out of vehicle.

- Drive belt.
- Muffler.
- Air intake silencer tube.
- Choke cable at carburetor.
- Throttle cable at carburetor.
- Fuel lines at carburetor.

○ **NOTE:** Secure fuel lines so that the opened ends are higher than the fuel level in the tank.

- Disconnect negative cable (ground) from battery, then disconnect electrical connections leading from engine.
- Console.
- Engine mount nuts.

DISASSEMBLY & ASSEMBLY


- Ⓢ At assembly on crankcase, apply Loctite Lock'n Seal 242 or equivalent on threads.
- Ⓢ Torque to 4.4 kg-m (32 ft-lbs).

INSATALLATION IN VEHICLE

To install engine on vehicle, inverse removal procedure. However, pay attention to the following:

- Check ignition timing prior to installation on vehicle.
- Check tightness of engine mount nuts.
- After throttle cable installation, check carburetor maximum throttle opening.
- Check pulley alignment.

BOTTOM END



- | | |
|-----------------------------|-------------------------|
| 1. Crankshaft | 17. Nut (magnetol) |
| 2. Shim | 18. Breaker point cam |
| 3. Bearing | 19. Spring |
| 4. Starter gear | 20. Washer |
| 5. Bushing (manual model) | 21. Oil seal |
| 6. Crankcase upper half | 22. Retaining washer |
| 7. Crankcase lower half | 23. Needle cage bearing |
| 8. Crankcase sealant | 24. "O" ring (bearing) |
| 9. Bolt or stud with nut | 25. "O" ring |
| 10. Lockwasher | 26. Stud |
| 11. Loctite Lock'n Seal 242 | 27. Woodruff key |
| 12. Stud | 28. Stud |
| 13. Spacer bushing | 29. Washer |
| 14. Lockwasher | 30. Washer |
| 15. Nut | 31. Screw |
| 16. Nut | |

BOTTOM END

CLEANING

Discard all oil seals, gaskets, "O" rings and sealing rings.

Clean all metal components in a non-ferrous metal cleaner.

Remove old sealant from crankcase mating surfaces with Bombardier sealant stripper.

CAUTION: Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY & ASSEMBLY

General

Refer to Technical Data Section for component fitted tolerance and wear limit.

①② Crankshaft end-play is adjusted with shim(s) located between crankshaft and magneto side bearing. To determine correct amount of shim(s), proceed as follows.


○ **NOTE:** Crankshaft end-play requires adjustment only when crankshaft and/or crankcase is replaced.

Remove magneto side bearing and existing shim(s). Slide the appropriate bearing simulator and the retaining washer on the crankshaft. (See Tool Section).


Position crankshaft assembly into crankcase lower half. Make sure that retaining washers are correctly seated in the grooves.

Gently tap crankshaft counterweight until P.T.O. side bearing bears against retaining washer.

Any free-play between the bearing simulator and magneto side retaining washer, minus recommended end-play, is the distance to be covered by shim(s). Shims are available in the thickness of 0.1 mm (.004"), 0.2 mm (.008"), 0.3 mm (.012"), 0.5 mm (.020"), 1 mm (.039").



③ To remove bearing from crankshaft use a protective cap and special puller, as illustrated. (See Tool Section).




Prior to installation, place bearings into an oil container and heat the oil to 100° C (210° F) for 10 min. This will expand bearings and ease installation.

Install bearings with groove outward.

○ **NOTE:** Prior to magneto side bearing installation, determine crankshaft end-play and install required shim(s) on crankshaft extension.

④ To remove starter gear from crankshaft it may be necessary to use a special puller as illustrated. (See Special Tools).





At assembly, apply a light coat of anti-seize compound on crankshaft extension nearest starter gear.

⑥⑦⑧ Crankcase halves are factory matched and therefore, are not interchangeable or available as single halves.

Prior to joining of crankcase halves, prepare mating surfaces with crankcase sealant primer then apply a light coat of crankcase sealant (See Tool Section) as per instructions printed on container.

Position the crankcase halves together and tighten nuts (or bolts) by hand then install armature plate (tighten) on magneto side to correctly align the crankcase halves.

Torque nuts (or bolts) to 2.2 kg-m (16 ft-lbs) following illustrated sequence.




- Ⓐ Torque to 2.2 kg-m (16 ft-lbs).
- Ⓑ At assembly on crankcase, apply Loctite Lock'n Seal 242 or equivalent on threads.
- Ⓒ Torque to 4.4 kg-m (32 ft lbs).
- Ⓓ Torque to 2.2 kg-m (16 ft-lbs).
- Ⓔ To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section).

- At assembly, apply Loctite Lock'n Seal 242 or equivalent on threads then torque to 7.5 kg-m (54 ft lbs).
- Ⓕ At assembly apply a light coat of lithium grease on seal lip. Seal outer surface should be flush with crankcase.

SECTION 04
SUB-SECTION 02 (TWO CYLINDER ENGINE)

TOP END



- | | |
|----------------------------------|-----------------------------|
| 1. Gasket (cylinder / crankcase) | 18. Lockwasher |
| 2. Cylinder (P.T.O.) | 19. Nut |
| 3. Cylinder (Mag) | 20. Gasket |
| 4. Gasket (head, cylinder) | 21. Isolating flange |
| 5. Cylinder head (P.T.O.) | 22. Locking tab |
| 6. Cylinder head (Mag) | 23. Nut |
| 7. Flat washer | 24. Exhaust gasket |
| 8. Support sleeve | 25. Exhaust socket (P.T.O.) |
| 9. Nut | 26. Exhaust socket (Mag) |
| 10. Distance nut | 27. Lockwasher |
| 11. Stud | 28. Screw |
| 12. Gasket | 29. Sealing ring |
| 13. Intake manifold | 30. Exhaust manifold |
| 14. Gasket | 31. Piston |
| 15. Intake cover | 32. Ring |
| 16. Stud | 33. Gudgeon pin |
| 17. Washer | 34. Circlip |

TOP END

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

NOTE: The letter "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston mag grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY & ASSEMBLY


NOTE: Refer to Technical Data for component fitted tolerance and wear limit.

When installing cylinder and / or cylinder head, the cylinder aligning tool must be used to ensure sealing of intake manifold and exhaust. (See Tool Section).

Install muffler on exhaust socket then install aligning bar.

Cross torque cylinder head nuts to 2.1 kg-m (15 ft-lbs).

NOTE: Torque each cylinder head individually.



Torque cylinder head nuts to 2.1 kg-m (15 ft-lbs).

Torque to 2.1 kg-m (15 ft-lbs).

Place a clean cloth over crankcase to prevent circlip from falling into crankcase. Use a pointed tool to remove circlips from piston.


CAUTION: When tapping out gudgeon pins, hold piston firmly in place to eliminate the possibilities of transmitting shock and pressure to the connecting rod.

At assembly, place the pistons over the connecting rods with the letters "AUS" (over an arrow on the piston dome) facing in direction of the exhaust port.


EXHAUST




Also make sure that the piston windows are aligned with the crankcase transfer passages when the gudgeon pin orifice is in-line with the connecting rod bore.





NOTE: Once the circlips are installed turn each circlip so the circlip break is not directly on piston notch. Remove any burrs from piston caused through circlip installation using very fine emery cloth.



MAGNETO



- 1. Nut
- 2. Loctite Lock'n Seal 242
- 3. Magneto housing
- 4. Spring
- 5. Centrifugal weight
- 6. Screw
- 7. Screw
- 8. Lockwasher
- 9. Lighting coil 110 W
- 10. Ignition generating coil
- 11. Lighting coil 30 W
- 12. Capacitor
- 13. Breaker point set
- 14. Pivot pin
- 15. Breaker point
- 16. Lubricating wick
- 17. Screw
- 18. Screw
- 19. Lockwasher
- 20. Starting pulley
- 21. Magneto ring
- 22. Armature
- 23. Screw
- 24. Lockwasher



- 25. Flat washer
- 26. Wires grommet
- 27. Armature plate
- 28. Screw
- 29. Distance sleeve 11 mm
- 30. Spark plug

- 31. Sealing sleeve
- 32. Spark plug protector (shielded)
- 33. Protection cap
- 34. H.T. cable
- 35. Protection cap
- 36. Ignition coil

MAGNETO


CLEANING

Clean all metal components in a non-ferrous metal cleaner.

CAUTION: Clean armature and magneto using only a clean cloth.


DISASSEMBLY & ASSEMBLY

To remove or install magneto retaining nut, lock crankshaft in position with special hold-on support as illustrated. (See Tool Section)



①②③ With magneto retaining nut removed and hold-on support in place, install special puller onto hub.

Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto from its taper.



At assembly, clean crankshaft extension (taper) then apply Loctite Lock'n Seal 242 or equivalent.



Install magneto retaining nut (with Loctite Lock'n Seal 242 on threads) and torque to 8.3 kg-m (60 ft-lbs).

④⑤ At assembly, apply a small amount of low temperature grease into spring seating.

⑦ At assembly, apply Loctite Lock'n Seal 242 on retaining screw threads.

⑧⑨⑩ Whenever a coil is replaced, the air gap (distance between coil end and magnet) must be adjusted.

To check air gap, insert a feeler gauge of 0.30-0.45 mm (.012"-.018") between magnet and coil ends. If necessary to adjust, slacken coil retaining screws and relocate coil.



⑪ To replace a capacitor, it is first necessary to unsolder the two (2) black leads. The capacitor can then be driven out of the armature plate using a suitable drift and hammer. To reinstall, inverse procedure.


⑫⑬ Do not remove pivot pin unless replacement is needed, if removed reinstall with Loctite Lock'n Seal on threads.

Old type breaker point set can be replaced by new type if pivot pin is removed. When installing new breaker point type it is advisable to fill the pivot pin cavity of the armature plate with Loctite 277 (thick red solution).

⑭ When replacing breaker point set, apply a light coat of grease on lubricating wick.

⑰ Apply Loctite Lock'n Seal 242 on threads.

COOLING SYSTEM



COOLING SYSTEM

CLEANING

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY & ASSEMBLY

①④ It is first necessary to heat bearing housing to 65° C (150° F) to remove or install bearing.

⑤ Newer pulley half does not have a shoulder on its inner face so it is installed with a 6 mm (.236") spacer.


Pulley half



⑥ Shim(s) located between pulley halves are used to adjust fan belt free-play. Correct free-play is 6 mm (¼"). If necessary to adjust, install or remove shim(s) between pulley halves. Install excess shim(s) between outer pulley half and washer.

⑦ Lock fan pulley with special holder wrench to remove or install pulley retaining nut. (See Tool Section).

Special holder wrench



At assembly torque nut to 6.4 kg-m (46 ft-lbs).

⑧⑨⑩⑪ At assembly, apply a light coat of Loctite "Lock'n Seal 242" on threads. It should be noted that to correctly remove a Loctite locked screw, it is first necessary to slightly tap on head screw to break Loctite bond. The screw can then be removed. This will eliminate the possibility of screw breakage.

TWO CYLINDER ENGINE — BREAKER POINTS TYPE

FOREWORD

For timing purposes, it is necessary to separate the twin cylinder engines into three groups.

GROUP 1: engine types 248, 294

These engines do not incorporate an automatic advance mechanism. The ignition timing marks on the magneto ring are stamped at the full advance position.

GROUP 2: engine types 338, 401, 434

343 prior to serial no. 2 670 920
440 prior to serial no. 2 748 146
640 prior to serial no. 2 637 301

These engines incorporate an automatic advance mechanism. The ignition timing marks on the magneto ring are stamped at the no advance position.

GROUP 3: engine types 305

343 from serial no. 2 670 921
440 from serial no. 2 748 147
640 from serial no. 2 637 302
346 and 436 from 1977

These engines incorporate an automatic advance mechanism. The ignition timing marks on the magneto ring are stamped at the full advance position. Therefore, when setting the ignition timing **always hold the centrifugal lever at the full advance position.**


Two methods are detailed in this section; the first using the timing marks stamped on the engine, the second using a T.D.C. gauge.

TIMING MARKS PROCEDURE

1. Disconnect spark plug wires and remove spark plugs.
2. Remove rewind starter assembly from engine then remove the fan protector, starting pulley and "V" belt.

NOTE: The upper breaker points set controls the timing of the magneto side piston and the lower breaker points set controls the P.T.O. side piston.

3. Rotate crankshaft until breaker points, visible through magneto ring opening, are fully open. Adjust points setting to 0.40 mm (0.05 (0.016" (0.02) using a feeler gauge and screwdriver, as illustrated. Repeat procedure for other set of points. **Adjust both side equally.**




NOTE: Breaker points gap can change upon tightening. Always recheck after tightening.


4. Disconnect junction block at engine then connect one lead of a timing light (flashlight type or of a tone timer), to the blue wire (mag. side) leading from engine. Connect other wire to fan cowl (ground).

NOTE: On group III engines, hold centrifugal lever in the open position (toward magneto rim) while performing steps 5, 6 and 7).

5. Slacken the two (2) armature plate retaining screws and turn timing instrument ON. Rotate crankshaft until mag. side piston approaches top dead center and timing marks align. Rotate armature plate until timing light fluctuates or tone signal level varies. Retighten retaining screws.
6. Ignition timing can change upon tightening therefore, rotate the magneto counter-clockwise ¼ of a turn and slowly turn the magneto back in a clockwise direction. As soon as the timing marks align the timing light should fluctuate, or the tone signal level should vary. Readjust if necessary.



Too early: Turn armature plate clockwise




Too late: Turn armature plate counter-clockwise

SECTION 04


SUB-SECTION 04 (IGNITION TIMING)

7. Disconnect timing instrument wire from blue wire then reconnect it to the blue / red wire (P.T.O. side) leading from engine. Rotate crankshaft until P.T.O. side piston approaches top dead center. As soon as timing marks align timing light should fluctuate, or tone signal sound level should vary. If necessary to adjust proceed as follows:

- If timing is too early decrease breaker points gap toward lower limit, i.e. 0.35 mm (.014"), then recheck timing.
- If timing is too late increase breaker points gap toward upper limit, i.e. 0.45 mm (.018"), then recheck timing.



Too early: Decrease points gap



Too late: Increase points gap


TDC GAUGE PROCEDURE

1. Disconnect spark plug wires and remove spark plugs.
2. Remove rewind starter assembly from engine then remove the fan protector, starting pulley and "V" belt.

NOTE: The upper breaker points set controls the timing of the magneto side piston and the lower breaker points set control the P.T.O. side piston.


3. Rotate crankshaft until breaker points, visible through magneto ring opening are fully open. Adjust points setting to $0.40 \text{ mm} \pm 0.05$ (.016" \pm .002) using a feeler gauge and screwdriver, as illustrated.

Repeat procedure for other set of points. Adjust both side equally.



NOTE: Breaker points gap can change upon tightening. Always recheck after tightening.

4. Disconnect junction block at engine then connect one lead of a timing light (flashlight type or a tone timer), to the blue wire (mag. side) leading from engine. Connect other wire to fan cowl (ground).
5. Install and adjust T.D.C. gauge on engine as follows.
 - Rotate magneto until mag. side piston is just before top dead center.
 - With gauge in adaptor, adjust roller so that it is parallel with dial face. Tighten roller lock nut.



- Loosen adaptor lock nut then holding gauge with dial face toward magneto, screw adaptor in mag. side spark plug hole.
 - Slide gauge far enough into adaptor to obtain a reading then finger tighten adaptor lock nut.
 - Rotate magneto until mag. side piston is at Top Dead Center.
 - Unlock outer ring of dial and turn it until "0" on dial aligns with pointer.
 - Lock outer ring in position.
6. Slacken the two (2) armature plate retaining screws and turn timing instrument ON.

Rotate magneto counter-clockwise until specified piston position before top dead center is reached. (Refer to Technical Data Section). Hold advance mechanism centrifugal lever in full advance position (toward magneto ring) then slowly rotate armature plate until timing light fluctuates or until tone signal sound level varies. Retighten retaining screws.

- **NOTE:** Ignition timing can change upon tightening. Always recheck after tightening.
7. Disconnect timing instrument wire from blue wire then reconnect it to the blue / red wire leading from engine. Remove T.D.C. gauge from mag. side and reinstall it on P.T.O. side, as previously detailed.
8. Hold centrifugal lever in full advance position (toward magneto rim) and rotate crankshaft until P.T.O. piston approaches T.D.C. As soon as same specified piston position before top dead center as on mag. side is reached the timing light should fluctuate or tone signal level vary. If necessary to adjust proceed as follows:

With centrifugal lever in full advance position and piston at specified position, slacken lower breaker points set retaining screw then readjust breaker points gap until light fluctuates or tone signal level varies.

- If timing is too early decrease breaker points gap toward lower limit, i.e. 0.35 mm (.014"), then recheck timing.
- If timing is too late increase breaker points gap toward upper limit, i.e. 0.45 mm (.018"), then recheck timing.


- **NOTE:** Breaker points gap can change upon tightening. Always recheck after tightening.

EDGE GAP VERIFICATION

By following either of the procedures mentioned herein the edge gap will automatically be adjusted, however, if the edge gap is to be verified, proceed as follows:

- From timing marks, rotate magneto clockwise $\frac{1}{4}$ of a turn. Hold advance mechanism centrifugal weight in the open position (toward magneto rim) then slowly turn magneto back counter-clockwise until timing light fluctuates or until tone signal sound level varies.

At this point check the distance between pole shoe trailing edge and magnet ledge gap), with a strip of cardboard of appropriate width (Refer to Technical Data Section).



- **NOTE:** Repeat same operation for second cylinder.


If edge gap is more or less than specified the problem lies within engine internal components (crankshaft out of alignment, broken woodruff key, loose breaker cam, etc.). Corrective measures should be applied.

IGNITION TIMING ONE CYLINDER

Two methods are detailed in this section; the first using the timing marks stamped on the engine, the second using a T.D.C. gauge.

TIMING MARK PROCEDURE

1. Disconnect spark plug wire and remove spark plug.
2. Remove rewind starter assembly from engine then remove the starting pulley from magneto ring.
3. Rotate crankshaft until breaker points, visible through magneto ring opening, are fully open. Adjust points gap to $0.40 \text{ mm} \pm 0.05 \text{ mm}$ (.016" \pm .002") using a feeler gauge and screwdriver as illustrated.



NOTE: Breaker points gap can change upon tightening. Always recheck after tightening.

4. Disconnect junction block at engine then connect one lead of a timing light (flashlight type), or a tone timer to the black wire leading from engine. Connect other wire to fan cowl (ground).
5. Turn timing instrument ON and rotate magneto until timing marks align. Slacken the three (3) armature plate retaining screws then rotate armature plate until timing light fluctuates or tone signal sound level varies. Retighten retaining screw at this position.



Too early:
Turn Armature
Plate Clockwise




Too late:
Turn Armature
Plate Counter-Clockwise

NOTE: Ignition timing can change upon tightening. Always recheck after tightening.


TDC GAUGE PROCEDURE

1. Disconnect spark plug wire and remove spark plug.
2. Remove rewind starter assembly from engine then remove the starting pulley from magneto ring.
3. Rotate crankshaft until breaker points, visible through magneto ring opening, are fully opened. Adjust points gap to $0.40 \text{ mm} \pm 0.05 \text{ mm}$ (.016" \pm .002") using a feeler gauge and screwdriver as illustrated.

NOTE: Breaker points gap can change upon tightening. Always recheck after tightening.



4. Disconnect junction block at engine then connect one lead of a timing instrument (flashlight type or tone timer), to the black wire coming from engine. Connect other wire to fan cowl (ground).
5. Install and adjust T.D.C. gauge on engine as follows:
 - Rotate magneto clockwise until piston is just before top dead center.
 - With gauge in adaptor, adjust roller so that it is parallel with dial face. Tighten roller lock nut.



SECTION 04
SUB-SECTION 04 (IGNITION TIMING)

- Loosen adaptor lock nut then holding gauge with dial face toward magneto, screw adaptor in spark plug hole.
 - Slide gauge far enough into adaptor to obtain a reading then finger tighten adaptor lock nut.
 - Rotate magneto until piston is at Top Dead Center.
 - Unlock outer ring of dial and turn it until "0" on dial aligns with pointer.
 - Lock outer ring in position.
6. Slacken the three (3) armature plate retaining screws and turn timing instrument ON.
7. Rotate magneto counter-clockwise until specified piston position before top dead center is reached. Hold advance mechanism centrifugal lever in full advance position (toward magneto ring) then slowly rotate armature plate until timing light fluctuates or until tone signal sound level varies. Retighten retaining screws.


NOTE: Ignition timing can change upon tightening. Always recheck after tightening.

Edge Gap Verification

By following either of the two procedures herein mentioned the edge gap will automatically be adjusted, however, if the edge gap is to be verified, proceed as follows:

From timing marks, rotate magneto clockwise $\frac{1}{4}$ of a turn. Hold advance mechanism centrifugal weight in the open position (toward magneto rim) then slowly turn magneto back counter-clockwise until timing light fluctuates or until tone signal sound level increases.

At this point check the distance between pole shoe trailing edge and magnet ledge gap), with a strip of cardboard of appropriate width (Refer to Technical Data Section).



If edge gap is more or less than specified the problem lies within engine internal components (crankshaft out of alignment, broken woodruff key, loose breaker cam, etc.) corrective measures should be applied.

C.D. IGNITION


FOREWORD

On models equipped with a C.D. ignition system, plug firing is initiated by an electrical pulse. This pulse is released when a metal projection on the flywheel hub rotates past the pick-up coil. Therefore, timing must be performed while the engine is running.

A stroboscopic timing light such as Sun PTL 45, Snap-On MT215B, Bosch EFAW 169A, or a suitable equivalent, plus a 12 volt battery are needed.

PROCEDURE

Place skis tips against a wall. Use a support incorporating protective guard to block vehicle off the ground. (Approx. 15 cm (6") between track and floor). Remove rubber plug from upper crankcase half. Connect an operating timing light to magneto side spark plug wire.




◆ **WARNING:** Ensure that no one will pass behind the vehicle, even momentarily, while timing engine. Also, make sure that pulley guard is in position and that track is clear of tools, clothes, etc.

Start engine. The magneto ring / crankcase timing marks should coincide when full advance is obtained. Full advance is at 6,000 RPM.

▼ **CAUTION:** Running the engine unnecessarily will cause premature slider shoe wear.

If the timing marks do not coincide, remove rewind starter and starting pulley. Slacken off the two (2) Allen capscrews securing the armature plate. Rotate plate clockwise if timing is advanced, counter-clockwise if timing is retarded.



Once timing is correct on Mag. side, release throttle, apply the brake and turn off the ignition. Connect timing light to P.T.O. side spark plug wire. Start engine and check if P.T.O. timing coincides with Mag. side timing.

If timing does not coincide, install a T.D.C. gauge into P.T.O. spark plug hole. Scribe true marks on magneto rings at lower and upper timing limits B.T.D.C. (Refer to Technical Data). Repeat for other cylinder.

Position armature plate so that both cylinders fire within specified tolerance.

ELECTRICAL CHARTS INDEX

Year	Model	Chart No.	Headlamp Watt	Tail Light Watt
1974	Elan 250	1	60 / 60	8 / 23
1974	Elan 250E	3	35 / 35	8 / 23
1974	Elan 250 Deluxe, 294 SS	4	35 / 35	5 / 18
1974	Olympique 300	2	60 / 60	8 / 23
1974	Olympique 340, 400, 440	5	60 / 60	8 / 23
1974	Olympique 340E, 440E	6	35 / 35	8 / 23
1974	T'NT 300 SM	4	35 / 35	5 / 18
1974	T'NT 340SM, 440SM, Everest	7	60 / 60	5 / 18
1974	T'NT 340SE, 440SE	8	60 / 60	5 / 18
1974	T'NT F / A 340, 400, 440	9	60 / 60	5 / 18
1974	Nordic 640 ER	10	60 / 60	8 / 23
1974	Alpine 440 ER	11	35 / 35	8 / 23
1974	Alpine 640 ER	12	35 / 35	8 / 23
1974	Elite 440 ER	13	35 / 35	5 / 18
1975	Elan 250	3	60 / 60*	8 / 23
1975	Elan 250 Deluxe, 300 SS	20	35 / 35	5 / 18
1975	Olympique 300-340	15	60 / 60	5 / 18
1975	Olympique 300E - 340E	16	60 / 60	5 / 18
1975	T'NT 340-440	23	60 / 60	5 / 18
1975	T'NT 340E - 440E	22	60 / 60	5 / 18
1975	T'NT Everest 440	17	60 / 60	5 / 18
1975	T'NT Everest 440E	18	60 / 60	5 / 18
1975	T'NT F / A 340 - 440	19	60 / 60	5 / 18
1975	T'NT R / V 245	21	60 / 60	5 / 18
1975	Alpine 640 ER	14	60 / 60	8 / 23
1975	Elite 440 ER	13	35 / 35	5 / 18
1976	Elan 250 (up to se. no. 3013 0399 in).	3	60 / 60*	8 / 23
1976	Elan 250 (from se. no 3013 03999)	24	60 / 60	8 / 23
1976	Elan 250 Deluxe	20	45 / 45	5 / 18
1976	Olympique 300 single	25	60 / 60	5 / 18
1976	Olympique 300 - 340	15	60 / 60	5 / 18
1976	Olympique 300E - 340E	16	60 / 60	5 / 18
1976	Olympique Plus 440	26	60 / 60	5 / 18
1976	T'NT 340	23	60 / 60	5 / 18
1976	T'NT 340E	22	60 / 60	5 / 18
1976	Everest 440	23	60 / 60	5 / 18
1976	Everest 440E	22	60 / 60	5 / 18
1976	T'NT R / V 250-340	28	60 / 60	5 / 18
1976	Alpine 640 ER	27	60 / 60	5 / 18
1977	Elan 250	29	60 / 60	5 / 18
1977	Elan 250 Deluxe	30	45 / 45	5 / 18
1977	Olympique 300 Mono	25	60 / 60	5 / 18
1977	Olympique 300 Twin, 340, 440	31	60 / 60	5 / 18


SECTION 05

SUB-SECTION 01 (ELECTRICAL CHARTS)

Year	Model	Chart No.	Headlamp Watt	Tail Light Watt
1977	Olympique 340 E	32	60 / 60	5 / 18
1977	Everest 340	23	60 / 60	5 / 18
1977	Everest 340 E	33	60 / 60	5 / 18
1977	Everest 440	34	60 / 60	5 / 18
1977	Everest 440 E	35	60 / 60	5 / 18
1977	T'NT 340 & 440 F / A, 440 F / C	36	60 / 60	5 / 18
1977	RV 340	37	60 / 60	5 / 18
1977	Alpine 640 ER	38	60 / 60	5 / 18

* 35 / 35 W with electric start option

COLOR CODE					
BK	—	BLACK	GN	—	GREEN
WH	—	WHITE	GY	—	GREY
RD	—	RED	VI	—	VIOLET
BL	—	BLUE	OR	—	ORANGE
YL	—	YELLOW	BR	—	BROWN







Chart 2







Chart 4







Chart 6







Chart 8








Chart 10








Chart 13





Chart 14







Chart 16






Chart 18





Chart 19





Chart 20






Chart 22




Chart 23





Chart 24







Chart 26







Chart 30







Chart 32



† Optional on some models

Chart 33




Chart 34




Chart 35





Chart 36







Chart 38

BOMBARDIER IGNITION TESTER



GENERAL

The Bombardier ignition tester is an electrical energy measuring device capable of measuring the peak energy output of a coil.

The tester is of solid state construction and performs as a comparator. The correct value of energy output is indicated in each test and is then compared with the value taken from the engine being tested.

The energy output is verified by means of a 0-100 scale on the tester. The greater the energy output, the greater value indication on the scale. The indication is in the form of an incandescent lamp that lights when the scale knob is set at the position corresponding to the energy output.

The tester has two input ranges selected by a toggle switch. The LOW range is sensitive to AC or DC voltages from 0.5 to 27 volts. The HIGH range is sensitive to AC or DC voltages of from approximately 75 to 500 volts.

TEST CONDITION

All tests are performed on the vehicle at cranking speed. It would seem logical that removal of spark plugs would allow the engine to turn over faster, therefore raising the output level of the ignition system. It was found that vigorous cranking against compression causes the flywheel to snap over, raising the output higher than by cranking without compression. If output results are marginal, output can be measured with and without compression. **Test values listed are taken against compression.**

Always crank vigorously as in actual starting.

Read all instructions thoroughly and as you become familiar with this test instrument it will be possible to test a complete ignition system in a matter of minutes. Always proceed in the following order:

1. Connect tester P and N clip leads as illustrated.
2. Follow test procedure sequence.
3. After every test that lights the indicator lamp, reset the indicator circuit by depressing the reset button.

ANALYSIS OF TEST RESULTS

Indicator lamp lights at specific setting.

Output is as specified. Test results should repeat three times. If readings do not repeat, output is erratic and cause should be investigated (loose connections or components, etc.).

Indicator lamp lights at a lower setting.

This indicates that the output is less than that designed to operate the engine in a satisfactory manner. The engine may run at a lower setting, but be the subject to hard starting and misfire. Be certain that correct engine cranking conditions were met before condemning the ignition.

Indicator lamp does not light.

One component is defective. Proceed as instructed to find defective component.

Intermittent ignition problems

In dealing with intermittent problems there is no easy diagnosis. For example, problems that occur only at normal engine operating temperature have to be tested under similar conditions.

In most cases of temperature and / or vibration failure, only parts replacement can solve the problem as most of these failures return to normal when engine is not running.

Double trouble


There is always the possibility of more than one defective parts. If after a component has been replaced, the problem still persists, carefully repeat the complete test procedure to find the other defective part.

ANALYSER TEST AND MAINTENANCE

A test simulator is provided with each tester as a means to test the lamp, detector circuit, and batteries.


High scale test

a) Place switch in HIGH position. Plug the simulator into an electric outlet (117 VAC) for ten seconds.

 **CAUTION:** After charging, do not touch plug terminals while pressing test button. A mild shock will result.

b) Remove the simulator from the outlet, and connect the "P" and "N" leads from the tester to the simulator as indicated on the button of the simulator.

c) Set the tester dial to 50, or below. Depress the button of the simulator. The indicator lamp on the tester should light.

 **NOTE:** For each test performed by the simulator, it must be recharged.

Low scale test

a) Place switch in LOW position.

b) Set tester dial to 50, or below.

c) Connect **N** lead to negative terminal of 12 volt battery. Connect **P** lead to positive terminal of 12 volt battery; indicator lamp should light.

If lamp does not light, check tester batteries. If they are installed correctly and are good, check the clip leads for faulty connections. If no fault can be found, refer to the warranty statement for instructions for sending the tester back to Electro-Specialties, Inc.

Battery replacement


1. Remove the four (4) screws securing cover to case.
2. Carefully lift cover.
3. Replace batteries with size "C" Alkaline batteries. Be sure to observe polarity markings on battery holder or lamp will not light.
4. Install cover on case carefully being certain that no wires are pinched between cover and case. Secure cover.

 **NOTE:** Weak batteries will not impair tester operation or calibration. The light will grow dim.

The ignition tester may give false readings if the rivets on the back cover come in contact with metal.

Indicator knob alignment

Check indicator knob alignment by turning knob fully clockwise. The white mark on the knob must align with no. 100 on the scale. If the marks does not line up with the no. 100, loosen the knob set screw, line the mark on the knob with no. 100, and tighten the set screw. Re-check alignment.

 **NOTE:** If after adjustment, the knob is turned fully counter-clockwise and it does not exactly align with the 0, it is of no consequence.


TESTS INDEX

ROTAX ONE CYLINDER ENGINE BREAKER POINTS IGNITION	Test no. 1:	Ignition coil output to spark plug	p. 3
	Test no. 2:	Ignition generator coil output	p. 4
	Test no. 3:	Lighting coil output	p. 4
	Test no. 4:	Brake light coil output	p. 4
ROTAX TWO CYLINDER ENGINE BREAKER POINTS IGNITION	Test no. 5:	Ignition coil output to spark plug	p. 5
	Test no. 6:	Ignition generator coil output	p. 5
	Test no. 7:	Lighting coil output	p. 6
	Test no. 8:	Brake light coil output	p. 6
ROTAX TWO CYLINDER ENGINE CD IGNITION	Test no. 9:	C.D. box output to spark plug	P. 6
	Test no. 10:	Ignition generator coil output	p. 7
	Test no. 11:	Trigger coil output (all engine types except 640)	p. 7
	Test no. 12:	Trigger coil output (640 engine types)	p. 8
	Test no. 13:	Lighting coil output	p. 10

Test no. 1: Ignition coil output to spark plug

NOTE: To obtain accurate readings it is necessary to install a new correctly gapped spark plug. However, if test is performed on engine before spark plug is changed, a low or no tester reading could indicate a fouled or faulty spark plug. Replace spark plug by a new one and recheck.

1. Attach tester N lead over spark plug wire directly behind spark plug cap. Connect P lead to a good engine ground.



CAUTION: Never connect the tester lead directly to the inner metallic spark plug wire.

2. Set tester dial and switch as follows:

Engine type	Switch position	Dial	
		With suppressor cap	Without suppressor cap
247, 302	LOW	60	45

3. Turn ignition key to ON, disable kill button circuit, then crank engine.


A. Indicator lamp lights: Ignition output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistent output.

B. Indicator lamp does not light: Ignition coil output is low or spark plug is faulty if test no. 2 is positive.

WARNING: Lift rear of vehicle off the ground while performing this test as the engine may start.

Test no. 2: Ignition generator coil output

1. Disconnect blue and black wires from terminal (15) of ignition coil.
2. Attach tester P lead to blue and black wires previously disconnected. Connect tester N lead to a good engine ground.




3. Set tester dial and switch as follows:

Engine type	Switch position	Dial
247, 302	HIGH	75

4. Turn ignition key to ON position, disable kill button circuit then crank engine.
 - A. Indicator lamp lights: Coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.
 - B. Indicator lamp does not light: Coil output is below specifications. This could be caused by a faulty coil or breaker points. Check breaker points condition and adjustment, and correct as necessary. Repeat test. If lamp still does not light the coil is defective and should be replaced.

Test no. 3: Lighting coil output

1. Disconnect wiring harness junction block at engine.
2. Connect tester leads as illustrated using two (2) harness adaptors.




3. Set tester dial and switch as follows:

Engine type	Switch position	Dial
247, 302	LOW	85

4. With ignition key to OFF position, crank engine.
 - A. Indicator lamp lights: Lighting coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
 - B. Indicator lamp does not light: Lighting coil is defective.

Test no. 4: Brake light coil output

1. Disconnect wiring harness junction block at engine.
2. Connect tester leads as illustrated using two (2) harness adaptors.



3. Set tester dial and switch as follows:

Engine type	Switch position	Dial
247, 302	LOW	85

4. With ignition key to OFF position, crank engine.


A. Indicator lamp lights: Brake light coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.

B. Indicator lamp does not light: Brake light coil is defective.

Test no. 5: Ignition coil output to spark plug

NOTE: To obtain accurate readings it is necessary to install new, correctly gapped spark plugs. However, if test is performed on engine before spark plugs are changed, a low or no reading could indicate fouled or faulty spark plugs. Replace them by new ones and re-check.

1. Attach tester P lead over P.T.O. spark plug wire directly behind spark plug cap. Connect N lead to a good engine ground.



CAUTION: Never connect the tester lead directly to the inner metallic spark plug wire.

2. Set tester dial and switch as follows:

Engine type	Switch position	Dial	
		Without suppressor cap	With suppressor cap
248, 294, 305, 338, 343, 401, 402, 434, 440, 640, 346, 436	LOW	40	50

3. Turn ignition switch key to ON position, disable kill button circuit then crank engine.

A. Indicator lamp lights: Coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.

B. Indicator lamp does not light: Coil output is low or spark plug is faulty if test no. 6 is positive.


4. Repeat above procedure on other side.

WARNING: Lift rear of vehicle off the ground while performing this test as the engine may start.

Test no. 6: Ignition generator coil output

1. Disconnect blue / red and black wires from terminal (15) of P.T.O. side ignition coil. Disconnect the two blue wires from terminal (1) of magneto side ignition coil. Make sure that both connectors do not touch the engine (ground).

2. Connect tester P lead to blue / red and black wires previously disconnected. Connect N lead to a good engine ground.



3. Set tester switch and dial as follows:

Engine type	Year	Switch position	Dial
248, 294		HIGH	75
305, 343, 346, 436, 402, 440, 640	1975, 76, 77	HIGH	80
338, 401, 434		HIGH	70

4. Turn ignition key to ON position, disable cut-out button circuit then crank engine.

A. Indicator lamp lights: Generator coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.

SECTION 05


SUB-SECTION 03 (ELECTRICAL TESTS)

- B. Indicator lamp does not light:** Generator coil output is below specifications. This could be caused either by a faulty coil or breaker points.
5. Repeat test with other side (blue wires). If test indicates good on magneto side wire, but not on the other, suspect faulty breaker points. If test indicates no output on either side, suspect either faulty generator coil or breaker points.

Test no. 7: Lighting coil output

- NOTE:** In some engine types covered by this test an additional lighting coil is connected in parallel with the main lighting coil, in this case, the test will determine if the whole assembly is working right or not. If test result appears to be negative, the electrical resistance of each component must be checked separately. (Refer to Technical Data 08, 05-03).

1. Disconnect wiring harness junction block at engine.
2. Connect tester leads as illustrated using two (2) harness adaptors.



3. Set tester dial and switch as follows:


Engine type	Year	Switch position	Dial
248, 294		LOW	80
305, 343, 402, 440, 640, 346, 436	1975-76-77	LOW	85

4. With ignition key to OFF position crank engine.
A. Indicator lamp lights: Lighting coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
B. Indicator lamp does not light: Lighting coil is defective.

Test no. 8: Brake light coil output

- NOTE:** This test is applicable to engine types 338 & 401 (1974) and 434 (1974-75).

1. Disconnect wiring harness junction block at engine.
2. Connect tester leads as illustrated using two (2) harness adaptors.



3. Set tester dial and switch as follows:


Engine type	Year	Switch position	Dial
338, 401	1974	LOW	85
434	1974-75		

4. With ignition key to OFF position crank engine.
A. Indicator lamp lights: Brake light coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.
B. Indicator lamp does not light: Brake light coil is defective.

Test no. 9: CD box output to spark plug

- NOTE:** To obtain accurate readings it is necessary to install new, correctly gapped spark plugs. However, if test is performed on engine before spark plugs are changed, a low or no reading could indicate fouled or faulty spark plugs. Replace them by new ones and re-check.

1. Attach tester P lead over P.T.O. spark plug wire directly behind spark plug cap. Connect N lead to a good engine ground.



CAUTION: Never connect the tester lead directly to the inner metallic spark plug wire.

2. Set tester switch and dial as follows:

Engine type	Switch position	Dial	
		With suppressor cap	Without suppressor cap
245, 345, 346, 396, 436, 440, 640	LOW	40	20

3. Turn ignition switch key to ON position, disable kill button circuit then crank engine.

A. Indicator lamp lights: CD box output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.

B. Indicator lamp does not light: If ignition generator coil and trigger coil test (no. 10, 11, 12) are positive, CD box output is low or spark plug is faulty.


WARNING: Lift rear of vehicle off the ground while performing this test as the engine may start.

4. Repeat above procedure on other side.

Test no. 10: Ignition generator coil output

1. Disconnect wire connector from C.D.I. electronic box.

2. Using one (1) harness adaptor, connect tester P lead to red wire of connector removed from C.D.I. electronic box. Connect N test lead to ground (engine); do not use brown wire as ground.



3. Set tester switch and dial as follows:

Engine type	Switch position	Dial
2435, 345, 346, 396, 436, 440, 640	HIGH	55

4. Turn ignition key to ON position, disable cut-out button circuit then crank engine.

A. Indicator lamp lights: Charging coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.


B. Indicator lamp does not light: If trigger coil test (no. 11 or 12) is positive, the problem is a faulty ignition generator coil.

WARNING: Do not touch tester P lead clip while cranking the engine. Also make sure that tester P lead clip does not contact any metallic object.

Test no. 11: Trigger coil output (all engine types except 640)

1. Connect tester leads as follows:

- Connect tester P lead, as illustrated, to wire coming from P.T.D. side trigger at connector removed from C.D.I. electronic box. Use one (1) harness adaptor.
- Connect tester N lead to a good engine ground.



2. Set tester switch and dial as follows:

Engine type	Switch position	Dial
245, 345, 346, 396, 436, 440	LOW	60

3. Turn ignition key to ON position, disable cut-out button circuit then crank engine.

A. Indicator lamp lights: Trigger coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.

B. Indicator lamp does not light: The problem is a faulty trigger coil.


SECTION 06
SUB-SECTION 03 (ELECTRICAL TESTS)

○ **NOTE:** If not output is indicated on trigger coil, carefully inspect the trigger ground connection wire connected to C.D.I. electronic box retaining screw. Clean and tighten connection then repeat test.

4. Connect tester leads to opposite trigger as follows:
 - Connect tester **P** lead to wire leading from mag side trigger.
 - Leave tester **N** lead connected to a good engine ground.

Test no. 12: Trigger coil output (640 engine type)

1. Disconnect wire connector from C.D.I. electronic box, remove the C.D.I. electronic box from its bracket then disconnect the four (4) wires (violet, black / violet, black / yellow, violet / yellow) fitted with clear insulating sleeve from the timing box.




Connect tester leads as follows:

Connect tester **P** lead, as illustrated, to violet / yellow wire removed from timing box terminal marked Vio-Yel (plate).

○ **NOTE:** There are two (2) violet / yellow wires connected to the timing box; use the one with a clear plastic insulator.

- Connect tester **N** lead to black / yellow wire removed from timing box.



2. Set tester switch and dial as follows:

Engine type	Switch position	Dial
640	LOW	60

3. Turn ignition key to **ON** position, disable cut-out button circuit then crank engine.

A. Indicator lamp lights: Trigger coil output is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.

B. Indicator lamp does not light: The problem is a faulty trigger coil.


If above test indicates correct trigger coils output and ignition is unsatisfactory test timing box.

Timing box test

1. Connect tester **P** lead, as illustrated, to violet wire removed from timing box terminal marked Vio (plate).

○ **NOTE:** There are two violet wires connected to the timing box; use the one with a clear plastic insulator.

- Connect N lead to black / violet wire removed from timing box.



2. Turn ignition key to ON position, disable cut-out button circuit then crank engine.


A. Indicator lamp lights: Timing box is up to specifications. Repeat test at least three (3) times to verify reading and check for consistency.

B. Indicator lamp does not light: The problem is a faulty timing box.

Test no. 13: Lighting oil output

NOTE: In some engine types covered by this test an additional lighting coil is connected in parallel with the main lighting coil, in this case the test will determine if the whole assembly is working right or not. If test result appears to be negative, the electrical resistance of each component must be checked separately. (Refer to Technical Data 08, 05-02).

1. Disconnect wiring harness junction block at engine.
2. Connect tester leads as illustrated using two (2) harness adaptors.








3. Set tester dial and switch as follows:

Engine type	Switch position	Dial
245, 345, 346, 396, 436, 440, 640	LOW	85









4. With ignition key to OFF position, crank engine.







A. Indicator lamp lights: Lighting coil output is up to specifications. Repeat test at least three (3) times to verify reading and consistency.

B. Indicator lamp does not light: Lighting coil is defective.







ITEM	USE	APPLICABLE TO
<p data-bbox="185 457 358 512">Dial Indicator (T.D.C. gauge)</p> 	<p data-bbox="704 457 1122 485">Engine timing, to determine T.D.C.</p> 	<p data-bbox="1219 457 1414 485">All Engine types.</p>
<p data-bbox="180 877 310 905">Tone timer</p> 	<p data-bbox="704 877 943 905">Engine timing (static)</p>	<p data-bbox="1219 877 1398 905">All Engine types.</p>
<p data-bbox="175 1350 370 1413">Circuit Tester (continuity light)</p> 	<p data-bbox="699 1350 943 1413">Engine timing (static). Continuity tests.</p>	<p data-bbox="1219 1350 1398 1377">All Engine types.</p>
<p data-bbox="180 1623 488 1686">Magneto Ignition Analyser (Model D-10000)</p> 	<p data-bbox="699 1623 1105 1650">Engine electrical components tests.</p>	<p data-bbox="1219 1623 1398 1650">All Engine types.</p>

**SECTION 07
(TOOLS)**

<p>Bombardier Ignition Tester</p>  <p>A rectangular electronic device with a carrying handle on top. The front panel features a large circular dial with multiple segments, a power switch, and a small indicator light. The text 'BOMBARDIER' and 'IGNITION TESTER' is visible on the panel.</p>	<p>Engine electrical components tests.</p>	<p>All engine types.</p>
<p>Carburetor Leak Detector</p>  <p>A small, cylindrical tool with a pressure gauge on top and a hose-like attachment at the bottom.</p>	 <p>A detailed diagram showing the leak detector being used on a carburetor. Labels include 'Fuel outlet plug' at the top, 'LEAK DETECTOR' pointing to the tool's nozzle, and 'Fuel inlet' at the bottom.</p>	<p>All Tillotson carburetors.</p>
<p>Chain Breaking Tool</p>  <p>A mechanical tool with two long, parallel handles and a central mechanism consisting of several rollers and a handle for squeezing.</p>		<p>All types of chain.</p>
<p>Track Insert Installer</p>  <p>A tool with two long, thin handles and a curved, hook-like end.</p> <p>Heavy Duty</p>  <p>A rectangular metal block with a complex, notched shape and a threaded hole on one side.</p> <p>Insert Block</p>  <p>A U-shaped metal component with a central slot.</p>	 <p>A diagram showing the track insert installer being used to install a track insert. Labels include 'Track insert' pointing to the component being installed, 'Male (ig)' pointing to a part of the track, and 'Female (ig)' pointing to another part.</p>	<p>All types of track.</p>

<p>Link Plate Spring Lever</p> 		<p>All models with link plate springs.</p>
<p>Drive Pulley Retainer</p> 	<p>For indexation of governor cup.</p> 	<p>Square shaft drive pulley.</p>
<p>Drive Pulley Puller</p> 	<p>To remove drive pulley from crankshaft.</p> 	<p>Taper shaft engines.</p>

SECTION 07
(TOOLS)


<p>Bushing Pusher</p> 	<p>To install bushing in sliding half.</p> 	<p>High performance drive pulley.</p>
<p>Fan Holder</p> 		<p>Twin cylinders.</p>
<p>Fan Pulley Aligning Tool</p> 		<p>248-249-294 engine types.</p>

Starter Gear Puller




Twin cylinders
electric start engines.

Connecting Rod Holder














All single cylinder models,
370 engine type.

Cylinder Aligning Tool















Twin cylinders engine
types.

<p>Magneto Housing Holder.</p> 		<p>Single cylinder engine types.</p>
		<p>Twin cylinders engine types.</p>
	 <p>Puller</p>	<p>Twin cylinders engine types.</p>
<p>Bearing puller.</p> 	<p>To remove magneto ring from engine.</p>	<p>All engines.</p>

<p>Bearing Puller</p>  <p>A) Ring Screw B) Puller C) Ring for puller D) Ring half for ball bearing E) Ring half for roller bearing F) Puller Screw</p>		<p>All engine types.</p>
<p>Bearing Puller</p> 		<p>All engine types (old).</p>


SECTION 07
(TOOLS)

<p>Protection Cap</p> 	<p>Protect crankshaft end, when using bearing puller.</p> <p>Protective cap</p>   <p>Puller</p>	<p>All engine types.</p>
<p>Protection End Cap</p> 	<p>To protect crankshaft end, when using bearing puller.</p> 	<p>All taper shaft engine type.</p>
<p>Bearing Simulator</p> 	<p>When adjusting crankshaft play.</p>	<p>All engine types.</p>


<p>Oil Seal Sleeve</p> 	<p>To avoid oil seal damage during crankshaft installation.</p> 	<p>All single cylinder engine types and 370 type.</p>
<p>Oil Seal Pusher</p> 		<p>All single cylinder engine type and 370 type.</p>
<p>Rotary valve shaft puller</p> 	<p>To remove rotary valve shaft assembly from crankcase.</p> 	<p>RV engines.</p>

SECTION 07
(TOOLS)

Armature plate contact set
pivot pin remover (socket)




To remove contact set, pivot
pin from armature plate




All engine types using breaker
point type ignition.

TRACK TENSION SPECIFICATIONS (TORQUE REACTION SLIDE)




		1974	1975	1976	1977
OLYMPIQUE	340, 340E Plus (440) 440		10-13 mm (3/8 - 1/2 ")	10-13 mm (3/8 - 1/2 ") 10-13 mm (3/8 - 1/2 ")	10-13 mm (3/8 - 1/2 ") 10-13 mm (3/8 - 1/2 ")
EVEREST	340, 340E 440, 440E	19 mm (3/4 ")	19 mm (3/4 ")	19 mm (3/4 ")	19 mm (3/4 ") 19 mm (3/4 ")
T'NT F / C	340, 340E 440, 440E	19 mm (3/4 ") 19 mm (3/4 ")	19 mm (3/4 ") 19 mm (3/4 ")	19 mm (3/4 ")	
T'NT F / A	340, 440		19 mm (3/4 ")		
T'NT	340, 440				19 mm (3/4 ")
T'NT R / V	250 340		19 mm (3/4 ")	19 mm (3/4 ") 19 mm (3/4 ")	19 mm (3/4 ")

TRACK TENSION SPECIFICATIONS (BOGIE WHEEL SYSTEM)




		1974	1975	1976	1977
ELAN	250T, E	35 mm (1 3/8")			
	250	35 mm (1 3/8")	35 mm (1 3/8")	35 mm (1 3/8")	35 mm (1 3/8")
	250 Deluxe	35 mm (1 3/8")	35 mm (1 3/8")	35 mm (1 3/8")	35 mm (1 3/8")
OLYMPIQUE	300 Mono	57 mm (2 1/4")	57 mm (2 1/4")	57 mm (2 1/4")	57 mm (2 1/4")
	300 Twin			57 mm (2 1/4")	57 mm (2 1/4")
	340, 400, 440	57 mm (2 1/4")			
NORDIC	640ER	57 mm (2 1/4")			
ELITE	440ER	*57 mm (2 1/4")	*57 mm (2 1/4")		
ALPINE	440ER	*57 mm (2 1/4")			
	640ER	*57 mm (2 1/4")	*57 mm (2 1/4")	*57 mm (2 1/4")	*57 mm (2 1/4")

*Between top inside edge of track and center of bogie wheel set retaining bolt.




TRACK SPECIFICATIONS


CLEAT AND GUIDE ARRANGEMENT




TYPE 1: Narrow insert.




TYPE 2: Narrow insert with shoulder.




TYPE 3: Narrow guide with shoulder.




TYPE 4: Wide insert (large track hole).




TYPE 5: Wide guide (large track hole).



TYPE 6: Wide guide (large track hole).



TYPE 7: Internal drive metal link.



TYPE 8: Narrow guide with shoulder.

1974 TRACK SPECIFICATIONS

MODEL		TYPE OF TRACK
ELAN	250, 250E, 250 Deluxe 294SS	TYPE 1: Narrow insert. TYPE 2: Narrow insert with shoulder.
OLYMPIQUE	(Bogie) (Slide)	TYPE 1: Narrow insert. TYPE 2: Narrow insert with shoulder.
NORDIC	640ER	TYPE 4: Wide insert (large track hole).
T'NT	F / C 300, 340, 440 EVEREST 440 F / A 340, 400, 440	TYPE 6: Wide guide (large track hole). TYPE 5: Wide guide (large track hole). TYPE 3: Narrow guide with shoulder.
ELITE	440ER	TYPE 1: Narrow insert.
ALPINE	440ER, 640ER	TYPE 1: Narrow insert.

1975 TRACK SPECIFICATIONS

MODEL		TYPE OF TRACK
ELAN	250, 250 Deluxe 300SS	TYPE 1: Narrow insert. TYPE 2: Narrow insert with shoulder.
OLYMPIQUE	300, 300E Twin 340, 340E	TYPE 1: Narrow insert. TYPE 5: Wide guide (large track hole).
T'NT	F / C 340, 440 EVEREST 440 F / A 340, 440 R / V 245	TYPE 6: Wide guide (large track hole). TYPE 5: Wide guide (large track hole). TYPE 3: Narrow guide with shoulder. TYPE 7: Internal drive metal link.
ALPINE	640ER	TYPE 1: Narrow insert.
ELITE	440ER	TYPE 1: Narrow insert.

1976 TRACK SPECIFICATIONS

MODEL		TYPE OF TRACK
ELAN	250, 250 Deluxe	TYPE 1: Narrow insert.
OLYMPIQUE	300 Mono, Twin 340, 440 (Plus)	TYPE 1: Narrow insert. TYPE 5: Wide guide (large track hole).
T'NT F / C	340	TYPE 5: Wide guide (large track hole).
EVEREST	440	TYPE 5: Wide guide (large track hole).
T'NT R / V	250, 340	TYPE 8: Narrow guide with shoulder.
ALPINE	640ER	TYPE 1: Narrow insert.

1977 TRACK SPECIFICATIONS

MODEL		TYPE OF TRACK
ELAN	250, 250 Deluxe	TYPE 1: Narrow insert.
OLYMPIQUE	300 Mono, Twin 340 440	TYPE 1: Narrow insert. TYPE 5: Wide guide (large track hole). TYPE 6: Wide guide (large track hole).
EVEREST	340, 440	TYPE 5: Wide guide (large track hole).
T'NT	340, 440	TYPE 3: Narrow guide with shoulder.
R / V	340	TYPE 3: Narrow guide with shoulder.
ALPINE	640ER	TYPE 1: Narrow insert.

VEHICLE MODEL / DRIVE BELT NUMBER

	1974	WIDTH	1975	WIDTH	1976	WIDTH	1977	WIDTH
ELAN	250	30 mm (1 3/8")	570 0411	30 mm (1 3/8")	570 0411	30 mm (1 3/8")	570 0411	30 mm (1 3/8")
	250, 250 Twin	30 mm (1 3/8")						
	250 Deluxe	30 mm (1 3/8")	570 0411	30 mm (1 3/8")	570 0411	30 mm (1 3/8")	570 0411	30 mm (1 3/8")
	2945S	30 mm (1 3/8")						
	3005S	30 mm (1 3/8")	570 0411	30 mm (1 3/8")				
OLYMPIQUE	300 Twin	30 mm (1 3/8")	570 0414	30 mm (1 3/8")	414 2327	33 mm (1 3/8")	414 2327	33 mm (1 3/8")
	300E Twin	30 mm (1 3/8")	570 0414	30 mm (1 3/8")	414 2327	33 mm (1 3/8")		
	300 Mono				570 0411	30 mm (1 3/8")	570 0411	30 mm (1 3/8")
	340, 340E	30 mm (1 3/8")	570 0414	30 mm (1 3/8")	414 2327	33 mm (1 3/8")	414 2327	33 mm (1 3/8")
	400, 400E	30 mm (1 3/8")						
	440	30 mm (1 3/8")			414 2417	33 mm (1 3/8")	414 2327	33 mm (1 3/8")
	Plus (440)	30 mm (1 3/8")			570 0414	30 mm (1 3/8")	414 2327	33 mm (1 3/8")
T'NT	300SM	30 mm (1 3/8")						
	340SM, SE	30 mm (1 3/8")	570 0411	30 mm (1 3/8")				
	340, 340E	30 mm (1 3/8")	570 0414	30 mm (1 3/8")	414 2327	33 mm (1 3/8")		
T'NT	340 F / A							
	440 F / A							
	440 F / C							
EVEREST	340							
	440SL	30 mm (1 3/8")	570 0414	30 mm (1 3/8")			414 2327	33 mm (1 3/8")
	440						414 2417	33 mm (1 3/8")
	440E						414 2417	33 mm (1 3/8")
NORDIC	640ER	30 mm (1 3/8")						
ALPINE	440ER	30 mm (1 3/8")						
	640ER	30 mm (1 3/8")	570 0414	30 mm (1 3/8")	414 2277	33 mm (1 3/8")	414 2277	33 mm (1 3/8")
ELITE	440ER	30 mm (1 3/8")	570 0414	30 mm (1 3/8")				
T'NT F / A	340, 440	30 mm (1 3/8")	414 1884	30 mm (1 3/8")				
	400	30 mm (1 3/8")	414 1884	30 mm (1 3/8")				
R / V	250		414 2277	33 mm (1 3/8")	414 2277	33 mm (1 3/8")	414 2277	33 mm (1 3/8")
	340				414 2277	33 mm (1 3/8")	414 2277	33 mm (1 3/8")

1974 DRIVE PULLEY SPECIFICATIONS

		PULLEY TYPE	COUNTERWEIGHT IDENTIFICATION	SPRING NUMBER	SPRING COLOR	SPRING LENGTH mm (inch) ± 1.5 (0.060")	RETAINING BOLT TORQUE kg-m (ft-lbs)
ELAN	250, 250E	R.R.S.	E-4	504 2129	Bronze	81.3 (3.200)	*5.1-7.5 (37-54)
	250 Deluxe	R.R.S.	D-4	414 1623	Blue	77.7 (3.060)	*5.1-7.5 (37-54)
	294SS	R.S.S./L.C.)	B-1-K	414 1955	Yellow	100.1 (3.940)	*11.5-12.7 (83-92)
OLYMPIQUE	All models	P.L.	No hole	414 0013	Black	76.2 (3.0)	*5.1-7.5 (37-54)
TNT	300SM	R.S.S./L.C.)	B-1-K	414 1955	Yellow	100.1 (3.940)	*11.5-12.7 (83-92)
	340SM, SE	R.S.S./L.C.)	C-3-L	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)
	440SM, SE	R.S.S./L.C.)	C-4-L	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)
	EVEREST	R.S.S./L.C.)	C-4-L	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)
TNT F/A	340	H.P.	A-8	414 1572	White	101.6 (4.0)	**8-9.4 (58-68)
	400, 440	H.P.	A-9	414 1572	White	101.6 (4.0)	**8-9.4 (58-68)
NORDIC	640ER	R.S.S./L.C.)	C-8	414 1955	Pink	122.2 (4.810)	*11.5-12.7 (83-92)
ALPINE	440ER	P.L.	1 rivet, 1 washer	414 1587	Brown	77.7 (3.060)	*5.1-7.5 (37-54)
	640ER	P.L.	1 rivet, 3 washers	414 1587	Brown	77.7 (3.060)	*5.1-7.5 (37-54)
ELITE	440ER	R.S.S./L.C.)	C-8-A)	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)

H.P.: High Performance
P.L.: Pressure Lever
R.R.S.: Roller Round Shaft
R.S.S.: Roller Square Shaft
L.C.): Large Center

* Torque retaining bolt to specification then loosen and retorque to specific value.

** After bolt is torqued, start engine and repeatedly apply throttle and brake. Stop engine and retorque.

1975 DRIVE PULLEY SPECIFICATIONS

		PULLEY TYPE	COUNTERWEIGHT IDENTIFICATION	SPRING NUMBER	SPRING COLOR	SPRING LENGTH mm (inch) ± 1.5 (.063")	RETAINING BOLT TORQUE kg-m (ft-lbs)
ELAN	250	R.S.S.	E-4	504 2129	Bronze	81.3 (3.200)	*5.1- 7.5 (37-54)
	250 Deluxe, 300SS	R.S.S.(L.C.)	B-1-K	414 1966	Yellow	99.8 (3.930)	*11.5-12.7 (83-92)
OLYMPIQUE	300, 340	R.S.S.(L.C.)	C-3-L	414 2239	Yellow (cut)	88.9 (3.500)	*11.5-12.7 (83-92)
	340	R.S.S.(L.C.)	C-3-L	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)
TNT F / C	340	R.S.S.(L.C.)	C-3-L	414 2239	Yellow (cut)	88.9 (3.500)	*11.5-12.7 (83-92)
TNT F / C	440	R.S.S.(L.C.)	C-4-L	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)
TNT F / C	440	R.S.S.(L.C.)	C-4-L	414 2235	Black (cut)	104.6 (4.120)	*11.5-12.7 (83-92)
EVEREST	440	R.S.S.(L.C.)	C-4-L	414 2235	Black (cut)	104.6 (4.120)	*11.5-12.7 (83-92)
TNT F / A	340	H.P.	B	414 1572	White	101.6 (4.0)	**8- 9.4 (58-68)
	440	H.P.	A	414 1572	White	101.6 (4.0)	**8- 9.4 (58-68)
TNT	245 RV	▼ R.S.S.(S.C.)	A-3	414 2328	Gold	74.4 (2.930)	**8- 9.4 (58-68)
ALPINE 640ER	Series 000 3307	R.S.S.(L.C.)	C-8	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)
	Series 000 3308	R.S.S.(L.C.)	C-8	414 2235	Black (cut)	104.6 (4.120)	*11.5-12.7 (83-92)
ELITE	440ER	R.S.S.(L.C.)	C-8-M	414 1967	Light blue	118.9 (4.680)	*11.5-12.7 (83-92)

H.P.: High Performance
R.S.S.: Roller Round Shaft
R.S.S.: Roller Square Shaft
(S.C.): Small Center
(L.C.): Intermediate Center
(L.C.): Large Center

▼: Hub Plug with Wear pads

* Torque retaining bolt to specification then loosen and retorque to specific value.

** After bolt is torqued, start engine and repeatedly apply throttle and brake. Stop engine and retorque.

1976 DRIVE PULLEY SPECIFICATIONS

	PULLEY TYPE	COUNTERWEIGHT IDENTIFICATION	SPRING NUMBER	SPRING COLOR	SPRING LENGTH mm (inch) ± 1.5 (± 0.060")	RETAINING BOLT TORQUE kg-m (ft-lbs)
ELAN	250	E-4	504 2129	Bronze	81.3 (3.200)	*5.1- 7.5 (37-54)
	250 Deluxe	D-2	414 1623	Blue	77.7 (3.060)	*5.1- 7.5 (37-54)
OLYMPIQUE	300 Mono	Full flyweight	414 1587	Brown	77.7 (3.060)	*5.1- 7.5 (37-54)
	300 Twin, 340 Plus (440)	C-3-L	414 1967	Light blue	118.9 (4.680)	**8 - 9.4 (58-68)
		C-8-M	414 2235	Black (cut)	104.6 (4.120)	*11.5-12.7 (83-92)
T'NT	340	C-3-L	414 1967	Light blue	118.9 (4.680)	**8 - 9.4 (58-68)
EVEREST	440	C-4-L	414 1966	Pink	122.2 (4.810)	**8 - 9.4 (58-68)
T'NTR / V	250	A-2	414 2328	Gold	74.4 (2.930)	**8 - 9.4 (58-68)
	340	A-3	414 2610	Purple	73.6 (2.900)	**8 - 9.4 (58-68)
ALPINE	640ER	C-8 double	414 1966	Pink	122.2 (4.810)	*11.5-12.7 (83-92)

P.L.: Pressure Lever

R.R.S.: Roller Square Shaft

R.S.S.: Roller Square Shaft

(S.C.): Small Center

(I.C.): Intermediate Center

(Bearing): With Bearing

◆ Hub Plug with "Duralon" Bushing.

* Torque retaining bolt to specification then loosen and retorque to specific value

** After bolt is torqued, start engine and repeatedly apply throttle and brake. Stop engine and retorque.

1977 DRIVE PULLEY SPECIFICATIONS

	PULLEY TYPE	COUNTERWEIGHT IDENTIFICATION	SPRING NUMBER	SPRING COLOR	SPRING LENGTH mm (inch) ± 1.5 (0.060")	RETAINING BOLT TORQUE kg-m (ft-lbs)
ELAN	250	E-4	414 2580	Bronze	81.3 (3.200)	*5.1 - 7.5 (37-54)
	250 Deluxe	D-2	414 2581	Blue	77.7 (3.060)	*5.1 - 7.5 (37-54)
OLYMPIQUE	300 Mono	E-4	414 2581	Blue	77.7 (3.060)	*5.1 - 7.5 (37-54)
	300 Twin, 340	C-3-L	414 1967	Light blue	118.9 (4.680)	**8 - 9.4 (58-68)
	440	C-8-M	414 1967	Light blue	118.9 (4.680)	**8 - 9.4 (58-68)
EVEREST	340	C-3-L	414 1967	Light blue	118.9 (4.680)	**8 - 9.4 (58-68)
	440	C-4-L	414 1966	Pink	122.2 (4.810)	**8 - 9.4 (58-68)
TNT	340	C-4-L	414 1966	Yellow	100.1 (3.940)	**8 - 9.4 (58-68)
	440 Free Air	C-4-L ①	414 1967	Light blue	118.9 (4.680)	**8 - 9.4 (58-68)
RV	440 Fan Cooled	C-4-L	414 1966	Pink	122.2 (4.810)	**8 - 9.4 (58-68)
	340	A-3	414 2835	Red	88.9 (3.500)	**8 - 9.4 (58-68)
ALPINE	640ER	C-8 double	414 1966	Pink	122.2 (4.810)	*11.5-12.7 (83-92)

R.R.S.: Roller Round Shaft

R.S.S.: Roller Square Shaft

(Bearing): With Bearing

◆ Hub Plug with "Duralon" Bushing

● With "Duralon" Bushing

① With 4 std. washers no. 399-901-500.

* Torque retaining bolt to specification then loosen and retorque to specific value.

** After bolt is torqued, start engine and repeatedly apply throttle and brake. Stop engine and retorque.

WEAR PADS

WEAR PAD PART NO.	APPLICATION		VEHICLE MODEL
	INNER HALF PART NO.	SHAFT CLASSIFICATION	
504 2207 00	504 2217 00	Forged	'75 Elan 250 Deluxe and 300SS
504 2207 00	504 2211 00	Forged	'75 Alpine (1st series), '74 '75 T'NT 440, '74 Everest
504 2207 00	504 2204 00	Forged	'71 '75 T'NT 340
504 2277 00	504 2233 00	Machined	'75 Alpine (2nd series), '75 T'NT 440 and Everest
504 2277 00	504 2245 00	Machined	'75 T'NT 340 '75 Olympique 300 340
504 2251 00	504 2247 00	Machined	'75 T'NT R / V 245
504 2207 00	504 2279 00		'76 Alpine
504 2207 00	504 2233 00		'76 Olympique PLUS

DRIVEN PULLEY SPRING TENSION

		1974 kg ± 1 (lbs ± 2)	1975 kg ± 1 (lbs ± 2)	1976 kg ± 1 (lbs ± 2)	1977 kg ± 1 (lbs ± 2)
ELAN	All models	3.6 (8)	3.6 (8)	3.6 (8)	3.6 (8)
OLYMPIQUE	All models	3.6 (8)	3.6 (8)	3.6 (8)	3.6 (8)
NORDIC	640ER	3.6 (8)			
T'NT F / A		5.9 (13)	5.9 (13)		
T'NT F / C		3.6 (8)	5 (11)	3.6 (8)	
EVEREST		3.6 (8)	5 (11)	3.6 (8)	3.6 (8)
T'NT					3.6 (8)
RV	250 340		5.9 (13)	5.9 (13) 5.9 (13)	5.9 (13)
ALPINE	440ER 640ER	3.6 (8) 3.6 (8)	5.4 (12)	5.4 (12)	5.4 (12)
ELITE		3.6 (8)	3.6 (8)		

1974 75 PULLEY ALIGNMENT SPECIFICATIONS


		OFFSET *		DISTANCE **	
		(Simulator rod dia.)		(Between pulleys)	
		1974	1975	1974	1975
ELAN	250	14 mm (9/16")	14 mm (9/16")	47 mm (1 7/8")	47 mm (1 7/8")
	250E, 250T	14 mm (9/16")	14 mm (9/16")	47 mm (1 7/8")	
	250 Deluxe	14 mm (9/16")	14 mm (9/16")	47 mm (1 7/8")	38 mm (1 1/2")
	294SS, 300SS	13 mm (1/2")	13 mm (1/2")	38 mm (1 1/2")	
OLYMPIQUE	300 Mono, Twin 340, 400, 440	14 mm (9/16")	13 mm (1/2")	47 mm (1 7/8")	35 mm (1 3/8")
NORDIC	640ER	13 mm (1/2")		41 mm (1 5/8")	
EVEREST	440	13 mm (1/2")	13 mm (1/2")	35 mm (1 3/8")	35 mm (1 3/8")
T'NT F / C	300, 340, 440				
T'NT F / A	340, 400, 440	Self-adjusting	Self-adjusting	● 31 mm (1 1/4")	31 mm (1 1/4")
ALPINE	440ER	14 mm (9/16")		● 47 mm (1 7/8")	
	640ER		14 mm (9/16")		● 41 mm (1 5/8")
ELITE	440ER	14 mm (9/16")	14 mm (9/16")	● 38 mm (1 1/2")	● 38 mm (1 1/2")
RV	245		13 mm (1/2")		35 mm (1 3/8")

* Tolerance: ± 0.8 mm (± 1/32")

** Tolerance: ± 1.6 mm (± 1/16")

● Non-adjustable

1976 AND UP PULLEY ALIGNMENT SPECIFICATIONS



- Dimension "X" must never exceed dimension "Y".
- Dimension "Y" can exceed dimension "X" by 1.6 mm (1/16 ").

		DIMENSION X & Y (Offset)		NOMINAL DISTANCE (Between pulleys)	
		1976	1977	1976	1977
ELAN	250, 250 Deluxe	32-34 mm (1 9/32 - 1 1/32")	33-35 mm (1 5/16 - 1 3/8")	43-44 mm (1 1/16 - 1 3/8")	43-44 mm (1 1/16 - 1 3/8")
OLYMPIQUE	300 Mono	32-34 mm (1 9/32 - 1 1/32")	same	47 mm (1 7/8")	47 mm (1 7/8")
	300 Twin, 340	33-35 mm (1 5/16 - 1 3/8")	same	35 mm (1 3/8")	35 mm (1 3/8")
	Plus (440)	32-34 mm (1 9/32 - 1 1/32")		35 mm (1 3/8")	
	440				35 mm (1 3/8")
EVEREST	340		same		35 mm (1 3/8")
	440	33-35 mm (1 5/16 - 1 3/8")	same	35 mm (1 3/8")	
T'NT F / C	340	33-35 mm (1 5/16 - 1 3/8")		35 mm (1 3/8")	
T'NT	340, 440		same		35 mm (1 3/8")
RV	250	33-35 mm (1 5/16 - 1 3/8")		35 mm (1 3/8")	
	340				35 mm (1 3/8")
ALPINE	640ER	32-34 mm (1 9/32 - 1 1/32")	same	44 mm (1 3/4")	44 mm (1 3/4")

1974 SPROCKET AND CHAIN SPECIFICATIONS

		UPPER / LOWER	CHAIN PITCH
ELAN	250	10 / 25	½" single
	250E	10 / 25	½" single
	250T	14 / 35	⅝" double
	250 Deluxe	14 / 35	⅝" double
	294SS	15 / 34	⅝" double
OLYMPIQUE	300	15 / 35	⅝" double
	340	15 / 34	⅝" double
	340E	15 / 34	⅝" double
	400	16 / 34	⅝" double
	400E	16 / 34	⅝" double
	440	16 / 33	⅝" double
NORDIC	640ER	18 / 33	⅝" triple
T'NT	300SM	14 / 34	⅝" double
	340SM	15 / 34	⅝" double
	340SE	15 / 34	⅝" double
	440SM	19 / 38	⅝" triple
	440SE	19 / 38	⅝" triple
EVEREST	440SL	19 / 38	⅝" triple
T'NT F / A	340	*14-15-16 / 44	⅝" triple
	400	*15-16-17 / 44	⅝" triple
	440	*15-16-17 / 44	⅝" triple
ALPINE	440ER	17 / 46	⅝" triple
	640ER	17 / 38	⅝" triple
ELITE	440ER	17 / 46	⅝" triple

* Maximum engine revolutions 8300 RPM.

1975 76 SPROCKET AND CHAIN SPECIFICATIONS

		UPPER / LOWER		CHAIN PITCH	
		1975	1976	1975	1976
ELAN	250	10 / 25	10 / 25	½" single	½" single
	250 Deluxe	14 / 35	14 / 35	¾" double	¾" double
	300SS	15 / 34		¾" double	
OLYMPIQUE	300 Mono		15 / 35		¾" double
	300 Twin	14 / 35	16 / 35	¾" double	¾" double
	300E Twin	14 / 35	16 / 35	¾" double	¾" double
	340	15 / 34	17 / 34	¾" double	¾" double
	340E	15 / 34	17 / 34	¾" double	¾" double
	440 Plus		17 / 34		¾" double
T'NT	340	15 / 34	16 / 34	¾" double	¾" double
	340E	15 / 34	16 / 34	¾" double	¾" double
	440	19 / 38		¾" triple	
	440E	19 / 38		¾" triple	
EVEREST	440	19 / 38	21 / 38	¾" triple	¾" triple
	440E	19 / 38	21 / 38	¾" triple	¾" triple
T'NT F / A	340	15 / 44		¾" triple	
	440	16 / 44		¾" triple	
T'NT R / V	250	16 / 40	15 / 38	¾" double	¾" double
	340		18 / 38		¾" triple
ALPINE	640ER	17 / 38	17 / 34	¾" triple	¾" triple
ELITE	440ER	17 / 46		¾" triple	

1977 SPROCKET AND CHAIN SPECIFICATIONS

		UPPER / LOWER	CHAIN PITCH
ELAN	250	10 / 25	½ " single
	250 Deluxe	14 / 35	¾ " double
OLYMPIQUE	300 Mono	15 / 35	¾ " double
	300 Twin	16 / 35	¾ " double
	340	17 / 34	¾ " double
	440	20 / 34	¾ " triple
EVEREST	340	16 / 34	¾ " double
	440	21 / 38	¾ " triple
T'NT	340	15 / 34	¾ " double
	440 Free Air	18 / 38	¾ " triple
	440 Fan cooled	18 / 38	¾ " triple
RV	340	18 / 38	¾ " triple
ALPINE	640ER	17 / 38	¾ " triple

1974 STEERING SYSTEM TORQUE SPECIFICATIONS

	STEERING SYSTEM TYPE	HANDLE BAR RETAINING BOLT		STEERING ARM TO SKI LEG		TIE ROD END TO STEERING ARM	
		kg-m	(ft-lbs)	kg-m	(ft-lbs)	kg-m	(ft-lbs)
ELAN (All models)	1	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
OLYMPIQUE (All except 300 Mono) 300 Mono	2	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)
	2	3.8-4.8	(28-35)	6-7.6	(44-55)	2.5-3.2	(18-23)
NORDIC 640ER	3	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)
TNT F / C	4	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)
EVEREST	5	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)
TNT F / A	5	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)
ALPINE	6	3.8-4.8	(28-35)	2.5-3.2	(18-23)	*5.5-6.9	(40-50)
ELITE	7	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)

1975-1976 STEERING SYSTEM TORQUE SPECIFICATIONS

	STEERING SYSTEM TYPE	HANDLE BAR RETAINING BOLT		STEERING ARM TO SKI LEG		TIE ROD END TO STEERING ARM	
		kg-m	(ft-lbs)	kg-m	(ft-lbs)	kg-m	(ft-lbs)
ELAN (All models)	1	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
OLYMPIQUE (All models)	10	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
TNT F / C	4	3.8-4.8	(28-35)	2.5-3.2	(18-23)	2.5-3.2	(18-23)
EVEREST	9	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
F / A	9	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
RV	8	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
ALPINE	6	3.8-4.8	(28-35)	2.5-3.2	(18-23)	*5.5-6.9	(40-50)

* Steering arm ball bushing torque value.

1977 STEERING SYSTEM TORQUE SPECIFICATIONS

	STEERING SYSTEM TYPE	HANDLE BAR RETAINING BOLT		STEERING ARM TO SKI LEG		TIE ROD END TO STEERING ARM	
		kg-m	(ft-lbs)	kg-m	(ft-lbs)	kg-m	(ft-lbs)
ELAN	1	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
OLYMPIQUE T'NT EVEREST	10	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
RV	12	Welded		2.5-3.2	(18-23)	2.5-3.2	(18-23)
ALPINE	11	3.8-4.8	(28-35)	2.5-3.2	(18-23)	*5.5-6.9	(40-50)

* Steering arm ball bushing torque value.

1974 SKI SYSTEM TORQUE SPECIFICATIONS

	SKI SYSTEM TYPE	LEAF SPRING / SPRING COUPLER RETAINING BOLT		RUNNER SHOE		SPRING COUPLER TO SKI LEG
		kg-m	(ft-lbs)	kg-m	(ft-lbs)	
ELAN (All models except 294SS) 294SS	1	4.8-5.5	(35-40)	0.5-0.7	(4-5)	Tighten bolt, move ski by hand to check that it pivotes easily on ski-leg. Then tighten locking nut to 6-7.6 kg-m (44-55 ft-lbs).
	1			1.2-1.6	(9-12)	
OLYMPIQUE	2	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
NORDIC	5	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
T'NT F / C EVEREST F / A	3	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
ALPINE	4	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
ELITE	6	4.8-5.5	(35-40)	1.2-1.6	(9-12)	

1975-1976-1977 SKI SYSTEM TORQUE SPECIFICATIONS

	SKI SYSTEM TYPE	LEAF SPRING / SPRING COUPLER RETAINING BOLT		RUNNER SHOE		SPRING COUPLER TO SKI LEG
		kg-m	(ft-lbs)	kg-m	(ft-lbs)	
ELAN (All models except 300SS) 300SS 1975	7	4.8-5.5	(35-40)	0.5-0.7	(4-5)	Tighten bolt, move ski by hand to check that it pivotes easily on ski-leg. Then tighten locking nut to 6-7.6 kg-m (45-55 ft-lbs).
	7			1.2-1.6	(9-12)	
OLYMPIQUE	8	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
T'NT F / C EVEREST 1975-76 T'NT & EVEREST 1977	9	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
T'NT F / A 1975	10	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
T'NT RV	11	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
ELITE 1975	6	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
ALPINE 1975-76 1977	12	4.8-5.5	(35-40)	1.2-1.6	(9-12)	
	13	4.8-5.5	(35-40)	1.2-1.6	(9-12)	

TOLERANCE AND WEAR LIMIT

Year	Engine Type	Cylinder bore (nominal)			Piston to wall clearance		Ring End gap	Crankshaft End play
		std.	1st o.s.	2nd o.s.	Fitted tolerance	Wear limit		
1974	247	69.0 mm (2.7165")	69.5 mm (2.7362")	N.A.	0.065-0.100 mm (.0026-.0039")	0.165 mm (.0065")	0.25-1.60 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1974	302	76.0 mm (2.9921")	76.5 mm (3.0118")	77 mm (3.0315")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0076")	0.30-1.60 mm (.012-.063")	0.10-0.40 mm (.004-.016")
1975	247	69.0 mm (2.7165")	69.5 mm (2.7362")	N.A.	0.065-0.100 mm (.0026-.0039")	0.165 mm (.0065")	0.25-1.60 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1976	247	69.0 mm (2.7165")	69.5 mm (2.7362")	N.A.	0.065-0.100 mm (.0026-.0039")	0.165 mm (.0065")	0.25-1.60 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1976	302	76.0 mm (2.9921")	76.5 mm (3.0118")	77.0 mm (3.0315")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0076")	0.30-1.60 mm (.012-.063")	0.10-0.40 mm (.004-.016")
1977	247	69.0 mm (2.7165")	69.5 mm (2.7362")	N.A.	0.063-0.099 mm (.0025-.0039")	0.162 mm (.0064")	0.25-1.60 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1977	302	76.0 mm (2.9921")	76.5 mm (3.0118")	77.0 mm (3.0315")	0.078-0.114 mm (.0031-.0045")	0.198 mm (.0078")	0.25-1.60 mm (.010-.063")	0.10-0.40 mm (.004-.016")

Year	Engine type	Cyl. bore nominal dimension		- Piston to wall clearance		Ring end-gap	Crankshaft end-play
		Standard	Oversize	Fitted tolerance	Wear limit		
1974	248	54.0 mm (2.1260")	54.5 mm (2.1457")	0.050-0.085 mm (.0020-.0034")	0.135 mm (.0054")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1974	294	57.0 mm (2.2441")	57.5 mm (2.2638")	0.050-0.085 mm (.0020-.0034")	0.135 mm (.0054")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1974	338	59.5 mm (2.3425")	60.0 mm (2.3622")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0076")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1974	343	59.5 mm (2.3425")	60.0 mm (2.3622")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0076")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1974	346	59.5 mm (2.3425")	59.75 mm (2.3524")	0.100-0.135 mm (.0039-.0053")	0.235 mm (.0092")	0.20-1.60 mm (.008-.063")	N.A.
1974	396	64.5 mm (2.5394")	64.75 mm (2.5492")	0.090-0.125 mm (.0035-.0049")	0.215 mm (.0084")	0.25-1.60 mm (.010-.063")	N.A.
1974	401	64.5 mm (2.5394")	65.0 mm (2.5591")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0076")	0.25-1.60 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1974	434	67.5 mm (2.6575")	68.0 mm (2.6772")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0076")	0.25-1.60 mm (.010-.063")	N.A.
1974	436	67.5 mm (2.6575")	67.75 mm (2.6873")	0.110-0.145 mm (.0043-.0057")	0.255 mm (.010")	0.25-1.60 mm (.010-.063")	N.A.
1974	440	67.5 mm (2.6575")	N.A.	0.063-0.153 mm (.0021-.006")	0.216 mm (.0086")	0.25-1.60 mm (.010-.063")	N.A.
1974	640	76.0 mm (2.9921")	76.5 mm (3.0118")	0.090-0.125 mm (.0043-.0057")	0.215 mm (.0084")	0.30-1.60 mm (.012-.063")	0.10-0.40 mm (.004-.016")

N.A.: Not applicable

TOLERANCE AND WEAR LIMIT (TWO CYLINDER ENGINE)

Year	Engine Type	Cyl. bore nominal dimension		Piston to wall clearance		Ring end-gap	Crankshaft end-play
		Standard	Overize	Fitted tolerance	Wear limit		
1975	245	54.0 mm (2.1260")	54.25 mm (2.1358")	0.070-0.105 mm (.0028-.0041")	0.175 mm (.0069")	0.20-0.50 mm (.008-.020")	0.10-0.40 mm (.004-.016")
1975	248	54.0 mm (2.1260")	54.5 mm (2.1457")	0.050-0.085 mm (.0020-.0033")	0.135 mm (.0053")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1975	294	57.0 mm (2.2441")	57.5 mm (2.2638")	0.050-0.085 mm (.0020-.0033")	0.135 mm (.0053")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1975	305	55.5 mm (2.1850")	56.0 mm (2.2047")	0.050-0.085 mm (.0020-.0033")	0.135 mm (.0053")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1975	343	59.5 mm (2.3425")	60.0 mm (2.3622")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0077")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1975	346	59.5 mm (2.3425")	59.75 mm (2.3524")	0.100-0.135 mm (.0039-.0053")	0.235 mm (.0093")	0.20-1.60 mm (.008-.063")	N.A.
1975	434	67.5 mm (2.6575")	68.0 mm (2.6772")	0.090-0.115 mm (.0031-.0045")	0.195 mm (.0077")	0.25-1.60 mm (.010-.063")	N.A.
1975	436	67.5 mm (2.6575")	67.75 mm (2.6673")	0.090-0.125 mm (.0035-.0049")	0.215 mm (.0085")	0.25-1.60 mm (.010-.063")	N.A.
1975	440	67.5 mm (2.6575")	N.A.	0.063-0.153 mm (.0025-.006")	0.216 mm (.0086")	0.25-1.60 mm (.010-.063")	N.A.
1975	640	76.0 mm (2.9921")	76.5 mm (3.0118")	0.090-0.110 mm (.0035-.0043")	0.215 mm (.0085")	0.30-1.60 mm (.012-.063")	0.10-0.40 mm (.004-.016")
1976	245	54.0 mm (2.1260")	54.25 mm (2.1358")	0.070-0.105 mm (.0028-.0041")	0.175 mm (.0069")	0.20-0.50 mm (.008-.020")	N.A.
1976	248	54.0 mm (2.1260")	54.5 mm (2.1457")	0.050-0.085 mm (.0020-.0033")	0.135 mm (.0053")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1976	305	55.5 mm (2.1850")	56.0 mm (2.2047")	0.070-0.105 mm (.0028-.0041")	0.175 mm (.0069")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1976	343	59.5 mm (2.3425")	60.0 mm (2.3622")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0077")	0.20-1.60 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1976	345	63.0 mm (2.4803")	63.25 mm (2.4902")	0.050-0.085 mm (.0020-.0033")	0.135 mm (.0053")	0.20-0.50 mm (.008-.020")	N.A.
1976	434	67.5 mm (2.6575")	68.0 mm (2.6772")	0.080-0.115 mm (.0031-.0045")	0.195 mm (.0077")	0.25-1.60 mm (.010-.063")	N.A.
1976	440	67.5 mm (2.6575")	N.A.	0.033-0.153 mm (.0013-.006")	0.216 mm (.0086")	0.25-1.60 mm (.010-.063")	N.A.
1976	640	76.0 mm (2.9921")	76.5 mm (3.0118")	0.070-0.105 mm (.0028-.0041")	0.175 mm (.0069")	0.30-1.60 mm (.012-.063")	0.10-0.40 mm (.004-.016")




N.A.: Not applicable

TOI ERANCE AND WEAR LIMIT (TWO CYLINDER ENGINE)

Year	Engine Type	Cyl. bore nominal dimension		Piston to wall clearance		Ring end-gap	Crankshaft end-play
		Standard	Oversize	Fitted tolerance	Wear limit		
1977	248	54.0 mm (2.1259")	54.5 mm (2.1456")	0.048-0.083 mm (.0019-.0033")	0.132 mm (.0052")	0.20-1.80 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1977	305	55.5 mm (2.1850")	56.0 mm (2.2047")	0.068-0.104 mm (.0027-.0041")	0.173 mm (.0068")	0.20-1.80 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1977	343	59.5 mm (2.3425")	60.0 mm (2.3622")	0.078-0.114 mm (.0031-.0045")	0.198 mm (.0078")	0.20-1.80 mm (.008-.063")	0.10-0.40 mm (.004-.016")
1977	345	63.0 mm (2.4803")	63.25 mm (2.4901")	0.048-0.063 mm (.0019-.0033")	0.132 mm (.0052")	0.20-0.51 mm (.008-.020")	N.A.
1977	346	59.5 mm (2.3425")	59.75 mm (2.3524")	0.099-0.134 mm (.0039-.0053")	0.233 mm (.0092")	0.20-1.80 mm (.008-.063")	N.A.
1977	436	67.5 mm (2.6574")	67.75 mm (2.6673")	0.069-0.124 mm (.0035-.0049")	0.213 mm (.0084")	0.25-1.80 mm (.010-.063")	N.A.
1977	440*	67.5 mm (2.6574")	68.0 mm (2.6771")	0.068-0.114 mm (.0027-.0045")	0.183 mm (.0072")	0.25-1.80 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1977	440**	67.5 mm (2.6574")	N.A.	0.078 mm (.0031")	0.156 mm (.0062")	0.25-1.80 mm (.010-.063")	0.10-0.40 mm (.004-.016")
1977	640	76.0 mm (2.9921")	76.5 mm (3.0118")	0.068-0.104 mm (.0027-.0041")	0.173 mm (.0068")	0.30-1.80 mm (.012-.063")	0.10-0.40 mm (.004-.016")

N.A.: Not applicable
 * Cast iron sleeve cylinder
 ** Nikasil coated cylinder




1974 IGNITION TIMING SPECIFICATIONS

Engine Type	Ignition Type	Direct measurement B.T.D.C. 	Indirect measurement B.T.D.C. 	Edge gap 
247	BK PT	3.98 mm ± 0.25 (.157" ± .010)	N.A.	6.5 mm ± 1.5 (.260" ± .060)
248	BK PT	2.22 mm ± 0.25 (.087" ± .010)	2.29 mm ± 0.25 (.090" ± .010)	9.0 mm ± 2.0 (.354" ± .080)
294	BK PT	2.39 mm ± 0.25 (.094" ± .010)	2.49 mm ± 0.30 (.098" ± .012)	9.0 mm ± 2.0 (.354" ± .080)
302	BK PT	3.98 mm ± 0.25 (.157" ± .010)	5.79 mm ± 0.41 (.228" ± .016)	6.5 mm ± 1.5 (.260" ± .060)
338	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.62 mm ± 0.27 (.143" ± .011)	6.5 mm ± 1.5 (.260" ± .060)
343	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.73 mm ± 0.30 (.147" ± .012)	6.5 mm ± 1.5 (.260" ± .060)
346	CD	2.07 mm ± 0.25 (.081" ± .010)	N.A.	N.A.
396	CD	2.07 mm ± 0.25 (.081" ± .010)	N.A.	N.A.
401	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.73 mm ± 0.30 (.147" ± .012)	6.5 mm ± 1.5 (.260" ± .060)
434	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.5 mm ± 1.5 (.260" ± .060)
436	CD	2.07 mm ± 0.25 (.081" ± .010)	N.A.	N.A.
440	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.5 mm ± 1.5 (.260" ± .060)
640	CD	3.35 mm ± 0.25 (.132" ± .010)	3.48 mm ± 0.25 (.137" ± .010)	N.A.
640	BK PT	3.95 mm ± 0.25 (.156" ± .010)	4.11 mm ± 0.25 (.162" ± .010)	6.5 mm ± 1.5 (.260" ± .060)

N.A.: Not applicable






1975 IGNITION TIMING SPECIFICATIONS

Engine Type	Ignition Type	Direct measurement B.T.D.C. 	Indirect measurement B.T.D.C. 	Edge gap 
245	CD	1.20 mm ± 0.25 (.047" ± .010)	N.A.	N.A.
247	BK PT	3.98 mm ± 0.25 (.157" ± .010)	N.A.	6.5 mm ± 1.5 (.260" ± .060)
248	BK PT	2.22 mm ± 0.25 (.087" ± .010)	2.29 mm ± 0.25 (.090" ± .010)	9.0 mm ± 2.0 (.276" ± .060)
294	BK PT	2.39 mm ± 0.25 (.094" ± .010)	2.49 mm ± 0.30 (.098" ± .012)	9.0 mm ± 2.0 (.276" ± .060)
305	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.73 mm ± 0.30 (.147" ± .012)	6.5 mm ± 1.5 (.260" ± .060)
343	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.73 mm ± 0.30 (.147" ± .012)	6.5 mm ± 1.5 (.260" ± .060)
346	CD	2.07 mm ± 0.25 (.081" ± .010)	N.A.	N.A.
434	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.5 mm ± 1.5 (.260" ± .060)
436	CD	2.07 mm ± 0.25 (.081" ± .010)	N.A.	N.A.
440	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.5 mm ± 1.5 (.260" ± .060)
440	CD	2.07 mm ± 0.25 (.081" ± .010)	2.21 mm ± 0.25 (.087" ± .010)	N.A.
640	BK PT	3.95 mm ± 0.25 (.156" ± .010)	4.11 mm ± 0.25 (.162" ± .010)	6.5 mm ± 1.5 (.260" ± .060)




N.A.: Not applicable

1976 IGNITION TIMING SPECIFICATIONS

Engine Type	Ignition Type	Direct measurement B.T.D.C. 	Indirect measurement B.T.D.C. 	Edge gap 
245	CD	1.15 mm ± 0.25 (.045" ± .010)	N.A.	N.A.
247	BK PT	3.96 mm ± 0.25 (.157" ± .010)	N.A.	6.5 mm ± 1.5 (.260" ± .060)
248	BK PT	2.22 mm ± 0.25 (.087" ± .010)	2.29 mm ± 0.25 (.090" ± .010)	9.0 mm ± 2.0 (.354" ± .079)
302	BK PT	3.96 mm ± 0.25 (.157" ± .010)	N.A.	6.5 mm ± 1.5 (.260" ± .060)
305	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.73 mm ± 0.30 (.147" ± .012)	6.5 mm ± 1.5 (.260" ± .060)
343	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.73 mm ± 0.30 (.147" ± .012)	6.5 mm ± 1.5 (.260" ± .060)
345	CD	1.0 mm ± 0.25 (.039" ± .010)	N.A.	N.A.
434	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.5 mm ± 1.5 (.260" ± .060)
440	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.5 mm ± 1.5 (.260" ± .060)
640	BK PT	3.95 mm ± 0.25 (.156" ± .010)	4.11 mm ± 0.25 (.162" ± .010)	6.5 mm ± 1.5 (.260" ± .060)

N.A.: Not applicable.

1977 IGNITION TIMING SPECIFICATIONS

Engine Type	Ignition Type	Direct measurement B.T.D.C. 	Indirect measurement B.T.D.C. 	Edge gap 
247	BK PT	3.98 mm ± 0.25 (.157" ± .010)	N.A.	6.6 mm ± 1.5 (.260" ± .060)
248	BK PT	2.22 mm ± 0.25 (.087" ± .010)	2.29 mm ± 0.25 (.090" ± .010)	9.0 mm ± 2.0 (0.354" ± .079)
302	BK PT	3.98 mm ± 0.25 (.157" ± .010)	N.A.	6.6 mm ± 1.5 (.260" ± .060)
305	BK PT	① 3.07 mm ± 0.25 (.121" ± .010)	① 3.73 mm ± 0.30 (.147" ± .012)	6.6 mm ± 1.5 (.260" ± .060)
343	BK PT	② 3.07 mm ± 0.25 (.121" ± .010)	② 3.73 mm ± 0.30 (.147" ± .012)	6.6 mm ± 1.5 (.260" ± .060)
345	CD	1.0 mm ± 0.25 (.039" ± .010)	N.A.	N.A.
346	BK PT	2.52 mm ± 0.25 (.100" ± .010)	N.A.	6.6 mm ± 1.5 (.260" ± .060)
436	BK PT	2.52 mm ± 0.25 (.100" ± .010)	N.A.	6.6 mm ± 1.5 (.260" ± .060)
440	BK PT	3.07 mm ± 0.25 (.121" ± .010)	3.30 mm ± 0.25 (.130" ± .010)	6.6 mm ± 1.5 (.260" ± .060)
640	BK PT	3.95 mm ± 0.25 (.156" ± .010)	4.11 mm ± 0.25 (.162" ± .010)	6.6 mm ± 1.5 (.260" ± .060)

N.A.: Not applicable

- ① From engine serial No. 2 852 346 and up, use 2.11 mm (.083") for direct timing and 2.46 mm (.097") for indirect timing.
- ② From engine serial No. 2 930 685 and up, use 2.11 mm (.083") for direct timing and 2.46 mm (.097") for indirect timing.


CARBURETOR SPECIFICATIONS

YEAR	MODEL	ENGINE TYPE	CARBURETOR	MAIN FUEL JET DIA.	LOW SPEED ADJ. + 1/8 - 0	HIGH SPEED ADJ. + 1/8 - 0	IDLE SPEED R.P.M.
1974	ELAN 250	247	HR-133-A	.042"	1/2	fixed	1800-2200
1974	ELAN 250 2 cyl.	248	HR-155-A	.044"	1	fixed	1800-2200
1974	ELAN 250DL	248	HR-155-A	.044"	1	fixed	1800-2200
1974	ELAN 294SS	294	HR-161-A	.051"	1/2	fixed	1800-2200
1974	OLYMPIQUE 300	302	HR-132-A	-	1/2	1	1800-2200
1974	OLYMPIQUE 340	338	HR-131-A	.050"	1/2	fixed	1800-2200
1974	OLYMPIQUE 400	401	HR-134-A	.052"	1/2	fixed	1800-2200
1974	OLYMPIQUE 440	434	HR-135-A	.045"	1/2	fixed	1800-2200
1974	T'NT 300	294	HR-164-A	-	1	1	1800-2200
1974	T'NT 340	343	HD-134-A	-	1	1	1800-2200
1974	T'NT 440	440	HD-138-A	-	1	1	1800-2200
1974	EVEREST 440	440	HD-138-A	-	1	1	1800-2200
1974	NORDIC 640	640	HD-133-A	.067"	1	fixed	1800-2200
1974	ALPINE 440	434	HD-108-A	.054"	1/2	fixed	1800-2200
1974	ALPINE 640	640	HD-124-A	.073"	1/2	fixed	1800-2200
1974	ELITE 440	434	HD-140-A	.058"	1	fixed	1800-2200
1974	T'NT 340 F / A	346	2 x HR-149-A	-	1	1 1/2	1800-2200
1974	T'NT 400 F / A	396	2 x HD-123-A	-	1	1/2	1800-2200
1974	T'NT 440 F / A	436	2 x HRM-3A	-	1	1 1/2	1800-2200
1975	ELAN 250	247	HR-133-A	.042"	1/2	fixed	1800-2000
1975	ELAN 250 Deluxe	248	HR-165-A	.044"	1	fixed	1800-2000
1975	ELAN 300SS	294	HR-166-A	.051"	1/2	fixed	1800-2000
1975	OLYMPIQUE 300, 300E	306	HR-169-A	.051"	1	fixed	1500-1800
1975	OLYMPIQUE 340, 340E	343	HR-170-A	.054"	1	fixed	1500-1800
1975	T'NT 340, 340E	343	HD-134-A	-	1	1	1800-2200
1975	T'NT 440, 440E	440	HD-138-A	-	1	1	1800-2200
1975	EVEREST 440, 440E	440	HD-138-A	-	1	1	1800-2200
1975	T'NT F / A 340	346	2 x HR-168-A	-	1	1 1/2	1800-2000
1975	T'NT F / A 440	436	2 x HRM-5-A	-	1	1	1800-2000
1975	T'NT F / A 245 R / V	245	2 x VM-34-72	.260	1	fixed	3000
1975	ALPINE 640ER	640	HD-142-A	.060"	1	fixed or 1	1500-1800
1975	ELITE 440ER	434	HD-140-A	.058"	1	fixed	1800-2200

CARBURETOR SPECIFICATIONS

YEAR	MODEL	ENGINE TYPE	CARBURETOR	MAIN FUEL JET DIA.	LOW SPEED ADJ. + ¼ - 0	HIGH SPEED ADJ. + ¼ - 0	IDLE SPEED R.P.M.
1976	ELAN 250	247	HR-173-A	.046"	1	fixed	1500-1800
1976	ELAN 250SS	248	HR-172-A	.042"	1	fixed	1800-2200
1976	OLYMPIQUE 300 Mono	302	HR-174-A	.045"	1	fixed	1200-1500
1976	OLYMPIQUE 300 300E, Twin	305	HR-169-A	.051"	1	fixed	1500-1800
1976	OLYMPIQUE 340, 340E	343	HR-170-B	.054"	1	fixed	1500-1800
1976	OLYMPIQUE Plus 440	434	HR-176-A	.049"	1	fixed	1500-1800
1976	T'NT 340, 340E	343	HD-148-A	-	1	1	1500-1800
1976	T'NT EVEREST 440, 440E	440	HD-147-A	-	1	1	1500-1800
1976	T'NTR / V 250	245	2 x VM 34-93	no. 300	1	fixed	3000
1976	T'NTR / V 340	345	2 x VM 34-94	no. 320	1	fixed	2500
1976	ALPINE 640ER	640	HRM-7-A	-	1 ½	1	1500-1800
1977	ELAN 250	247	HR-173-A	.046"	1	fixed	1500-1800
1977	ELAN 250 Deluxe	248	HR-172-A	.042"	1	fixed	1800-2200
1977	OLYMPIQUE 300 Mono	302	HR-174-A	.045"	1	fixed	1200-1500
1977	OLYMPIQUE 300 Twin	305	VM 30-90	no. 280	1 ½ ± 0	fixed	1500-1800
1977	OLYMPIQUE 340	343	VM 30-91	no. 260	1 ½ ± 0	fixed	1500-1800
1977	OLYMPIQUE 440	440	VM 32-113	no. 290	1 ½ ± 0	fixed	1500-1800
1977	EVEREST 340	343	HD-148-A	-	1	1	1500-1800
			OPTIONAL VM 30-98	no. 250	1 ½ ± 0	fixed	1500-1800
1977	EVEREST 440	440	VM 34-110	no. 340	1 ½ ± 0	fixed	1500-1800
1977	T'NT 340	345	VM 34-118	no. 300	1 ± 0	fixed	1800-2000
1977	T'NT 440	436	VM 36-53	no. 350	1 ± 0	fixed	1800-2000
1977	T'NT 440	440	VM 34-110	no. 340	1 ½ ± 0	fixed	1500-1800
1977	RV 340	345	2 x VM 34-135	no. 320	1 ± 0	fixed	3000-3200
1977	ALPINE 640ER	640	HRM-7-A	-	1 ½	1	1500-1800

NOZZLE CHECK VALVE INSTALLATION POSITION



NOZZLE CHECK VALVE PRESS DEPTH SPECIFICATIONS

MODEL	Main Nozzle / Discharge Tube	Main Nozzle	Intermediate Nozzle
HD-108-A HD-134-A HD-123-A HD-148-A HD-140-A HD-142-A	Not applicable	Nozzle shoulder flush with well floor	Not applicable
HD-124-A HD-133-A	.343" *	Not applicable	Not applicable
HD-138-A HD-147-A	.343" *	Not applicable	.156"

* Measurement taken between lowest point of nozzle and bottom of carburetor body.

All measurements \pm .005"

MIKUNI CARBURETOR SPECIFICATIONS

CARBURETOR	MAIN JET (Production)	JET NEEDLE*	NEEDLE JET	CUT AWAY	PILOT JET	AIR SCREW
VM 34-72	260	6DH4-2	P-4 (159)	2.5	35	1 turn
VM 34-93	300	6DH4-2	P-0 (159)	1.5	35	1 turn
VM 34-94	320	6DH4-2	P-2 (159)	1.5	30	1 turn
VM 30-90	260	6DH2-3	P-6 (159)	1.5	25	1½ turn
VM 30-91	260	6DH2-3	Q-0 (159)	2.0	25	-1½ turn
VM 30-98	250	6F9-3	Q-2 (159)	3.5	35	1½ turn
VM 34-110	340	6F9-3	P-2 (159)	1.5	20	1½ turn
VM 34-118	300	6F9-3	Q-2 (159)	3.5	35	1 turn
VM 32-113	290	6F9-4	Q-2 (159)	3.5	35	1½ turn
VM 36-53	350	6I1-2	P-2 (159)	3.5	40	1 turn
VM 34-135	320	6DH2-4	P-0 (159)	1.5	30	1 turn

*6DH4, -3 indicates specific slot of the needle from top.

1975 RV 250 MAIN JET APPLICATION CHART

Meters (Feet) ALTITUDE	TEMPERATURE ° C (° F)							
	-45° C (-50)	-35° C (-30)	-25° C (-10)	-15° C (10)	0° C (30)	10° C (50)	20° C (70)	30° C (90)
0 Sea level	300	290	280	270	260	250	240	230
600 m (2,000)	290	280	270	260	250	240	230	220
1200 m (4,000)	270	260	250	240	230	220	210	200
1800 m (6,000)	260	250	240	230	220	210	200	190
2400 m (8,000)	240	230	220	210	200	190	180	170
3,000 m (10,000)	230	220	210	200	190	180	170	160

CAUTION: These adjustments are guideline only, specific adjustments vary with temperature, altitude, atmospheric pressure and humidity. Always observe spark plug condition for proper jetting.

1976 RV 250 MAIN JET APPLICATION CHART

Meters (feet) ALTITUDE	TEMPERATURE ° C (° F)							
	-45° C (-50)	-35° C (-30)	-25° C (-10)	-15° C (10)	0° C (30)	10° C (50)	20° C (70)	30° C (90)
0 (sea level)	350	330	320	310	300	290	280	270
600 m (2,000)	330	320	310	300	280	270	260	250
1,200 m (4,000)	310	300	290	280	270	260	250	240
1,800 m (6,000)	300	290	270	260	250	240	230	220
2,400 m (8,000)	280	270	260	250	240	220	210	200
3,000 m (10,000)	260	250	240	230	220	210	200	190

▼ CAUTION: These adjustments are guideline only, specific adjustments vary with temperature, altitude, atmospheric pressure and humidity. Always observe spark plug condition for proper jetting.

1976 RV 340 MAIN JET APPLICATION CHART

Meters (feet) ALTITUDE	TEMPERATURE ° C (° F)							
	-45° C (-50)	-35° C (-30)	-25° C (-10)	-15° C (10)	0° C (30)	10° C (50)	20° C (70)	30° C (90)
0 Sea level	370	360	350	330	320	310	300	290
600 m (2,000)	350	340	330	320	300	290	280	270
1,200 m (4,000)	330	320	310	300	290	270	260	250
1,800 m (6,000)	320	300	290	280	270	260	240	230
2,400 m (8,000)	300	290	280	260	250	240	230	210
3,000 m (10,000)	280	270	260	250	230	220	210	200

▼ CAUTION: These adjustments are guideline only, specific adjustments vary with temperature, altitude, atmospheric pressure and humidity. Always observe spark plug condition for proper jetting.

1977 RV 340 MAIN JET APPLICATION CHART

Meters (feet) ALTITUDE	TEMPERATURE ° C (° F)							
	-45° C (-50)	-35° C (-30)	-25° C (-10)	-15° C (10)	0° C (30)	10° C (50)	20° C (70)	30° C (90)
0 Sea level	350	340	330	320	310	300	280	270
600 m (2,000)	340	330	310	300	290	280	270	250
1,200 m (4,000)	320	310	300	290	270	260	250	240
1,800 m (6,000)	310	290	280	270	260	240	230	220
2,400 m (8,000)	290	280	260	250	240	230	220	200
3,000 m (10,000)	270	260	250	240	220	210	200	190

▼ CAUTION: These adjustments are guideline only, specific adjustments vary with temperature, altitude, atmospheric pressure and humidity. Always observe spark plug condition for proper jetting.

1971 72 73 74 BOSCH SPARK PLUG CHART

Engine Type	74		73		72		71	
	①	②	①	②	①	②	①	②
ELAN	250 (247)	M145T1	M175T1	M145T1	M175T1	M145T1	M175T1	M145T1
	250E (247)							
	250T (248)	W240T1	W240T1	W225T1	W225T1			
	250 Deluxe (248)	W260T1	W260T1	W260T1	W260T1			
	250SS (248)							
294SS (294)	W260T1	W260T1	W260T1	W260T1				
OLYMPIQUE	300 (302)	M175T1	M145T1	M175T1	M145T1	M175T1	M145T1	M145T1
	335 (337)							
	335 (337)							M175T1 (same as 1970)
OLYMPIQUE	340 (338)	W240T1	W225T1	W240T1	W225T1	W240T1	W225T1	W225T1
	369 (401)	W240T1	W240T1	W240T1	W240T1			
	440 (434)	M225T1	M175T1	M225T1	M175T1			
TNT	290 1 cyl. (292)							
	300 2 cyl. (294)	W260T1	W260T1	W260T1	W240T1	M260T31	M260T31	M260T31
	340 1 cyl. (342)	W260T1	W260T1	W260M1	W260T1	W260M1	M260T31	M260T31
	340 2 cyl. (343)	M260T1	M260T1	M260T31	M260T31	M260T31	M260T31	M260T31
	440 (434)							
	640 (641)							
	775 (775)					M310T31S	M280T31	M280T31
TNT F / A	340 (346)	W260M2	W260M2	W260M2	W260M2			
	440 (436)	W280M2	W280M2	W280M2	W280M2			
	400 (386)					TYPE 398		
	400 (398)					W280T30	W280T30	
NORDIC	399 (401)							
	440 (434)	M225T1	M225T1	M225T1	M225T1	(401)	W240T1	W225T1
	640 (640)						M225T1	M225T1
ALP. VAL.	399 (401)							
	440 (434)	M225T1	M175T1	M225T1	M175T1	M240T1	M225T1	W225T1
640 (640)	M225T1	M175T1	M225T1	M175T1	M225T1	M175T1	M225T1	
ELITE	440 (434)	M240T1	M225T1	M225T1	M175T1			

① Engine full load. ② Engine part load.

1975 76 77 BOSCH SPARK PLUG CHART

	Engine type	1975		1976		1977		
		①	②	①	②	①	②	
ELAN	250	(247)	M175T1	M145T1	M175T1	M175T1	M175T1	M175T1
	250 Deluxe	(248)	W240T1	W225T1	W240T1	W240T1	W240T1	W240T1
	300SS	(294)	W280T1	W240T1				
OLYMPIQUE	300 Mono	(302)			M225T1	M175T1	M175T1	M175T1
	300 Twin	(305)	W240T1	W225T1	W280T1	W240T1	W260M21	W240M21
	340	(343)	W260T1	W260T1	W260T1	W240T1	W260M21	W240M21
	Plus 440	(434)			M240T1	M225T1		
440	(440)					M260T1	M260T1	
EVEREST	340	(343)					W260M21	W260M21
	440	(440)	M260T1	M260T1	M260T1	M260T1	M260T1	M260T1
T'NT F / C	340	(343)	W260T1	W260T1	W260T1	W260T1		
	440	(440)	M260T1	M260T1				
T'NT	340	(346)					W260M22	W260M22
	440	(436)					W260M22	W260M22
	440	(440)					M260T1	M260T1
T'NT F / A	340	(346)	W280M2	W280M2				
	440	(436)	W280M2	W280M2				
T'NT RV	250	(245)	W280M22	W280M22	W280M22	W280M22	W280M22	W280M22
	340	(345)			W280M22	W280M22		
ELITE	440	(434)	M240T1	M225T1				
ALPINE	640	(640)	M225T1	M225T1	M225T1	M175T1	M240T1	M240T1

① Engine full load.

② Engine part load.

IGNITION GENERATING COIL, LIGHTING COIL & BRAKE LIGHT COIL RESISTANCE CHART

1974-75 MODELS		ENGINE TYPE	IGNITION GENERATING COIL		LIGHTING COIL		BRAKE LIGHT COIL	
			1974	1975	1974	1975	1974	1975
ELAN	250	247	3.4	3.4	0.45	0.45	1.85	1.85
	250T	248	1.15		0.45		1.90	
	250 Deluxe	248	1.15	1.15	0.45	0.45	1.90	1.90
	294SS,300SS	294	1.15	1.15	0.45	0.45	1.90	1.90
OLYMPIQUE	300	302	3.4		0.45		1.85	
	300	305		3.3		0.23		
	340	338	2.35		0.40		1.70	
	340	343		3.3		0.23		
	400	401	2.35		0.40		1.70	
	440	434	2.35		0.40		1.70	
EVEREST	440	440	3.4		0.40	0.23 ①		2.15 ②
T'NT F / C	300	294	1.15		0.45		1.90	
	340	343	3.4	3.3	0.40	0.23		
	440	440	3.4	3.3	0.40	0.23		
T'NT F / A	340	346			0.23	0.23		
	400	396			0.23			
	440	435			0.23	0.23		
	245 RV	245				0.23		
NORDIC	640	640			0.14			
ELITE	440	434	2.35	2.35	0.14	0.14	1.70	1.70
ALPINE	440	434	2.35		0.40		1.70	
	640	640	2.35	3.3	0.14	0.23		

All values are given in ohms, with a tolerance of $\pm 20\%$.

① ± 0.25 ohms


② additional lighting coil 30W

IGNITION GENERATING COIL LIGHTING COIL & BRAKE LIGHT COIL RESISTANCE CHART

1976-77 MODELS		ENGINE TYPE	IGNITION GENERATING COIL		LIGHTING COIL		BRAKE LIGHT COIL	
			1976	1977	1976	1977	1976	1977
ELAN	250	247	3.4	3.4	0.45	0.45	1.85	1.85
	250 Deluxe	248	1.15	1.15	0.45	0.45	1.90	1.90
OLYMPIQUE	300 Mono	302	3.4	3.4	0.45	0.45	1.85	1.85
	300 Twin	305	3.3	3.3	0.23	0.23		
	340	343	3.3	3.3	0.23	0.23		
	Plus (440) 440	434	2.36	3.3	0.45	0.23	1.70	
EVEREST	340	343		3.3		0.23		
	440	440	3.3	3.3	0.23	0.23		
T'NT F / C	340	343	3.3					
T'NT	340	346		3.3		0.23		
	440	436		3.3		0.23		
	440	440		3.3		0.23		
T'NT R / V	250	245	① 355		② 0.23		③ 2.15	
	340	345	① 355	355 ①	② 0.23	0.23 ②	③ 2.15	2.15 ①
ALPINE	640	640	3.3	3.3	③ 0.23	0.23 ③	③ 2.15	2.15 ①

All values are given in ohms, with a tolerance of $\pm 20\%$.

- ① ± 15 ohms
- ② ± 0.025 ohms
- ③ additional lighting coil 30W.





**Recreational
Products**

